

# Update the TV software

Philips continuously tries to improve its products and we recommend that you update the TV software when updates are available.

## What you need

To update with a USB storage device, you need:

- An empty USB flash drive. The USB flash drive must be FAT or DOS-formatted. Do not use a USB hard drive.
- A computer with Internet access
- An archive utility that supports the ZIP file format (for example, WinZip® for Microsoft® Windows® or StuffIt® for Macintosh®).

## Step 1: Check the current software version

- 1 Press **▲**.
- 2 Select [Setup] > [Software settings] > [Current software info], then press OK.
  - The current software information is displayed.
- 3 Write down the software version number.
- 4 To return, press OK.
- 5 To exit, press **↩**.

## Step 2: Download the latest software

### ! Caution

- Do not install a lower version of software than the current version installed on your product. Philips cannot be held liable or be made responsible for problems caused by a software downgrade.

- 1 Insert the USB flash drive into a USB port on your PC.
- 2 From your PC, navigate to [www.philips.com/support](http://www.philips.com/support)
- 3 Find your product and locate the software and drivers available for your TV set.
  - The software is available as a zip file.
- 4 If the software version is higher than the version on your TV, click the software update link.
- 5 Accept the license agreement and save the ZIP file to the USB flash drive.
- 6 Using the archive utility, extract all files to the root directory of the USB flash drive.
- 7 Disconnect the USB flash drive from the PC.

## Step 3: Update the TV software



### Warning

- Do not switch off the TV or remove the USB flash drive during the software update.
- If a power failure occurs during the update, do not remove the USB flash drive from the TV. The TV will continue the update as soon as power is restored.
- If an error occurs during the update, retry the procedure. If the error reoccurs, contact Philips Consumer Care.

- 1 Switch off the TV and disconnect all USB storage devices.
- 2 Connect the USB flash drive (containing the software update) to the USB connector on the TV.
- 3 Switch on the TV.
  - The TV detects the USB flash drive and starts to scan for software version.
  - A message prompts you to update the software.

 Note

- If the USB flash drive is not detected, disconnect it and reconnect again.

- 4 Follow the on-screen instructions to update the TV software.
- 5 Once complete, disconnect the USB flash drive from the TV.
- 6 Select [Restart], and then press OK to restart the TV.

 Note

- To prevent accidental updates to the TV software, delete all files from the USB flash drive.