

Clock Radio



*Let's make things better*

**PHILIPS**

**AJ 3225 - Clock radio**

English
Français
Español
Deutsch
Nederlands
Italiano



Meet Philips at the Internet http://www.philips.com

Printed in Hong Kong

English
<div><b>CONTROLS</b></div> <div> <p>① <b>ALARM 1 , ALARM 2</b></p> <ul style="list-style-type: none"><li><b>BUZ</b> activates the buzzer for alarm 1 or alarm 2</li> <li><b>RADIO</b> activates the radio for alarm 1 or alarm 2</li> <li><b>OFF</b> switches off the alarm 1 or alarm 2</li></ul> <p>② <b>Clock control</b></p> <ul style="list-style-type: none"><li><b>SET TIME</b><span> </span>: sets the clock time</li> <li><b>SET AL 1</b><span> </span>: sets the alarm time for alarm 1</li> <li><b>SET AL 2</b><span> </span>: sets the alarm time for alarm 2</li> <li><b>CLOCK</b><span> </span>: to run on clock time</li></ul> <p>③ <b>▲ / ▼</b><span> </span>: adjusts the hours and minutes for the clock and alarm times</p> <p>④ <b>DISPLAY</b><span> </span>- show the clock/ alarm times and status of the set</p> <p>⑤ <b>Battery door</b><span> </span>- opens to store a <b>9 volt 6F22</b> type battery (not included) for clock memory backup</p> <p>⑥ <b>VOL</b><span> </span>- adjusts the sound level</p> <p>⑦ <b>Frequency indicator</b><span> </span>- shows the radio frequency of your selected waveband</p> <p>⑧ <b>BAND</b><span> </span>-select FM/MW (AM or LW) waveband</p> <p>⑨ <b>TUNING</b><span> </span>- tunes to radio stations</p> <p>⑩ <b>SLEEP OFF /REPEAT ALARM</b></p> <ul style="list-style-type: none"><li>switches off the radio sleep function</li> <li>switches off the active alarm for a 6-7 minute period</li></ul> <p>⑪ <b>SLEEP</b><span> </span>- activates the radio for sleep function</p> <ul style="list-style-type: none"><li>adjusts the sleep period</li></ul> <p>⑫ <b>24 HOUR RESET</b><span> </span>- stops the active alarm for 24 hours</p> <p>⑬ <b>RADIO on / off</b><span> </span>- switches the radio on/off</p> <p>⑭ <b>BRIGHTNESS</b><span> </span>- changes the brightness of the display illumination</p> <p>⑮ <b>Mains lead</b><span> </span>- for AC mains supply</p> <p>⑯ <b>Pigtail aerial</b><span> </span>- improves FM reception</p></div>
<div><b>INSTALLATION</b></div> <div> <p><b>POWER SUPPLY</b></p> <p><b>1</b> Check if the mains supply, as shown on the <b>type plate as shown inside the battery compartment</b>, corresponds to your local mains supply. If it does not, consult your dealer or service center.</p> <p><b>2</b> Connect the mains cord to the wall socket.</p> <p><b>3</b> <b>To disconnect the set from the mains supply completely, remove the plug from the wall socket.</b></p></div>
<div><b>CLOCK MEMORY BACKUP</b></div> <div> <p>The clock memory backup allows your alarm and clock time settings to be stored for up to a day when there is a power interruption e.g. mains failure. The complete clock radio and display illumination will be switched off. As soon as the mains supply returns, the display will indicate the correct time.</p></div>
<div><b>STAND-BY POWER CONSUMPTION</b></div> <div> <p><b>1</b> Remove the battery door to insert a <b>9 volt 6F22</b> type battery (not included) for backup.</p> <p><b>2</b> Replace the battery door.</p></div> <p><i><b>NOTE:</b> If no backup battery is installed or the power interruption is prolonged, you will need to set the clock and alarm times again.</i></p> <p><i><b>Batteries contain chemical substances so should be disposed of properly.</b></i></p>
<div><b>Standby power consumption</b></div> <div> <p>.....3W</p></div>
<div><b>For users in the UK: please follow the instructions on the reverse of this sheet.</b></div>
ILLUMINATION BRIGHTNESS
<div> <p>Adjust the <b>BRIGHTNESS</b> switch to HI or LOW</p> <ul style="list-style-type: none"><li>HI to increase brightness</li> <li>LOW to select low illumination</li></ul></div>
<div><b>SWITCHING OFF THE ALARM</b></div> <div> <p>There are three ways of switching off the alarm. Unless you cancel the alarm completely, the <b>24 hour alarm reset option</b> will be automatically selected after 59 minutes, from the time your alarm time first goes off.</p></div> <p><b>24 HOUR ALARM RESET</b></p> <p>If you want the alarm mode to be stopped immediately but also wish to retain the same alarm setting for the following day:</p> <ul style="list-style-type: none"><li>Press <b>24 HOUR RESET</b> during the alarm call.</li></ul>

## RADIO

*You can use this set solely as a radio!*

- Adjust **RADIO off /on** to **ON** to switch on the radio.
- Select your waveband by adjusting the **BAND** switch.
- Adjust **TUNING** to tune to your desired station.
- Turn the **VOLUME** control to adjust the volume level.
- Adjust **RADIO off /on** to **OFF** to switch off the radio.

**To improve reception:**

- FM:** extend and position the pigtail for optimum reception.
- AM:** uses a built-in aerial inside the set. Direct the aerial by adjusting the position of your set.

### SETTING THE CLOCK AND ALARM TIMES

The time is displayed using the 24-hour clock

***IMPORTANT!** To adjust the clock and alarm times accurately, always make sure you press the ▲ or ▼ buttons separately and not simultaneously.*

- Adjust the **clock control** to **SET TIME** or **SET AL 1** or **SET AL 2** to set the clock or alarm time respectively.
- Press **▲** or **▼** repeatedly or hold down on the respective button to adjust the hours and minutes.
- Release **▲** or **▼** when you reach the correct setting.
- After you have set both the hour and minutes, adjust the **clock control** to **CLOCK** to run on clock time.

### SELECTING THE ALARM MODE

#### GENERAL

If you wish to use the alarm, you must first set the alarm time first. You can choose from two different alarm modes to wake you up: by radio or buzzer.

- Select your choice of alarm mode by adjusting **ALARM 1** or **ALARM 2** to **RADIO** or **BUZ**
  - The 2 buzzers are at a set volume and cannot be adjusted. **BUZ** on **ALARM 1** is a low tone buzzer while **BUZ** on **ALARM 2** is a high tone.

### MAINTENANCE

- If you do not intend to use the set for a long time, withdraw the mains plug from the wall socket. In addition to this, it is advisable to remove the battery from the clock radio. This will prevent any danger of leakage and the clock radio will not be damaged.
- Do not expose the set to humidity, rain, sand or excessive heat caused by heating equipment or direct sunlight.
- To clean the set, use a soft, slightly dampened chamois leather. Do not use any cleaning agents containing alcohol, ammonia, benzene or abrasives as these may harm the housing.

### ENVIRONMENTAL INFORMATION

We have reduced packaging to the minimum for easy separation into two materials: paper and cardboard.

Your set consists of materials which can be recycled if disassembled by a specialized company. Please observe local regulations on the disposal of packing materials and old equipment.

<p><i><b>This product complies with the radio interference requirements of the European Union.</b></i></p> <p><i><b>The type plate is located on the bottom of the set.</b></i></p>
---

***Graphical symbols and supplementary markings are located on the bottom of the set.***

Français
<div><b>BOUTONS DE COMMANDE</b></div> <div> <p>① <b>ALARM 1 , ALARM 2</b></p> <ul style="list-style-type: none"><li><b>BUZ</b> activation de la sonnerie pour l’alarme1 ou alarme 2</li> <li><b>RADIO</b> activation de la radio pour l’alarme 1 ou alarme 2</li> <li><b>OFF</b> pour éteindre l’alarme 1 ou alarme 2</li></ul> <p>② <b>Contrôle de l’horloge</b></p> <ul style="list-style-type: none"><li><b>SET TIME</b><span> </span>: pour fixer l’heure de l’horloge</li> <li><b>SET AL 1</b><span> </span>: mise à l’heure de l’alarme 1</li> <li><b>SET AL 2</b><span> </span>: mise à l’heure de l’alarme 2</li> <li><b>CLOCK</b><span> </span>: pour faire fonctionner à l’heure de l’horloge</li></ul> <p>③ <b>▲ / ▼</b><span> </span>: pour régler les heures et minutes de l’horloge et des alarmes.</p> <p>④ <b>ÉCRAN AFFICHEUR</b><span> </span>- démontre les heures de l’horloge/l’alarme et le statut de réglage du radio-réveil</p> <p>⑤ <b>Couvercle du logement de la pile</b><span> </span>- s’ouvre pour placer une pile de type <b>9 volt 6F22</b> (non-incluse) pour mémoire de secours de l’horloge</p> <p>⑥ <b>VOL</b><span> </span>- ajuste le niveau du son</p> <p>⑦ <b>L’indicateur de fréquences</b><span> </span>- indique la fréquence radio de la bande d’onde sélectionnée.</p> <p>⑧ <b>BAND</b><span> </span>-sélectionne la bande de fréquence FM/MW (AM ou LW)</p> <p>⑨ <b>TUNING</b><span> </span>-réglage pour stations de radio</p> <p>⑩ <b>SLEEP OFF /REPEAT ALARM</b></p> <ul style="list-style-type: none"><li>ferme/éteint le mode sommeil de l’appareil</li> <li>ferme/éteint l’alarme pour une période de 6-7 minutes</li></ul> <p>⑪ <b>SLEEP</b><span> </span>- active la fonction sommeil du radio</p> <ul style="list-style-type: none"><li>réglage de la durée avant mise en sommeil</li></ul> <p>⑫ <b>24 HOUR RESET</b><span> </span>- arrête l’alarme pour une période de 24 heures</p> <p>⑬ <b>RADIO on / off</b><span> </span>- pour mettre en marche ou fermer le radio</p> <p>⑭ <b>BRIGHTNESS</b><span> </span>- pour modifier la luminosité de l’affichage</p> <p>⑮ <b>Cordon d’Alimentation sur le Secteur</b><span> </span>- pour une alimentation sur Courant Alternatif</p> <p>⑯ <b>Antenne en tîre bouchon</b><span> </span>- pour améliorer la réception FM</p></div>
<div><b>INSTALLATION</b></div> <div> <p><b>POWER SUPPLY</b></p> <p><b>1</b> Check if the mains supply, as shown on the <b>type plate as shown inside the battery compartment</b>, corresponds to your local mains supply. If it does not, consult your dealer or service center.</p> <p><b>2</b> Connect the mains cord to the wall socket.</p> <p><b>3</b> <b>To disconnect the set from the mains supply completely, remove the plug from the wall socket.</b></p></div>
<div><b>CLOCK MEMORY BACKUP</b></div> <div> <p>The clock memory backup allows your alarm and clock time settings to be stored for up to a day when there is a power interruption e.g. mains failure. The complete clock radio and display illumination will be switched off. As soon as the mains supply returns, the display will indicate the correct time.</p></div>
<div><b>Standby power consumption</b></div> <div> <p>.....3W</p></div>
<div><b>For users in the UK: please follow the instructions on the reverse of this sheet.</b></div>
ILLUMINATION BRIGHTNESS
<div> <p>Adjust the <b>BRIGHTNESS</b> switch to HI or LOW</p> <ul style="list-style-type: none"><li>HI to increase brightness</li> <li>LOW to select low illumination</li></ul></div>
<div><b>SWITCHING OFF THE ALARM</b></div> <div> <p>There are three ways of switching off the alarm. Unless you cancel the alarm completely, the <b>24 hour alarm reset option</b> will be automatically selected after 59 minutes, from the time your alarm time first goes off.</p></div> <p><b>24 HOUR ALARM RESET</b></p> <p>If you want the alarm mode to be stopped immediately but also wish to retain the same alarm setting for the following day:</p> <ul style="list-style-type: none"><li>Press <b>24 HOUR RESET</b> during the alarm call.</li></ul>

## SWITCHING OFF THE ALARM

There are three ways of switching off the alarm. Unless you cancel the alarm completely, the **24 hour alarm reset option** will be automatically selected after 59 minutes, from the time your alarm time first goes off.

## 24 HOUR ALARM RESET

If you want the alarm mode to be stopped immediately but also wish to retain the same alarm setting for the following day:

- Press **24 HOUR RESET** during the alarm call.

### CANCELING THE ALARM COMPLETELY

To cancel the set alarm time before it goes off, or during the alarm call:

- Adjust **ALARM 1** or **ALARM 2** to **OFF** position.

### REPEAT ALARM

This repeats your alarm call at 6-7-minute intervals.

- During the alarm call, press **SLEEP OFF /REPEAT ALARM**.
- Repeat if desired for up to 59 minutes.

## SLEEP

#### About Sleep

This set has a built-in timer which enables the set to be automatically switched off during radio playback after a set period of time. This allows you to lie back, listen and fall asleep. The maximum sleep time is 59 minutes.

#### Setting SLEEP

- Check that both the **clock control** is in **CLOCK** position and the radio is switched off.
  - Set your sleep time by pressing on the **SLEEP** button. Keep your finger on the button and the display will begin to count down from **0:59** to **0:00** minutes.
    - To cancel sleep, or to switch off the sleep period press **SLEEP OFF /REPEAT ALARM**.
- IMPORTANT!***
- 1** During **SLEEP** activation, if you attempt to cancel **SLEEP** by pressing **RADIO ON / OFF**, the radio cannot be switched off.

- To switch off, press **RADIO ON / OFF** and **SLEEP OFF /REPEAT ALARM** alternately and repeatedly.

### TROUBLESHOOTING

If a fault occurs, first check the points listed below before taking the set for repair. If you are unable to remedy a problem by following these hints, consult your dealer or service center.

***WARNING:** Under no circumstances should you try to repair the set yourself, as this will invalidate the warranty. Do not open the set as there is a risk of electric shock.*

## Problem

- Possible Cause*
- Remedy

#### SLEEP does not function

- Radio already in the ON position*
- Switch off the radio first, before setting **SLEEP**

#### Occasional crackling sound during FM broadcast

- Weak signal*
- Extend and position the pigtail

#### Continuous crackling/hiss disturbance during MW (AM/LW) broadcast

- Electrical interference from TV, computer, fluorescent lamp, etc.*
- Move set away from other electrical equipment

#### The alarm does not function

- Alarm time not set and/or alarm mode not selected*
- See the alarm time and / select alarm mode

- Volume too low for RADIO*
- Adjust the volume

- Radio alarm not adjusted to radio station*
- Tune to a radio station

Français
<div><b>BOUTONS DE COMMANDE</b></div> <div> <p>① <b>ALARM 1 , ALARM 2</b></p> <ul style="list-style-type: none"><li><b>BUZ</b> activation de la sonnerie pour l’alarme1 ou alarme 2</li> <li><b>RADIO</b> activation de la radio pour l’alarme 1 ou alarme 2</li> <li><b>OFF</b> pour éteindre l’alarme 1 ou alarme 2</li></ul> <p>② <b>Contrôle de l’horloge</b></p> <ul style="list-style-type: none"><li><b>SET TIME</b><span> </span>: pour fixer l’heure de l’horloge</li> <li><b>SET AL 1</b><span> </span>: mise à l’heure de l’alarme 1</li> <li><b>SET AL 2</b><span> </span>: mise à l’heure de l’alarme 2</li> <li><b>CLOCK</b><span> </span>: pour faire fonctionner à l’heure de l’horloge</li></ul> <p>③ <b>▲ / ▼</b><span> </span>: pour régler les heures et minutes de l’horloge et des alarmes.</p> <p>④ <b>ÉCRAN AFFICHEUR</b><span> </span>- démontre les heures de l’horloge/l’alarme et le statut de réglage du radio-réveil</p> <p>⑤ <b>Couvercle du logement de la pile</b><span> </span>- s’ouvre pour placer une pile de type <b>9 volt 6F22</b> (non-incluse) pour mémoire de secours de l’horloge</p> <p>⑥ <b>VOL</b><span> </span>- ajuste le niveau du son</p> <p>⑦ <b>L’indicateur de fréquences</b><span> </span>- indique la fréquence radio de la bande d’onde sélectionnée.</p> <p>⑧ <b>BAND</b><span> </span>-sélectionne la bande de fréquence FM/MW (AM ou LW)</p> <p>⑨ <b>TUNING</b><span> </span>-réglage pour stations de radio</p> <p>⑩ <b>SLEEP OFF /REPEAT ALARM</b></p> <ul style="list-style-type: none"><li>ferme/éteint le mode sommeil de l’appareil</li> <li>ferme/éteint l’alarme pour une période de 6-7 minutes</li></ul> <p>⑪ <b>SLEEP</b><span> </span>- active la fonction sommeil du radio</p> <ul style="list-style-type: none"><li>réglage de la durée avant mise en sommeil</li></ul> <p>⑫ <b>24 HOUR RESET</b><span> </span>- arrête l’alarme pour une période de 24 heures</p> <p>⑬ <b>RADIO on / off</b><span> </span>- pour mettre en marche ou fermer le radio</p> <p>⑭ <b>BRIGHTNESS</b><span> </span>- pour modifier la luminosité de l’affichage</p> <p>⑮ <b>Cordon d’Alimentation sur le Secteur</b><span> </span>- pour une alimentation sur Courant Alternatif</p> <p>⑯ <b>Antenne en tîre bouchon</b><span> </span>- pour améliorer la réception FM</p></div>
<div><b>INSTALLATION</b></div> <div> <p><b>POWER SUPPLY</b></p> <p><b>1</b> Check if the mains supply, as shown on the <b>type plate as shown inside the battery compartment</b>, corresponds to your local mains supply. If it does not, consult your dealer or service center.</p> <p><b>2</b> Connect the mains cord to the wall socket.</p> <p><b>3</b> <b>To disconnect the set from the mains supply completely, remove the plug from the wall socket.</b></p></div>
<div><b>CLOCK MEMORY BACKUP</b></div> <div> <p>The clock memory backup allows your alarm and clock time settings to be stored for up to a day when there is a power interruption e.g. mains failure. The complete clock radio and display illumination will be switched off. As soon as the mains supply returns, the display will indicate the correct time.</p></div>
<div><b>Standby power consumption</b></div> <div> <p>.....3W</p></div>
<div><b>For users in the UK: please follow the instructions on the reverse of this sheet.</b></div>
ILLUMINATION BRIGHTNESS
<div> <p>Adjust the <b>BRIGHTNESS</b> switch to HI or LOW</p> <ul style="list-style-type: none"><li>HI to increase brightness</li> <li>LOW to select low illumination</li></ul></div>
<div><b>SWITCHING OFF THE ALARM</b></div> <div> <p>There are three ways of switching off the alarm. Unless you cancel the alarm completely, the <b>24 hour alarm reset option</b> will be automatically selected après 59 minutes, à partir du temps où votre alarme sonnera pour la première fois.</p></div> <p><b>“RESET” D’ALARME 24 HEURES</b></p> <p>Si vous désirez que le mode d’alarme soit arrêté immédiatement mais vous désirez également garder le même réglage pour la journée suivante:</p> <ul style="list-style-type: none"><li>Appuyez le bouton <b>24 HOUR RESET</b> pendant le cri de l’alarme.</li></ul>

English
<div><b>BOUTONS DE COMMANDE</b></div> <div> <p>① <b>ALARM 1 , ALARM 2</b></p> <ul style="list-style-type: none"><li><b>BUZ</b> activation de la sonnerie pour l’alarme1 ou alarme 2</li> <li><b>RADIO</b> activation de la radio pour l’alarme 1 ou alarme 2</li> <li><b>OFF</b> pour éteindre l’alarme 1 ou alarme 2</li></ul> <p>② <b>Contrôle de l’horloge</b></p> <ul style="list-style-type: none"><li><b>SET TIME</b><span> </span>: pour fixer l’heure de l’horloge</li> <li><b>SET AL 1</b><span> </span>: mise à l’heure de l’alarme 1</li> <li><b>SET AL 2</b><span> </span>: mise à l’heure de l’alarme 2</li> <li><b>CLOCK</b><span> </span>: pour faire fonctionner à l’heure de l’horloge</li></ul> <p></p></div>



