

Quick start guide



- 1 Prepare
- 2 Connect
- 3 Enjoy


PHILIPS

Please read and accept our Streamium terms & conditions as well as the Software End User License Agreement that are included in the User Manual.

What's in the box



Streamium Network Music Player NP1100



Remote control
2 x AAA batteries



1 x RCA cable




1 x AC power cable



CD-ROM containing
user manual and
software


Before using the remote control:

Insert batteries as shown.



I Prepare

Front view




- ① Display

Top view




- ① **STANDBY - ON**

Rear view




- ① **LINE OUT** (red/white) jacks
② **DIGITAL OUT** jack
③  jack
④ **ETHERNET** jack
⑤ **POWER SUPPLY** jack

Remote control



- ① **Power**
- ② **MUSIC SERVICES** optional feature available in some regions
- ③ **SETTINGS**
- ④ **DIM** adjust display
- ⑤ **FAVORITE**
- ⑥ **SEARCH**
- ⑦ **▲ ▼ ◀ ▶** navigate
- ⑧ **OK / ▶||** confirm / play/pause
- ⑨ **▶▶** skip forward
- ⑩ **■** stop
- ⑪ **+ VOL -**
- ⑫ **MUTE**
- ⑬ **CLEAR**
- ⑭ **a/A** case shift
- ⑮ **▲RATE▼**
- ⑯ **◀◀** skip back
- ⑰ **HOME**
- ⑱ **SHUFFLE** random play
- ⑲ **REPEAT**
- ⑳ **MUSIC**
- ㉑ **INTERNET RADIO**

2 Connect



- A** Connect a sound system
- B** Connect the player to the power supply
- C** Connect the player to a home network
- D** Wirelessly stream music from a PC

This section describes the most commonly used wireless home network setup. (For instructions on how to create a 'wired' connection, refer to the User Manual.)

When you connect the player to a home network with broadband Internet access

You can listen to Internet radio

You can connect to the Internet for firmware updates

START HERE...

Important! For first-time setup, hold ready your network name and network password or the encryption key.

A Connect a sound system

- 1 Use the supplied red and white audio cables to connect the AUX IN jacks of the sound system with the red and white **LINE OUT** jacks of the NP1100.
- 2 Set the source of the sound system to 'AUX' and control the sound system as you normally would.

B Connect the player to the power supply

After a short introduction demo, the player shows the [**Language**] screen.

- 1 Press ▲▼ to select the language, then press ►.
> The display shows the [**Date format**] screen.
- 2 Press ▲▼ to adjust, then ► to confirm the setting and skip to the next setting.
- 3 Follow step 2 to set date format, time format, date, and time.
> The display shows the [**Network setup**] screen.

C Create a wireless connection to your home network with broadband Internet access

- 1 Press **▲▼** to select **[Wireless]**, then press **▶**.
- 2 Press **▶** to start searching for your home network.
- 3 Press **▲▼** to select your home network with wireless broadband Internet access, then press **▶**.
- 4 Select **[Automatic]** > (Enable Proxy?) **[No (default)]**.
> *The NP1100 displays a confirmation screen that the settings are saved.*

Here is how to create a wireless connection any time ‘after’ the initial setup:

- 1 Ensure that your wireless access point or wireless router is turned on and connected to broadband Internet.
- 2 Ensure that the NP1100 is turned on and connected to the wireless access point or wireless router.
- 3 On the NP1100, configure the network:
- 4 Press **HOME**.
- 5 Press **▲▼**, then to select **[Settings]** > **[Network setup]** > **[Wireless]** > **[Search for networks]**.
- 6 Press **▲▼**, then to select network.
 - Enter encryption key (if required).

Note For details on how to create wired connection, refer to the User Manual.

D Wirelessly stream music from a PC

You can wirelessly stream music to the NP1100 from a connected PC, if you install Windows Media Player 11 on the PC and configure the PC to share your music. (If Windows Media Player 11 is already installed on the PC, you can skip the installation section and continue with the configuration.)

Install Windows Media Player 11

- 1 On the PC, insert the supplied software CD.
 - Installation starts.
 - If installation does not start, click on the Windows Media Player 11 📀 icon in your Explorer program.
- 2 Follow the instructions on the PC to install Windows Media Player 11.

Configure a PC to share music

This chapter shows you how to configure the PC to share music with the NP1100.

- 1 Follow the instructions to install Windows Media Player 11.
- 2 On the PC, click **Start > Programs > Windows Media Player**.
- 3 In the Windows Media Player interface, click on the Library pull-down menu and select **Media sharing...**



- In the Media sharing... pop-up window, select Share my media, then confirm with **OK**.
 - When the NP1100 is connected to your home network, the display shows the NP1100 with an alert icon: 
- Click on the NP1100.
- Select **Allow**, then confirm with **OK**.
- On the NP1100, press **HOME**.
- Press **▲▼** to select **[Music]**, then press **▶**.
 - > The display shows **[Searching for UPnP servers...]**, followed by the list of media servers.*
- Press **▲▼** to select the PC, then press **▶**.

3 Enjoy

Internet radio

Note Internet radio features require that the NP1100 is connected to a home network with broadband Internet access.

A Listen to Internet radio

- Ensure that the NP1100 is turned on.
- Ensure that the NP1100 is connected to the home network with broadband Internet access.
- Press **INTERNET RADIO**.
 - The options are displayed.
 - To listen to a specific Internet radio station, select option **[Search]**, then use the alphanumeric buttons to enter the radio station name.
- Press **▲▼** to select the station, then press **▶**.
 - To return to the Home menu, press **HOME**.

Need help?

User Manual

See the user manual that came with your player.

Online

Go to www.philips.com/welcome

Hearing Safety

Listen at a moderate volume.

- Using headphones at a high volume can impair your hearing. This product can produce sounds in decibel ranges that may cause hearing loss for a normal person, even for exposure less than a minute. The higher decibel ranges are offered for those that may have already experienced some hearing loss.
- Sound can be deceiving. Over time your hearing “comfort level” adapts to higher volumes of sound. So after prolonged listening, what sounds “normal” can actually be loud and harmful to your hearing. To guard against this, set your volume to a safe level before your hearing adapts and leave it there.



To establish a safe volume level:

- Set your volume control at a low setting.
- Slowly increase the sound until you can hear it comfortably and clearly, without distortion.

Listen for reasonable periods of time:

- Prolonged exposure to sound, even at normally “safe” levels, can also cause hearing loss.
- Be sure to use your equipment reasonably and take appropriate breaks.

Be sure to observe the following guidelines when using your headphones.

- Listen at reasonable volumes for reasonable periods of time.
- Be careful not to adjust the volume as your hearing adapts.
- Do not turn up the volume so high that you can't hear what's around you.
- You should use caution or temporarily discontinue use in potentially hazardous situations.
- Do not use headphones while operating a motorized vehicle, cycling, skateboarding, etc.; it may create a traffic hazard and is illegal in many areas.

Important

Safety

Know these safety symbols




This 'bolt of lightning' indicates uninsulated material within your unit may cause an electrical shock. For the safety of everyone in your household, please do not remove product covering. The 'exclamation point' calls attention to features for which you should read the enclosed literature closely to prevent operating and maintenance problems.

WARNING: To reduce the risk of fire or electric shock, this apparatus should not be exposed to rain or moisture and objects filled with liquids,

such as vases, should not be placed on this apparatus.
CAUTION: To prevent electric shock, match wide blade of plug to wide slot, fully insert.

- ① Read these instructions.
- ② Keep these instructions.
- ③ Heed all warnings.
- ④ Follow all instructions.
- ⑤ Do not use this apparatus near water.
- ⑥ Clean only with dry cloth.
- ⑦ Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- ⑧ Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- ⑨ For countries with a polarized mains, do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.

Caution: To prevent electric shock, match the wide blade of the plug to the wide slot, fully insert.



- ⑩ Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- ⑪ Only use attachments/accessories specified by the manufacturer.
- ⑫ Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



- ⑬ Unplug this apparatus during lightning storms or when unused for long periods of time.
- ⑭ Refer all servicing to qualified service personnel. Servicing is required when

the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

- ⑮ **Battery usage CAUTION** – To prevent battery leakage which may result in bodily injury, property damage, or damage to the unit:
 - Install all batteries correctly, + and - as marked on the unit.
 - Do not mix batteries (old and new or carbon and alkaline, etc.).
 - Remove batteries when the unit is not used for a long time.
- ⑯ Apparatus shall not be exposed to dripping or splashing.
- ⑰ Do not place any sources of danger on the apparatus (e.g. liquid filled objects, lighted candles).
- ⑱ This product may contain lead and mercury. Disposal of these materials may be regulated due to environmental considerations. For disposal or recycling information, please contact your local authorities or the Electronic Industries Alliance: www.eiae.org.



Warning

- Never remove the casing of this NP1100.
- Never lubricate any part of this NP1100.
- Place this NP1100 on a flat, hard and stable surface.
- Never place this NP1100 on other electrical equipment.
- Only use this NP1100 indoors. Keep this NP1100 away from water, moisture and liquid-filled objects.
- Keep this NP1100 away from direct sunlight, naked flames or heat.

How to connect a plug

The wires in the mains lead are coloured with the following code: blue = neutral (N), brown = live (L).

As these colours may not correspond with the colour markings identifying the terminals in your plug, proceed as follows:

- Connect the blue wire to the terminal marked N or coloured black.
- Connect the brown wire to the terminal marked L or coloured red.
- Do not connect either wire to the earth terminal in the plug, marked E (or e) or coloured green (or green and yellow).

Before replacing the plug cover, make certain that the cord grip is clamped over the sheath of the lead - not simply over the two wires.

Mains plug

This apparatus is fitted with an approved 13 Amp plug. To change a fuse in this type of plug

proceed as follows:

- ① Remove fuse cover and fuse.
- ② Fix new fuse which should be a BS13625 Amp, A.S.T.A. or BSI approved type.
- ③ Refit the fuse cover.

If the fitted plug is not suitable for your socket outlets, it should be cut off and an appropriate plug fitted in its place.

If the mains plug contains a fuse, this should have a value of 5 Amp. If a plug without a fuse is used, the fuse at the distribution board should not be greater than 5 Amp.

The severed plug must be disposed off to avoid a possible shock hazard should it be inserted into a 13 Amp socket elsewhere.

Norge

Typeskilt finnes på apparatens bakside. Observer: Nettbryteren er sekundært innkoplet. Den innebygde nettdelen er derfor ikke fraktoplett nettet så lenge apparatet er tilsluttet nettkontakten.

For å redusere faren for brann eller elektrisk støt, skal apparatet, ikke utsettes for regn eller fuktighet.

Notice

Notice of compliance

For USA:

This equipment has been tested and found

to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

For Canada:

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications. This Class B digital apparatus complies with Canadian ICES-003.

Class II equipment symbol



This symbol indicates that the unit has a double insulation system.

Disposal of product and packing material

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



When this crossed-out wheeled bin symbol is attached to a product, it means the product is covered by the European Directive 2002/96/EC.

Please be informed about the local separate collection system for electrical and electronic products.

Please act according to your local rules and do not dispose of your old product with your normal

household waste. The correct disposal of your old product will help prevent potential negative consequences to the environment and human health. All redundant packing material has been omitted. We have done our utmost to make the packaging easily separable into mono materials. Please observe the local regulations regarding the disposal of packing materials.

Environmental information

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet.)

Your system consists of materials which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.

Battery disposal information

Batteries (including built-in rechargeable batteries) contain substances that may pollute the environment. Always hand the appliance in at an official collection point to remove any built-in batteries before you discard the appliance. All batteries must be disposed of at an official collection point.





Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners
© 2008 Koninklijke Philips Electronics N.V.
All rights reserved.
www.philips.com



Printed in China
wk8181