

1. Introduction

The Firmware Upgrade will upgrade WAC700 & WACS700's firmware to **Version 1.2.10**.

2. Key features added

The software release 1.2.10 has provided a solution for CD ejection problem that has happened on a marginal number of CDs.

3. Preparation

i) Verifying firmware version

Before upgrading, check the firmware version.

1. Turn on your WAC700 Center
2. Press **MENU**
3. Press **▲/▼** to select "**Information**". Press **OK**
 - The display shows the FW (firmware) version number
 - Upgrading is necessary if the FW version is an earlier one

***Note:** The firmware information is also useful when you call Philips Customer Care Center.*

ii) Checking Wi-Fi connection

Wi-Fi connection between Center and Station:

- Check you have pressed **STANDBY-ON** to turn on WAC700 Center and WAS700 Station
- On Station, check you can playback tracks in **HD** mode
- On Station, check the signal indication shows maximum reception

Wi-Fi connection with the Wireless router/Access Point (if applicable):

- Check the Wireless router/Access Point is working if your Center is connected to PC via a Wireless router/Access Point
-

4. Upgrading

You can upgrade the embedded firmware in 2 ways


A) [Upgrading from CD-ROM](#)

B) [Upgrading from PC](#)

A) Upgrading from CD-ROM

i) Prepare an upgrading CD


1. Check you have the following tools:
 - PC (Pentium III 300MHz processor or higher)
 - CD-R/RW writer and writing application software
 - Blank CD-R or CD-RW disc
 - Internet access (broadband or high speed)
2. Click the link to download Firmware Upgrade to your PC



3. Unzip the .zip file
(**Note:** - Do not rename the filename.
- Visit <http://www.winzip.com/> for downloads if you can not open the .zip file.)

4. Write the extracted files – not the zip file – onto a blank CD-R or CD-RW disc, using the following settings:
 - File System CD-ROM Joliet
 - File name length : max 31 chars (ISO Level 2)
 - Mode : 2/XA
 - Character set : ASCII
 - Single session
 - Write Speed : Low
 - Finalized the disc. (The application may do this automatically.)


(Note: Make sure you finalize the CD)



ii) Upgrade WACS700

Upgrade WAC700 Center:

1. Check WAC700 Center is on and WAS700 Station is off
2. On Center, insert the upgrading CD into the CD slot loader, with CD graphic printed side facing you



- Upgrading starts automatically
- The display shows “**Updating firmware, please wait.....**” .
A progress bar appears
- Center will reboot itself twice during the upgrading process
- After about 5 minutes, Center returns to HD mode. The upgrading is completed
(*Note: - Keep your Center turned on during the upgrading.*)

Upgrade WAS700 Station:

3. Press **STANDBY-ON** to turn WAS700 Station
 - Upgrading starts automatically
 - The display shows “**Updating firmware, please wait.....**” .
A progress bar appears
 - Station will reboot itself twice during the upgrading process
 - After about 5 minutes, Station returns to HD mode. The upgrading is completed
(*Note: - Keep your Station turned on during the upgrading.*)

Helpful hints:

- To check the firmware version, see ***Preparation: Verifying firmware version.***
- If you have any problem, see [troubleshooting](#).

B) Upgrading from PC

i) Download Firmware Upgrade to your PC

1. Click the link to download Firmware Upgrade to your PC




2. Unzip the .zip file
(*Note:* - Do not rename the filename.
- Visit <http://www.winzip.com/> for downloads if you can not open the .zip file.)


ii) Upgrade WACS700

Upgrade WAC700 Center:


1. Connect your PC and WAC700 Center using the supplied Ethernet cable
2. Launch the Digital Media Manager (DMM) on your PC
3. Select **Preference** → **Player Firmware** → **Upgrade Firmware**




4. Click **Yes** to start upgrading




5. Find the Firmware Upgrade file you stored in the PC. Click **Open**



→ You will start transferring the file to WAC700 Center



→ After file transferring is finished, upgrading starts automatically on WAC700 Center



- The Center's display shows "Updating firmware, please wait.....". A progress bar appears
 - Center will reboot itself twice during the upgrading process
 - After about 5 minutes, Center returns to HD mode. The upgrading is completed
- (Note: - Keep your Center turned on during the upgrading.)

Upgrade WAS700 Station:

6. Press **STANDBY-ON** to turn on WAS700 Station
 - Upgrading starts automatically
 - The display shows “**Updating firmware, please wait.....**” .
A progress bar appears
 - Station will reboot itself twice during the upgrading process
 - After about 5 minutes, Station returns to HD mode. The upgrading is completed

(*Note:* - Keep your Station turned on during the upgrading.)

Helpful hints:

- To check the firmware version, see **Preparation: Verifying firmware version.**
 - If you have any problem, see [troubleshooting](#).
-

5. Troubleshooting

If the Station’s display shows: "**Firmware is damaged, restoring a new copy ...**" or "**Center is connected, retrieving firmware**"

Follow the DON’T below:

- a. **DON’T restore Center’s setting** (Don’t select "Menu" → "Setting" → "Restore Setting" on Center)
- b. **DON’T delete Stations** from Center (Don’t select "Menu" → "Station Mgmt" → "Delete Station" on Center)
- c. **Do NOT change Center’s Wi-Fi setting**

Then,

1. If the progress bar is moving on, wait and upgrading will start later on the Station
 2. If the progress bar stops moving and/or Station’s display shows "**Error Code xxx**", turn off the Station and then turn it on.
 3. If Step 2’s problem still exists, check there is no Wi-Fi interference around and reduce the distance between Center, Station and Wireless router/Access Point (if applicable)
-

6. Firmware history

Version 1.2.10

- The software release 1.2.10 has provided a solution for CD ejection problem that has happened on a marginal number of CDs.

Version 1.2.6

- The software release 1.2.6 has improved certain software stability of WAC700.

Version 1.1.17

- Improved the CD slot loader mechanism to be more robust during insertion and ejection.

Version 1.1.15

- Improved Wi-Fi connection, shorten the connection time.
- Improved the CD slot loader mechanism to be more robust during insertion and ejection.

Version 1.1.10

- Firmware released later than the Version 1.0. Version 1.1.10 provides more stable Wi-Fi streaming for MP3 tracks

Note: If power failure occurs during CD ripping, you will lose all the tracks not compressed yet.

Version 1.0

- Firmware installed on the set delivered