


Register your product and get support at  
[www.philips.com/welcome](http://www.philips.com/welcome)



**PHILIPS**



[www.philips.com](http://www.philips.com)

 100% recycled paper  
4222.003.4214.1

## Introduction

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at [www.philips.com/welcome](http://www.philips.com/welcome).

## Important

Read this important information carefully before you use the appliance and save it for future reference.

### Danger

- Never vacuum up water or any other liquid, flammable substances or hot ashes.

### Warning

- Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.
- Do not use the appliance if the plug, the mains cord or the appliance itself is damaged.
- If the mains cord is damaged, you must have it replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- The plug must be removed from the socket-outlet before cleaning or maintaining the appliance.
- Do not point the hose, the tube or any other accessory at the eyes or ears nor put it in your mouth.

### Caution

- Never use the appliance without any of the filters. This could damage the motor and shorten the life of the appliance.
- Always clean all parts as shown in the user manual. Do not clean any parts with water and/or cleaning agents if this is not particularly shown in the user manual.
- If you clean a washable filter with water, make sure it is completely dry before you put it back into the appliance. Do not dry the filter in direct sunlight, on the radiator or in the tumble dryer. Replace a washable filter if it can no longer be cleaned properly or if it is damaged.
- To guarantee optimal dust retention and performance of the vacuum cleaner, always replace the filters with original Philips filters of the correct type (see chapter 'Ordering accessories').
- Always replace the batteries of the remote control with batteries of the correct type.
- Remove the batteries of the remote control if you are not going to use the appliance for one month or more.
- Maximum noise level:  $L_c = 84 \text{ dB(A)}$

## Electromagnetic fields (EMF)

This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

## Ordering accessories

To buy accessories or spare parts (such as filters and additional nozzles), visit [www.shop.philips.com/service](http://www.shop.philips.com/service) or go to your Philips dealer. You can also contact the Philips Consumer Care Centre in your country (see the worldwide guarantee leaflet for contact details).

## Recycling

- This symbol means that this product shall not be disposed of with normal household waste (2012/19/EU) (Fig. 1).
- This symbol means that this product contains batteries which shall not be disposed of with normal household waste (2006/66/EC) (Fig. 2).
- Follow your country's rules for the separate collection of electrical and electronic products and batteries. Correct disposal helps prevent negative consequences for the environment and human health.
- To remove disposable batteries, see the instructions for placing and/or removing batteries in the user manual.

## Guarantee and support

If you need information or support, please visit [www.philips.com/support](http://www.philips.com/support) or read the separate worldwide guarantee leaflet.

## Troubleshooting

This chapter summarises the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, visit [www.philips.com/support](http://www.philips.com/support) for a list of frequently asked questions or contact the Consumer Care Centre in your country.

Problem	Possible cause	Solution
The suction power is insufficient.	The dust container is full.	Empty the dust container.
	The filters are dirty.	Clean or replace the filters.
	The suction power is set to a low setting.	Increase the suction power with the regulator on the appliance or on the handgrip.
When I use my vacuum cleaner I sometimes feel electric shocks.	The nozzle, tube or hose is blocked up.	To remove the obstruction, disconnect the blocked-up item and connect it (as far as possible) the other way around. Switch on the vacuum cleaner to force the air through the blocked-up item in opposite direction.
	Your vacuum cleaner builds up static electricity. The lower the air humidity, the more static electricity the appliance builds up.	Discharge the appliance by frequently holding the tube against other metal objects in the room (for example the legs of a table or chair, a radiator etc.). You can also raise the air humidity level in the room.
The infrared remote control does not function.	The batteries do not make full contact or have not been inserted properly.	Remove the lid of the battery compartment and insert the batteries correctly. Make sure the - and + poles point in the right direction.
	The batteries are empty.	Replace the batteries. You can continue to vacuum but you cannot use the remote control to increase or decrease the suction power or to switch off the appliance. To switch off the appliance, press the on/off button on the appliance.

**Giriş**

Ürünümüzü satın aldığınız için teşekkür ederiz. Philips'e hoş geldiniz! Philips'in sunduğu destekten faydalanabilmek için lütfen ürününüzü şu adresten kaydedin: [www.philips.com/welcome](http://www.philips.com/welcome).

**Önemli**

Cihazı kullanmadan önce bu önemli bilgileri dikkatlice okuyun ve gelecekte başvurmak üzere saklayın.

**Tehlike**

- Hiçbir zaman su veya başka bir sıvıyı, yanıcı maddeleri veya sıcak külleri süpürmeyin.

**Uyarı**

- Cihazı prize takmadan önce, üstünde yazılı olan gerilimin, evinizdeki şebeke gerilimiyle aynı olup olmadığını kontrol edin.
- Cihazın fişi, kordonu veya kendisi hasarlıysa kesinlikle kullanmayın.
- Cihazın elektrik kablosu hasarlıysa, bir tehlike oluşturmasını önlemek için mutlaka Philips'in yetki verdiği bir servis merkezi veya benzer şekilde yetkilendirilmiş kişiler tarafından değiştirilmesini sağlayın.
- Bu cihazın 8 yaşın üzerindeki çocuklar ve fiziksel, motor ya da zihinsel becerileri gelişmemiş veya bilgi ve tecrübe açısından eksik kişiler tarafından kullanımı sadece bu kişilerin nezaretinden sorumlu kişilerin bulunması veya cihazın güvenli kullanım talimatlarının bu kişilere sağlanması ve olası tehlikelerin anlatılması durumunda mümkündür. Çocuklar cihazla oynamamalıdır. Temizlik ve kullanıcı bakımı herhangi bir gözetim olmadan çocuklar tarafından yapılmamalıdır.
- Cihazı temizlemeden veya cihazın bakımını yapmadan önce fişi prizden çekilmelidir.
- Hortumu, boruyu veya diğer herhangi bir aksesuarı gözlerinize veya kulaklarınıza tutmayın ya da ağzınıza sokmayın.

**Dikkat**

- Cihazı kesinlikle filtrelerden herhangi biri olmadan kullanmayın. Bu, motorun zarar görmesine ve cihazın kullanım ömrünün azalmasına neden olabilir.
- Tüm parçaları her zaman kullanım kılavuzunda gösterildiği şekilde temizleyin. Kullanım kılavuzunda özellikle gösterilmediği takdirde herhangi bir parçayı su ve/veya temizlik maddeleri ile temizlemeyin.
- Yıkanebilir bir filtreyi su ile temizliyorsanız, cihaza geri yerleştirmeden önce tamamen kuru olduğundan emin olun. Filtreyi doğrudan güneş ışığı altında, radyatör üzerinde veya çamaşır kurutma makinesinde kurutmayın. Yıkanebilir filtreyi temizlenemeyecek durumdaysa veya hasarlıysa değiştirin.
- Elektrikli süpürge için optimum toz tutma ve performans sağlama için, filtreleri her zaman doğru tipteki orijinal Philips filtreleri ile değiştirin (bkz. 'Aksesuar siparişi' bölümü).
- Uzaktan kumandanın pillerini mutlaka uygun tip pillerle değiştirin.
- Cihazı bir ay veya daha uzun bir süre kullanmayacaksanız uzaktan kumandanın pillerini çıkarın.
- Maksimum gürültü düzeyi: Lc = 84 dB(A)

**Elektromanyetik alanlar (EMF)**

Bu Philips cihazı, elektromanyetik alanlara maruz kalmaya ilişkin geçerli tüm standartlara ve düzenlemelere uygundur.

**Aksesuarların siparişi edilmesi**

Aksesuar veya yedek parça (filtreler ve ek başlıklar gibi) satın almak için [www.shop.philips.com/service](http://www.shop.philips.com/service) adresini ziyaret edin ya da Philips bayinize gidin. Aynı zamanda ülkenizdeki Philips Müşteri Hizmet Merkezi ile iletişime geçebilirsiniz (iletişim bilgileri için dünya çapında garanti kitapçığına başvurun).

**Geri dönüşüm**

- Bu simge, ürünün normal evsel atıklarla birlikte atılmaması gerektiği anlamına gelir (2012/19/EU) (Şek. 1).
- Bu simge, ürünün normal evsel atıklarla birlikte atılmaması gereken piller içerdiği anlamına gelir (2006/66/EC) (Şek. 2).
- Elektrikli ve elektronik ürünlerin ve pillerin ayrı olarak toplanmasına ilişkin ülkenizde geçerli olan kurallara uyun. Bu işlemin doğru şekilde yapılması çevreyi ve insan sağlığını olumsuz etkileyecek sonuçların önlenmesine yardımcı olur.
- Tek kullanımlık pilleri çıkarmak için kullanım kılavuzunda bulunan, pillerin yerleştirilmesi ve/veya çıkarılmasına ilişkin talimatlara bakın.

**Garanti ve destek**

Bilgi veya desteğe ihtiyaç duyarsanız lütfen [www.philips.com/support](http://www.philips.com/support) adresini ziyaret edin veya dünya çapında garanti kitapçığına okuyun.

**Sorun giderme**

Bu bölüm, cihazda en sık karşılaşılabileceğiniz sorunları özetlemektedir. Sorunu aşağıdaki bilgilerle çözemezseniz sık sorulan sorular listesi için [www.philips.com/support](http://www.philips.com/support) adresini ziyaret edin veya ülkenizdeki Müşteri Destek Merkezi ile iletişime kurun.

Sorun	Nedeni	Çözüm
Emiş gücü yetersiz.	Toz haznesi dolu olabilir.	Toz haznesini boşaltın.
	Filtreler kirli olabilir.	Filtreleri temizleyin ya da değiştirin.
	Emiş gücü düşük ayarlanabilir.	Emme gücünü cihazdaki veya saptaki regülatörle artırın.
	Başlık, boru veya hortum tıkanmış olabilir.	Herhangi bir tıkanma söz konusu olduğunda, tıkanan aparatı çıkartarak ters taraftan (mümkün olduğunca uzak) takın. Elektrikli süpürgeyi açarak tıkanmış parçaya ters yönden hava gönderin.
Elektrikli süpürgeyi kullanırken bazen elektrik çarpmış gibi hissediyorum.	Elektrikli süpürgeinizde statik elektrik birikmiştir. Havadaki nem ne kadar düşük olursa, cihazlarda biriken statik elektrik o kadar yüksek olur.	Boruyu sık sık odadaki diğer metal nesnelere değdirerek cihaz yükünü boşaltın (örneğin, masanın veya sandalyenin ayakları, radyatör vb.). Odadaki havanın nem seviyesini de artırabilirsiniz.
Kızılötesi uzaktan kumanda çalışmıyor.	Piller tam olarak temas etmiyor veya düzgün şekilde takılmamış.	Pil yuvasının kapağını kaldırın ve pilleri düzgün şekilde takın. - ve + kutupların doğru yönde yerleştirilmiş olduğundan emin olun.
	Piller bitmiştir.	Pilleri değiştirin. Elektrikli süpürgeyi kullanmaya devam edebilirsiniz, ancak emiş gücünü artırmak veya azaltmak için ya da cihazı kapatmak için uzaktan kumandayı kullanamazsınız. Cihazı kapatmak için cihaz üzerindeki açma/kapatma düğmesine basın.