



Introduction

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome. The SalonDry Compact from Philips has been specially designed to offer you comfortable and reliable drying. It has a compact and lightweight design, making it easy to use. The strong airflow dries your hair quickly, giving it the shine, body and richness you love. You can visit our website at www.philips.com for more information about this product or other Philips products.

Important

Read this user manual carefully before you use the appliance and save it for future reference.

Danger

- Keep the appliance away from water. Do not use it near or over water contained in baths, washbasins, sinks etc. When you use the appliance in a bathroom, unplug it after use. The proximity of water presents a risk, even when the appliance is switched off (Fig. 1).

Warning

- Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.
- Check the condition of the mains cord regularly. Do not use the appliance if the plug, the mains cord or the appliance itself is damaged.
- If the mains cord is damaged, you must have it replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

Caution

- For additional protection, we advise you to install a residual current device (RCD) in the electrical circuit that supplies the bathroom. This RCD must have a rated residual operating current not higher than 30mA. Ask your installer for advice.
- Never block the air grilles.
- This appliance is equipped with an overheat protection device. If the appliance overheats, it switches off automatically. Unplug the appliance and let it cool down for a few minutes. Before you switch on the appliance again, check the grilles to make sure they are not blocked by fluff, hair, etc.
- Always switch off the appliance before you put it down, even if it is only for a moment.
- Always unplug the appliance after use.
- Do not wind the mains cord round the appliance.
- Never use any accessories or parts from other manufacturers or that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.
- Do not insert metal objects into the air grilles to avoid electric shock.
- Keep the hairdryer clean and free of dust, dirt and styling products such as mousse, spray and gel.
- Do not use the appliance on artificial hair.
- Do not use the appliance for any other purpose than described in this manual.

Electromagnetic fields (EMF)

This Philips appliance complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user manual, the appliance is safe to use based on scientific evidence available today.

General description (Fig. 2)

- A** Concentrator
- B** Air outlet grille
- C** Air inlet grille
- D** Rocker switch with 2 heat/speed settings and off position
- E** Cool shot button (HP4962 only)
- F** Volume diffuser (HP4963 only)

Using the appliance**Drying**

- 1 Put the plug in the wall socket.
- 2 Select the desired setting to switch on the appliance (Fig. 3).
 - II: Strong airflow for fast drying
 - I: Gentle airflow especially intended for styling
 - O: Off
- 3 To dry your hair, make brushing movements with the hairdryer at a small distance from the hair (Fig. 4).
- 4 HP4962 only: When you have finished drying, press the cool shot button for a cool airflow. This closes the cuticles and adds shine to the hair (Fig. 5).

Concentrator

The concentrator enables you to direct the airflow straight at the brush or comb with which you are styling your hair.

- 1 Snap the concentrator onto the appliance (Fig. 6).
 - To disconnect the concentrator, pull it off the appliance.

Volume diffuser (HP4963 only)

The volume diffuser has been specially developed to gently dry both straight and curly or wavy hair.

- 1 To connect the volume diffuser, snap it onto the appliance. (Fig. 7)
To disconnect the volume diffuser, pull it off the appliance.
- 2 To add volume at the roots, insert the pins into your hair in such a way that they touch your scalp (Fig. 8).
- 3 Make rotating movements with the appliance to distribute the warm air evenly through your hair (Fig. 9).

Cleaning

Always unplug the appliance before you clean it.

Do not immerse the appliance in water nor rinse it under the tap.

- 1 Make sure the appliance is switched off and unplugged.
- 2 Remove the attachment from the appliance before you clean it.
- 3 Clean the appliance with a dry cloth.
- 4 Clean the attachment with a moist cloth or rinse it under the tap.

Note: Make sure the attachment is dry before you use or store it.

Storage

Never wind the mains cord round the appliance.

- 1 Make sure the appliance is switched off and unplugged.
- 2 Put the appliance in a safe place and let it cool down before you store it.

Environment

- Do not throw away the appliance with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment (Fig. 10).

Guarantee & service

If you need service or information or if you have a problem, please visit the Philips website at www.philips.com or contact the Philips Consumer Care Centre in your country (you find its phone number in the worldwide guarantee leaflet). If there is no Consumer

Care Centre in your country, go to your local Philips dealer.

Troubleshooting

If problems arise with your hairdryer and you cannot solve them with the information below, please contact the nearest Philips service centre or the Philips Consumer Care Centre in your country.

Problem	Solution
The appliance does not work at all.	Perhaps the socket to which the appliance has been connected is not live. Make sure the socket is live.

The appliance may have overheated and switched itself off. Unplug the appliance and let it cool down for a few minutes. Before you switch on the appliance again, check the grilles to make sure they are not blocked by fluff, hair, etc.

The appliance may not be suitable for the voltage to which it has been connected. Make sure that the voltage indicated on the type plate of the appliance corresponds to the local mains voltage.

The mains cord may be damaged. If the mains cord is damaged, you must have it replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.

제품 소개

필립스 제품을 구입해 주셔서 감사합니다! 필립스가 드리는 지원 혜택을 받으실 수 있도록 www.philips.com/welcome에서 제품을 등록하십시오. 필립스의 살롱드라이 컴팩트는 편안하고 안정적인 헤어 드라이어를 위해 디자인되었습니다. 컴팩트하고 가벼운 디자인으로 사용이 편리합니다. 강력한 바람으로 빠른 드라이어가 가능하며, 광택있고 건강하며 풍성한 머릿결로 가꾸어 줍니다. 본 제품에 대한 보다 자세한 정보가 필요할 경우에는 필립스 전자 홈페이지(www.philips.co.kr)를 방문하십시오.

중요사항

본 제품을 사용하기 전에 이 사용 설명서를 주의 깊게 읽고 나중에 참조할 수 있도록 잘 보관하십시오.

위험

본 제품은 물이 닿지 않는 곳에 보관하십시오. 본 제품을 욕조, 세면대 또는 싱크대와 같이 물 가까이에서 사용하지 마십시오. 욕실에서 사용할 경우 사용 후에는 반드시 전원 플러그를 뽑으십시오. 전원이 꺼져 있더라도 물에 닿으면 위험할 수 있습니다 (그림 1).

경고

제품에 전원을 연결하기 전에, 제품에 표시된 전압과 사용 지역의 전압이 일치하는지 확인하십시오. 전원 코드를 정기적으로 점검하여 플러그나 전원 코드 또는 제품 자체에 손상이 있으면 제품을 사용하지 마십시오. 전원 코드가 손상된 경우, 안전을 위해 필립스 서비스 센터 또는 필립스 서비스 지정점에 의뢰하여 교체하십시오. 신체적인 감각 및 정신적인 능력이 떨어지거나 경험과 지식이 풍부하지 않은 사용자(어린이 포함)는 혼자 제품을 사용하지 말고 제품 사용과 관련하여 안전에 책임 질 수 있도록 지시사항을 충분히 숙지한 사람의 도움을 받으십시오. 어린이가 제품을 가지고 놀지 못하도록 지도해 주십시오.

주의

추가 안전을 위하여 잔여 전류 소멸 장치(RCD)를 욕실 전원에 설치할 것을 권장합니다. 이 RCD의 정격 잔여 전류는 30mA 이하여야 합니다. 자세한 설치 방법은 전기 설비업체에 문의하십시오. 절대로 공기 흡입망을 막지 마십시오. 이 제품에는 과열 방지 기능이 내장되어 있어 제품이 과열되면 자동으로 전원이 꺼집니다. 제품의 전원을 뽑은 후 몇 분 동안 열기가 식도록 두십시오. 제품의 전원을 다시 켜기 전에, 보풀이나 머리카락 등에 의해 공기 흡입구가 막혀 있는지 반드시 확인하십시오. 잠시라도 제품을 내려놓을 경우에는 반드시 전원을 끄십시오. 사용 후 반드시 전원 코드를 뽑으십시오. 전원 코드를 제품에 감지 마십시오. 다른 제조업체에서 만들었거나 필립스에서 권장하지 않은 제품 액세서리 또는 부품은 절대 사용하지 마십시오. 이러한 액세서리나 부품을 사용했을 경우에는 품질 보증이 무효화됩니다. 감전 사고를 막으려면 공기 흡입망에 금속 물질을 삽입하지 마십시오. 헤어 드라이어에 먼지, 이물질 및 무스, 스프레이, 젤 등의 스타일링 제품이 묻지 않은 깨끗한 상태로 유지하십시오. 제품을 인조 모발에 사용하지 마십시오. 이 설명서에 나와있는 이외의 용도로 제품을 사용하지 마십시오.

EMF(전자기장)

이 필립스 제품은 EMF(전자기장)와 관련된 모든 기준을 준수합니다. 이 사용 설명서의 지침에 따라 적절하게 취급할 경우 이 제품은 안전하게 사용할 수 있으며 이는 현재까지의 과학적 증거에 근거하고 있습니다.

각 부의 명칭 (그림 2)

- A 집중 노즐
B 공기 배출구
C 공기 흡입구
D 2단계 열량과 풍량 조절 및 꺼짐 스위치
E 쿨샷 버튼(HP4962 모델만 해당)
F 볼륨 디퓨저(HP4963 모델만 해당)

제품 사용

드라이

- 1 플러그를 벽면 콘센트에 꽂으십시오.
2 원하는 설정을 선택하고 전원을 켜십시오 (그림 3).
- II: 빠른 드라이를 위한 강한 바람
- I: 스타일링을 위한 부드러운 바람
- O: 꺼짐
3 헤어드라이어를 모발에서 약간 거리를 두고 빗질하듯이 움직여서 드라이하십시오 (그림 4).
4 HP4962 모델만 해당: 모발을 말린 후 쿨샷 버튼을 눌러 시원한 바람으로 마무리하시면 모발 손상을 방지하여 윤기를 더해 줍니다 (그림 5).

집중 노즐

집중 노즐은 브러시나 빗을 사용하여 스타일링을 원하는 부위를 향하도록 할 수 있습니다.

- 1 제품에 집중노즐을 끼우십시오 (그림 6).
- 집중 노즐을 분리하려면 제품에서 집중 노즐을 당겨 빼내십시오.

볼륨 디퓨저(HP4963 모델만 해당)

볼륨 디퓨저는 스트레이트 및 컬 또는 웨이브 모발을 부드럽게 드라이 할 수 있도록 특별히 고안되었습니다.

- 1 볼륨 디퓨저는 제품에 끼워 연결하십시오. (그림 7)
볼륨 디퓨저를 분리하려면 제품에서 볼륨 디퓨저를 당겨 빼내십시오.
2 모근 부분에 볼륨감을 더하려면, 두피에 닿을 때까지 모발사이로 핀을 집어넣으십시오 (그림 8).
3 따뜻한 바람이 모발에 골고루 퍼지도록 헤어드라이어를 회전하면서 움직이십시오 (그림 9).

청소

제품을 청소하기 전에는 항상 제품의 전원 코드를 뽑으십시오.

제품을 물에 담그거나 헹구지 마십시오.

- 1 전원이 꺼져 있고 플러그가 뽑혀 있는지 확인하십시오.
2 액세서리를 청소하기 전에 제품에서 분리하십시오.
3 제품은 마른 천을 사용하여 닦으십시오.
4 액세서리는 젖은 천으로 닦거나 흐르는 수돗물로 헹구십시오.

참고: 액세서리를 사용하거나 보관하기 전에 마른 상태인지 확인하십시오.

보관

전원코드를 제품에 감지 마십시오.

- 1 전원이 꺼져 있고 플러그가 뽑혀 있는지 확인하십시오.
2 제품을 보관하기 전에 안전한 장소에 놓고 식히십시오.

환경

수명이 다 된 제품은 일반 가정용 쓰레기와 함께 버리지 마시고 지정된 재활용 수거 장소에 버리십시오. 이런 방법으로 환경 보호에 동참하실 수 있습니다 (그림 10).

품질 보증 및 서비스

보다 자세한 정보가 필요하시거나, 사용상의 문제가 있을 경우에는 필립스전자 홈페이지(www.philips.co.kr)를 방문하시거나 필립스 고객 상담실로 문의하십시오. 전국 서비스센터 안내는 제품 보증서를 참조하십시오. *(주)필립스전자: (02)709-1200 *고객 상담실: (080)600-6600(수신자부담)

문제 해결

헤어 드라이어에 문제가 있을 경우에는 아래 정보를 참조하시고, 더 많은 정보를 원하실 경우 가까운 필립스 서비스 센터나 필립스 고객 상담실로 문의하십시오.

문제점 해결책

제품이 전혀 작동하지 않습니다. 제품을 연결한 콘센트가 유효하지 않습니다. 콘센트가 작동하는지 확인하십시오.

제품이 과열되어 자동으로 전원이 꺼진 상태일 수 있습니다. 제품의 전원을 뽑은 후 몇 분 동안 식히십시오. 제품의 전원을 다시 켜기 전에 그림이 잔털, 머리카락 등으로 막혀 있지 않은지 확인하십시오.

연결된 전압이 제품에 적합하지 않을 수 있습니다. 제품에 표시된 전압과 사용 지역의 전압이 일치하는지 확인하십시오.

제품의 전원 코드가 손상되었을 수 있습니다. 전원 코드가 손상된 경우, 안전을 위해 필립스 서비스 센터 또는 서비스 지정점에 의뢰하여 교체하십시오.

제조번호 부여기준: 필립스 전자 제품의 제조번호는 모두 4자리로 되어 있습니다. 앞의 두 자리는 연도를 의미합니다. 나머지 뒤의 두 자리는 생산된 주를 의미합니다. 주는 1년을 52주로 나누어 순차적으로 구분합니다. (예: 0512 → 2005년 12번째 주에 생산 0504 → 2005년 4번째 주에 생산)