

General Description

- A** 2D Contour Tracking Comb
- B** 3-Dimensional Rounded Chromium Steel Blades
- C** Hair Length Selector
- D** On/Off Switch
- E** Socket for Appliance Plug
- F** Cleaning Brush
- G** Barber's Comb
- H** Charge Indication Light
- I** Mains plug with Transformer
- J** Appliance Plug
- K** Nose/ear/eyebrow Grooming Attachment
- L** Storage Stand
- M** Trimming Attachment

Important

- ▶ Check if the voltage indicated on the appliance corresponds to the mains voltage in your home before you connect the appliance.
- ▶ Make sure that the appliance does not get wet.
- ▶ This appliance is only designed for trimming the human beard and grooming nose hair, ear hair, eyebrows, moustache and sideburns.
- ▶ Keep the appliance out of the reach of children.

Charging

Charge the appliance fully before you start using it for the first time.

- 1** Make sure the appliance is switched off.

- 2** Insert the appliance plug into the appliance (Fig. 2).

- 3** Put the mains plug into the wall socket.

- ▶ After a few moments the green pilot light will go on to indicate that the appliance is charging (fig. 3).

It will take approx. 10 hours to fully charge the battery.

To optimise the lifetime of the appliance, do not charge it for more than 24 hours.

A fully charged appliance has a cordless trimming time of up to 40 minutes.

▫ *To optimise the lifetime of the rechargeable battery, we advise you to use the appliance until the battery is completely empty when the appliance has been charged for the first time. Do not recharge the appliance in between trimming sessions. Continue using the appliance until the motor almost stops running during a session. Then recharge the battery. Follow this procedure at least twice a year.*

- 4** If the battery is empty and you want to trim your beard, charge the appliance for at least 1.5 hours and you will have enough power for one trimming session.

Trimming

Always comb the beard, moustache and/or sideburns with the attached Barber's Comb before you start trimming.

Do not move the appliance too fast. Make smooth and gentle movements.

- ▶ To trim with the appliance disconnected from the mains:

- 1** Unplug trimmer from the outlet.

Trimming with comb attachment

The flexible combs (2D-Contour Tracking System) adjust to the contours of the face, the trimmer is easy to manoeuvre. Demanding areas, such as the chin- and throat area, are treated easily and an even cut is obtained.

Put on one of the exchangeable combs. To assemble the comb, insert the hook of the comb into the appliance and push it down until you hear a click.

- 1** Slide the adjustment comb to the desired trimming length setting (fig. 4). The chosen setting is indicated by the arrow.

Length setting table

The trimmer has 2 exchangeable comb attachments with 5 settings each, resulting in 10 different hairlengths that can be cut:

- ▶ Small comb (setting 1-5): resulting in a hairlength of 1.5 - 9 mm .
- ▶ Big comb (setting 1-5): resulting in a hairlength of 10 - 17 mm.
- ▶ The resulting hairlength corresponds with the smallest distance between the cutting blade

and the spot where the comb is in contact with the skin (fig. 5).

▫ *If you are using the trimmer for the first time, start at the maximum trimming length setting; setting 5 with big comb.*

- 2** Switch the appliance on.

- 3** To trim in the most effective way, move the trimmer against the direction of hair growth. Make sure the surface of the comb always stays in contact with the skin (fig. 6).

- 4** If a lot of hair has accumulated in the comb, remove the comb attachment and blow and/or shake the hair out of the comb. The selected trimming length setting will not change when you do this (fig. 7).

Trimming without comb attachment

- 1** Remove the comb attachment by pulling it off the appliance (fig. 8).

Never pull at the flexible top of the comb attachment. Always pull at the bottom part.

Cutting without comb attachment (or with position '0') will result in a very short stubble beard.

- 2** Switch the appliance on.

- 3** Make well-controlled movements. Touch the hair lightly with the trimmer (fig. 9).

Grooming

Do not use the attachment with a damaged or broken cutting or grooming attachment as injury may occur.

Use the grooming attachment

- ▶ For trimming nose hair, ear hair and eyebrows:

- 1** Move the comb into position '0' and remove the trimming attachment (fig. 10).

- 2** Assemble the grooming attachment by inserting it's hook into the housing and push it back until you hear a click (fig. 11).

Cutting nose hair

Make sure nasal passages are clean

- 1** Switch the groomer on.

- 2** Insert the groomer in one nostril and slowly move it in and out. Turning it around the same time to remove unwanted hair (fig. 12).

For best results, make sure the side of the tip is firm against skin. This will reduce the tickling effect than can occur during trimming nose hair.

Do not insert the tip more than 0.5 centimetres into your nostril.

Cutting ear hair

Clean outer area of ear and make sure it is free of wax.

- 1** Switch the groomer on.

- 2** Move the tip softly around the edge of ear to remove hairs extending beyond the outer ear. Then carefully insert the tip into outer ear (fig. 13)

Do not insert the tip more than 0.5 centimetres into your ear as this could damage the eardrum.

Cutting eyebrows

It is not recommended that you use the groomer to define or trim the entire eyebrow.

- 1** Switch the groomer on.

- 2** Use the tip to cut individual eyebrow hairs (fig. 14).

- 3** Put on the groomer at the root of the nose and move it along the eyebrow into the direction of hairgrowth (fig. 15).

Do not trim your eyelash, be careful not to get too close to your eyelashes and eyes.

Cleaning

Do not use abrasives, scourers or liquids such as alcohol, petrol or acetone to clean the appliance.

Do not immerse the appliance into water.

- 1** Make sure the appliance is switched off and disconnected from the mains before you start cleaning it.

- 2** Remove the comb attachment.

- 3** Open the cutting unit by pushing it backwards (fig. 16).

Be careful that the cutting element does not drop down.

- 4** Clean the cutting unit and the inside of the appliance with the brush supplied (2)

- 5** Reassemble the cutting unit by inserting the hook onto the appliance and pushing it back onto the appliance until you hear a click (fig. 17).

Cleaning grooming attachment

- 1** Remove the grooming attachment by pushing it backwards (fig. 18).

- 2** Blow and/or shake hairs out of the grooming attachment.

- 3** Reassemble one of the two attachments on the appliance (fig. 19).

Replacing the cutting unit

A worn or damaged cutting unit should only be replaced with an original Philishave cutting unit, available from authorised Philips service centres.

- 1** Remove the old cutting unit.

- 2** Put the new cutting unit back onto the appliance until you hear a click.

Storage

- 1** Store the appliance and attachments in the stand to prevent damaging (fig. 20).

Environment

The built-in rechargeable battery contains substances that may harm the environment.

Remove the rechargeable battery when you discard the appliance.

Do not throw the battery away with the normal household waste but hand it in at an official collection point.

You can also take the appliance to a Philips service centre, where the staff will be happy to help you remove the battery and dispose of it in an environmentally safe way.

- 1** Disconnect the appliance from the mains and let the appliance run until the motor stops.

- 2** Slide in the Guide Comb Attachment. Pull cutting unit back to remove it (fig. 21).

- 3** Put a screw driver between the housing part and the metal eccentric part and push it down until the housing part will be opened (fig. 22).

- 4** Pull the rechargeable battery (1) and the on/off circuit board (2) out of the housing (fig. 23).

- 5** Insert the screwdriver into the small slot in the printed circuit board marked with an arrow. Push the screwdriver down until part of the printed circuit board breaks off (fig. 24).

- 6** Remove the battery form the plastic part using a screwdriver.

Do not attempt to replace battery.

- 7** Discard the appliance.

Do not connect the appliance to the mains again after the battery has been removed.

Service und Information

If you need information or if you have a problem, please visit the Philips Web site at www.philips.com or contact the Philips Customer Care Centre in your country (you will find its phone number in the worldwide guarantee leaflet). If there is no Customer Care Centre in your country, turn to your local Philips dealer or contact the Service Department of Philips Domestic Appliances and Personal Care BV.

DEUTSCH

Allgemeine Beschreibung

- A** 2D Konturen-Kamm
- B** 3-dimensionale abgerundete Schneiden aus Chrom-Stahl
- C** Schnittlängenregler
- D** Ein-/Ausschalter
- E** Buchse für das Gerätekabel
- F** Reinigungsbürste
- G** Frisierkamm
- H** Ladekontroll-Lampe
- I** Steckernetzgerät
- J** Gerätestecker
- K** Aufsatz zum Trimmen von Haaren an Nase, Ohren, Augenbrauen
- L** Gerätereständer
- M** Schneideaufsatz

Wichtig

- ▶ Prüfen Sie, bevor Sie das Gerät in Betrieb nehmen, ob die Spannungsangabe auf dem Gerät mit der örtlichen Netzspannung übereinstimmt.
- ▶ Achten Sie darauf, daß das Gerät nicht naß wird.
- ▶ Dieses Gerät ist ausschließlich zum Schneiden menschlicher Bärte und zum Trimmen von Haaren an Nase, Ohren, Augenbrauen, Schnurrbärten und Koteletten bestimmt.
- ▶ Bewahren Sie das Gerät außer Reichweite von Kindern auf.

Den Akku aufladen

Laden Sie den Akku voll auf, bevor Sie das Gerät zum ersten Mal benutzen.

- 1** Achten Sie darauf, dass das Gerät ausgeschaltet ist.

- 2** Stecken Sie das Steckernetzgerät in das Gerät (Abb. 2).

- 3** Stecken Sie den Netzstecker in die Steckdose.

- ▶ Nach kurzer Zeit beginnt die grüne Kontroll-Lampe zu leuchten und zeigt an, dass der Akku geladen wird (Abb. 3).
- Nach ca. 10 Stunden ist der Akku voll aufgeladen.

Halten Sie das Gerät zum Aufladen nicht länger als 24 Stunden am Netz, das erhöht die Nutzungsdauer des Akkus.

Mit dem voll aufgeladenen Akku können Sie das Gerät bis zu 40 Minuten kabelfrei benutzen.

▫ *Sie erhöhen die Nutzungsdauer des Akkus, wenn Sie den Akku nach dem ersten Aufladen erst dann wieder laden, wenn er völlig entleert ist. Laden Sie ihn auch nicht zwischen zwei Anwendungen nach, sondern verwenden Sie das Gerät, bis der Motor stillsteht. Laden Sie dann den Akku wieder auf. - Gehen Sie zweimal im Jahr auf die gleiche Weise vor.*

- 4** Wollen Sie das Gerät verwenden, doch der Akku ist leer, so laden Sie ihn mindestens 1 1/2 Stunden; danach enthält er genügend Energie für eine Anwendung.

Den Bart schneiden

Kämmen Sie Bart, Schnurrbart und Koteletten vor dem Gebrauch des Geräts stets mit einem feinen Kamm aus.

Gehen Sie langsam mit ruhigen und kontrollierten Bewegungen vor.

- ▶ Zum Gebrauch des Geräts mit Akkubetrieb:

- 1** Ziehen Sie den Stecker aus der Steckdose.

Bartschneiden mit dem Schneideaufsatz

Die flexiblen Kämme des 2D-Contour-Systems passen sich den Konturen Ihres Gesichtes an. Das Gerät ist einfach zu handhaben. Empfindliche Partien wie Kinn- und Kehlkopf-Bereich sind leicht zu behandeln, und es wird ein gleichmäßiger Schnitt erzielt.

Nehmen Sie einen der auswechselbaren Schneideaufsätze, und führen Sie den Haken an dem Aufsatz in das Gerät ein. Drücken Sie den Aufsatz hinein, bis Sie hören, dass er einrastet ("Klick").

- 1** Schieben Sie den Schnittlängenregler auf die gewünschte Position (Abb. 4).

Die gewählte Einstellung ist an dem Pfeil sichtbar.

Tabelle der Schnittlängen

Das Gerät ist mit zwei auswechselbaren Schneideaufsätzen ausgestattet. Beide verfügen über jeweils 5 Einstellungen, so dass Sie zwischen 10 Schnittlängen wählen können:

- ▶ Kleiner Schneideaufsatz: Position 1 bis 5 = 1,5 bis 9 mm Schnittlänge.
- ▶ Großer Schneideaufsatz: Position 1 bis 5 = 10 bis 17 mm Schnittlänge.
- ▶ Die Schnittlänge entspricht dem kleinsten Abstand zwischen der Schneide und dem Punkt, an dem der Schneideaufsatz die Haut berührt (Abb. 5).

▫ *Wählen Sie beim ersten Gebrauch des Geräts den großen Schneideaufsatz und die maximale Schnittlänge von 5 mm.*

- 2** Schalten Sie das Gerät ein.

- 3** Den besten Erfolg erzielen Sie, wenn Sie das Gerät gegen die natürliche Bartwuchsrichtung führen. Achten Sie darauf, dass der Kamm stets Kontakt zur Haut behält (Abb. 6).

- 4** Hat sich viel Barthaar im Kamm angesammelt, so ziehen Sie den Schneideaufsatz vom Gerät, und blasen oder schütteln Sie das Haar aus dem Aufsatz. Die eingestellte Schnittlänge wird dabei nicht verändert (Abb. 7).

Verwendung ohne den Schneideaufsatz

- 1** Ziehen Sie den Schneideaufsatz vom Gerät (Abb. 8).

Ziehen Sie niemals an dem beweglichen Ober teil des Schneideaufsatzes, sondern stets an dem unteren Teil.

Die Benutzung des Geräts ohne einen Schneideaufsatz oder bei Position "0" erhalten Sie einen Drei-Tage-Bart.

- 2** Schalten Sie das Gerät ein.

- 3** Gehen Sie mit ruhigen und kontrollierten Bewegungen vor. Berühren Sie die Barthaare nur leicht mit dem Gerät (Abb. 9).

Trimmen

Verwenden Sie das Gerät nicht, wenn die Scher- oder Trimmeinheit defekt oder beschädigt ist. Sie könnten sich verletzen.

Verwendung des Trimm-Aufsatzes

- ▶ Zum Trimmen der Haare an Nase, Ohren und Augenbrauen:

- 1** Stellen Sie den Scherkamm-Aufsatz auf Position "0" und ziehen Sie ihn vom Gerät ab (Abb. 10).

- 2** Nehmen Sie den Trimm-Aufsatz, und führen Sie den Haken an dem Aufsatz in das Gerät ein. Drücken Sie den Aufsatz hinein, bis Sie hören, dass er einrastet ("Klick") (Abb. 11).

Die Haare an der Nase schneiden

Achten Sie darauf, dass die Nasengänge sauber sind.

- 1** Schalten Sie das Gerät ein.

- 2** Führen Sie den Trimm-Aufsatz in ein Nasenloch ein, und führen Sie ihn langsam hinein und heraus. Drehen Sie ihn gleichzeitig, um die störenden Haare zu entfernen (Abb. 12).

Das beste Ergebnis erhalten Sie, wenn die Seiten der Spitze dicht gegen die Haut gehalten wird. Dadurch wird auch das Kitzeln reduziert, das beim Schneiden der Haare in der Nase auftreten kann.

Führen Sie die Spitze nicht höher als 5 mm in die Nase ein.

Haare am Ohr trimmen

Reinigen Sie das äußere Ohr und achten Sie darauf, dass der Gehörgang frei von Ohrschmalz ist.

- 1** Schalten Sie das Gerät ein.

- 2** Bewegen Sie die Spitze langsam um den Rand der Ohrmuschel herum, damit die Haare getrimmt werden, die über das äußere Ohr heraus ragen. Führen Sie dann die Spitze in den Gehörgang ein (Abb. 13).

Führen Sie die Spitze nicht tiefer als 5 mm in den Gehörgang ein, damit das Trommelfell nicht beschädigt wird.

Augenbrauen trimmen

Wir raten davon ab, den Trimm-Aufsatz zum Konturieren oder Rasieren der Augenbrauen zu verwenden.

- 1** Schalten Sie das Gerät ein.

- 2** Benutzen Sie die Spitze, um einzelne Haare der Augenbrauen zu trimmen (Abb. 14).
- 3** Setzen Sie den Trimm-Aufsatz an der Nasenwurzel an, und bewegen Sie in entlang der Augenbraue in Haarwuchsrichtung (Abb. 15).

Reinigung

Trimmen Sie niemals mit dem Gerät Ihre Augenlider. Kommen Sie mit ihm den Augenlidern und den Augen nicht zu nahe.

Reinigung

Verwenden Sie zum Reinigen keine Scheuermittel oder Lösungsmittel wie Alkohol, Benzin oder Azeton.

Tauchen Sie das Gerät oder die Aufsätze niemals in Wasser.

- 1** Achten Sie, bevor Sie mit der Reinigung beginnen, darauf, daß das Gerät ausgeschaltet und nicht am Netz angeschlossen ist.

- 2** Nehmen Sie den Kamm-Aufsatz vom Gerät.

- 3** (1) Öffnen Sie die Schneideeinheit, indem Sie sie nach hinten klappen (Abb. 16). Achten Sie darauf, dass die Schneideinheit nicht hinunter fällt.

- 4** (2) Reinigen Sie die Schneideeinheit und die Innenwände des Geräts mit der beiliegenden Reinigungsbürste.

- 5** Setzen Sie die Schneideeinheit wieder ein, indem Sie den Haken auf das Gerät setzen und zurückdrücken, bis Sie hören, dass sie einrastet (Abb. 17).

Reinigung der Trimm-Aufsatzes

- 1** Nehmen Sie den Aufsatz von Gerät, indem Sie ihn nach hinten drücken (Abb. 18).

- 2** Blasen und/oder schütteln Sie die Haare aus dem Trimm-Aufsatz.

