Version: Ver1.2

==

Benefits of the Software Update: Improve the CD noise problem.

==

Software Update Procedure:

1. Unzip attached software and copy the unzipped two files into USB storage (make sure no other EXE file in the USB storage)

2. Set the source of main set in USB mode and insert USB storage with software loaded.

3. The set will start reading USB. When hearing Bi Bi sound, take out USB storage.

4. Change the source into disc mode (without disc inserted), and then press **DISPLAY** on the remote control for **4 times**. If you see **Nov 5 08**, it means the software upgrade is successful.

IMPORTANT:

DO NOT disconnect the device from the power supply during the firmware update.

==

Software Update History:

- **Ver1.1** – Improve the CD noise problem.