

Step 1: Ready for Firmware Upgrade

1.1 Prepare a USB sticker (The file system of USB sticker must be FAT16 or FAT 32).

1.2 Copy the upgrade file (upgrade.pkg) to the USB sticker root path.

Step 2: Firmware Upgrade

2.1 Plug the USB sticker into USB port on the side I/O port of TV as figure2.1




Figure 2.1

2.2 AC on (Power plug as Figure 2.2)



figure2.2

2.3. When TV detect the USB sticker will display below Upgrade information.



2.4 TV will upgrade automatically.

Notes: during upgrade process, please don't Power-Off!

2.5 When upgrade Success, remove the USB sticker and AC off.

Step 3: Check the FIRMWARE version and reset to default.

After finish, please press button on remote controller in sequence

"**1 2 3 6 5 4**" you can check the version is **2.11**, then it is right.