

Register your product and get support at

www.philips.com/welcome

DA200



User manual

PHILIPS

Contents

| | | |
|----------|------------------|----------|
| 1 | Important | 2 |
|----------|------------------|----------|

| | | |
|----------|-----------------------------|----------|
| 2 | Your docking speaker | 3 |
| | Introduction | 3 |
| | What's in the box | 3 |
| | Overview of the main unit | 3 |

| | | |
|----------|------------------|----------|
| 3 | Prepare | 4 |
| | Connect power | 4 |
| | Turn the unit on | 4 |

| | | |
|----------|------------------------------|----------|
| 4 | Play | 5 |
| | Listen to the iPod/iPhone | 5 |
| | Adjust sound | 5 |
| | Compatibility | 5 |
| | Charge the iPod/iPhone | 5 |
| | Play from an external device | 5 |

| | | |
|----------|-----------------------|----------|
| 5 | Specifications | 6 |
| | Amplifier | 6 |
| | General information | 6 |

| | | |
|----------|------------------------|----------|
| 6 | Troubleshooting | 7 |
|----------|------------------------|----------|

| | | |
|----------|---------------|----------|
| 7 | Notice | 8 |
| | Recycling | 8 |

1 Important

- Read these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- Apparatus shall not be exposed to dripping or splashing.
- Do not place any sources of danger on the apparatus (e.g. liquid filled objects, lighted candles).
- Where the plug of the Direct Plugin Adapter is used as the disconnect device, the disconnect device shall remain readily operable.



Warning

- Never remove the casing of this apparatus.
- Never lubricate any part of this apparatus.
- Never place this apparatus on other electrical equipment.

2 Your docking speaker

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

If you contact Philips, you will be asked for the model and serial number of this apparatus. The model number and serial number are on the bottom of the apparatus. Write the numbers here:

Model No. _____

Serial No. _____

Introduction

With this docking speaker, you can:


- Enjoy music on your iPod/iPhone;
- Charge your iPod/iPhone;
- Enjoy music on external audio player through MP3 link cable.

What's in the box

Check and identify the contents of your package:

- Main unit
- AC power adaptor
- Quick start guide

Overview of the main unit



- ① +/-
 - Adjust volume.
- ② Power socket
 - Connect the power adaptor.
- ③ Dock for iPod/iPhone
- ④ MP3-LINK
 - Connect an external audio player.
- ⑤ ⏻
 - Turn the unit on/off.


3 Prepare

Always follow the instructions in this chapter in sequence.

Connect power

Caution

- Risk of product damage! Make sure that the power supply voltage matches the voltage printed on the bottom of the unit.
- Risk of electric shock! When you unplug the AC adaptor, always pull the plug from the socket. Never pull the cord.
- Before you connect the AC adaptor, make sure that you have completed all the other connections.



Connect the AC power adaptor; one end to the power socket on the back of the unit, and the other the wall power supply.


Turn the unit on

Press  repeatedly on the top to turn the unit on/off.

4 Play

Listen to the iPod/iPhone


- 1 Load your iPod/iPhone.



- 2 Play your iPod/iPhone.
↳ Your music on the phone comes out through the device.

Adjust sound

To adjust the sound, press the button +/-.



Compatibility

Made for Apple iPod models with 30-pin dock connector as follows:


- iPod touch (4th generation)
- iPod touch (3rd generation)
- iPod touch (2nd generation)
- iPod touch (1st generation)
- iPod nano (6st generation)
- iPod nano (5th generation)
- iPod nano (4th generation)
- iPod nano (3rd generation)
- iPod nano (2nd generation)
- iPod nano (1st generation)
- iPod mini
- iPod classic
- iPod with video
- iPod with color display
- iPhone 4
- iPhone 3GS
- iPhone 3G
- iPhone

Charge the iPod/iPhone

When the system is connected to power, the docked iPod/iPhone begins to charge.

Play from an external device

You can also listen to an external audio player through the device.



Connect the MP3 link cable, one end to the **MP3-LINK** socket at the back, and the other to the headphone socket.

5 Specifications

Amplifier

| | |
|--------------------|-------------|
| Rated Output Power | 2 X 2 W RMS |
|--------------------|-------------|

General information

| | |
|----------|--|
| AC Power | Input: 100-240 V ~, 50/60Hz, 0.3A; Output: DC 5.9V = 1500 mA (Brand name: Philips; Model No.: S009GV0590150) |
|----------|--|

| | |
|-----------------------------|-----|
| Operation Power Consumption | 8 W |
|-----------------------------|-----|

| | |
|---------------------------|------|
| Standby Power Consumption | <1 W |
|---------------------------|------|

| | |
|------------------------------------|---------------------|
| Dimensions - Main Unit (W x H x D) | 18.5 x 63.5 x 82 mm |
|------------------------------------|---------------------|

| | |
|--------------------|---------|
| Weight - Main Unit | 0.68 kg |
|--------------------|---------|

6 Troubleshooting



Warning

- Never remove the casing of this apparatus.

To keep the warranty valid, never try to repair the system yourself.

If you encounter problems when using this apparatus, check the following points before requesting service. If the problem remains unsolved, go to the Philips web site (www.philips.com/welcome). When you contact Philips, ensure that the apparatus is nearby and the model number and serial number are available.

No power

- Make sure that the AC power adaptor of the device is connected properly.
- Make sure that there is power at the AC outlet.

No sound

- Adjust the volume.

Docked iPod/iPhone can't be charged

- Make sure that the device is compatible the iPod/iPhone.
- Make sure that the device is successfully connected to the iPod/iPhone.
- Remove the protective case of your iPod/iPhone.

7 Notice

Any changes or modifications made to this device that are not expressly approved by Philips Consumer Lifestyle may void the user's authority to operate the equipment.



This product complies with the radio interference requirements of the European Community.

Recycling



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

When you see the crossed-out wheel bin symbol attached to a product, it means the product is covered by the European Directive 2002/96/EC:



Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products. The correct disposal of your old product helps prevent potentially negative consequences on the environment and human health. Your product contains batteries covered by the European Directive 2006/66/EC, which cannot be disposed of with normal household waste.



Please inform yourself about the local rules on separate collection of batteries. The correct disposal of batteries helps prevent potentially negative consequences on the environment and human health.

Environmental information

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet.)

Your system consists of materials which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.



"Made for iPod" and "Made for iPhone" mean that an electronic accessory has been designed to connect specifically to iPod or iPhone respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod or iPhone may affect wireless performance. iPod and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries.



Note

- The type plate is located on the bottom of the apparatus.



Specifications are subject to change without notice
© 2011 Koninklijke Philips Electronics N.V.
All rights reserved.

AD200_12_UM_V1.0

