


QUICK START
MISE EN SERVICE RAPIDE
INICIO RÁPIDO



Thanks for buying **Philips AJ100 clock radio**.
Our **Quick Start** guides you through just some of the features on the set.
Please read our instruction booklet to really rise & shine!

PHILIPS



ENGLISH

Quick start as easy as ABC!

Step A

- Connect the supplied mains adapter to the set's 7.5V DC jack and the plug into a wall outlet.

Step B

How to set the Clock & Alarm time

1. Check the radio is switched off.
2. Press and hold **SET TIME/ SET AL** 🎵 / **SET AL** 🕒.
3. Press and hold **HR+/MIN+**.
4. Press **SETTIME/ SET AL** 🎵 / **SET AL** 🕒.

Step C

Selecting the Alarm mode

Press briefly:

- **ALARM** 🎵 once for radio or /and
- **ALARM** 🕒 once for buzzer:

Helpful hints:

- If you have selected **ALARM** 🎵, make sure you have properly tuned to a station before turning off the set (See **TUNING TO RADIO STATIONS**).

3 ways to switch off the alarm

- Either press briefly: **ALARM RESET/SLEEP** or **REPEAT ALARM/** BRIGHTNESS CONTROL
- Press **ALARM** 🎵 or **ALARM** 🕒

Radio

1. Press **RADIO ON/OFF** once to switch on the radio.
 2. Press **TUNING +/-** one second or more to tune to your station.
- To store a preset, hold down briefly on a **PRESET** button **1-5** until you hear a double beep.