

Clock Radio

Register your product and get support at
www.philips.com/welcome

QUICK START

MISE EN SERVICE RAPIDE

INICIO RÁPIDO

SCHNELLSTART

SNELSTART

AVVIVO RAPIDO




Thanks for buying **Philips AJ210 clock radio**.

Our **Quick Start** guides you through just some of the features on the set.

Please read our instruction booklet to really rise & shine!

PHILIPS



ENGLISH

Step A

- Connect the supplied mains adapter to the set's 7.5V DC jack and the plug into a wall outlet.

Step B

How to set the Clock & Alarm time

1. Press and hold **TIME SET** or **ALM1 / ALM2** until the time digits flash.
2. Press and hold **TUNING +/-** to adjust time.
3. Press **TIME SET** or **ALM1 / ALM2** to confirm.
4. Repeat the **steps 2~3** to complete all the other time items setting.

Step C

Selecting the Alarm mode

In standby mode, slide the **RADIO/BUZ** to select desired mode.

Helpful hints:

- If you have selected **RADIO**, make sure you have properly tuned to a station before turning off the set.

3 ways to switch off the alarm

- Either press briefly: **SLEEP/ALARM RESET** or **REPEAT ALARM/BRIGHTNESS CONTROL**
- Press **ALM1** or **ALM2**.

Radio

1. Press **RADIO ON/OFF** once to switch on the radio.
2. Press **AUTO SCAN** to program all available stations.
3. Press **PRESET +/-** until the desired preset station is displayed.

Weather forecast and Indoor thermometer

The unit can auto detect and measure atmospheric pressure changes to graphically display the weather forecast in the next 12 to 24 hours, and current indoor temperature.

Note:

- The weather forecast based on the atmospheric pressure may vary slightly from the actual weather situation.

