

Docking Entertainment System

AJ301DB


Register your product and get support at
www.philips.com/welcome

QUICK START



Thanks for buying **Philips AJ301D Docking Entertainment System**.
Our **Quick Start** guides you through just some of the features on the set.
Please read our instruction booklet to really rise & shine!

PHILIPS



ENGLISH

Step A

- Connect the supplied mains adapter to the set's 18V DC jack and the plug into a wall outlet.

Step B

How to set the Clock & Alarm time

1. Press and hold **TIME SET** or **ALM1 / ALM2** until the hour digits flash.
2. Press and hold **◀▶▶▶** to adjust time.
3. Press **TIME SET** or **ALM1 / ALM2** to confirm.
4. Repeat the **steps 2~3** to complete all the other time items setting.

Step C

Selecting the Alarm mode

In standby mode, slide the **DOCK/BUZZER/TUNER** to select desired mode.

Helpful hints:

- If you have selected **TUNER** alarm mode, make sure you have properly tuned to a station before turning off the set (See **Tuning to radio station**).
- If you have selected **DOCK** alarm mode, make sure you have docked the compatible player, or buzzer mode will be selected automatically.

3 ways to switch off the alarm

- Either press briefly: **POWER** or **REPEAT ALARM/ BRIGHTNESS CONTROL**.
- Press **ALM1** or **ALM2**.

Step D

Tuning to radio station

1. Press **TUNER/AUX** once to switch on the radio.
 2. Press **◀▶▶▶** one second or more to tune to your station.
- To store a preset, hold down briefly on a **PRESET** button **1-5** until you hear a double beep.

Step E

Playing Apple iPod using AJ301D

1. Select the correct dock adaptor from the supplied, then snap the adaptor into the dock to provide a snug fit for the player.
- The iPod connector is pre-installed with the AJ301D main unit.
- The indication on the adaptor's back fits specific iPod player.
2. Snap the compatible iPod player into the dock connector.
3. Press **DOCK** to select the dock mode.
- The connected player will play automatically

Helpful hints:

- By using the buttons (**▶▶▶▶**, **◀▶▶▶** and **VOLUME**) on the AJ301D and its remote control, the following iPod playback features are available: Play/Pause, selecting next/previous track, fast forwarding/rewinding and changing volume.
- Refer to the user manual supplied for detailed descriptions of "Compatible portable player", "Changing the dock", "Selecting the correct dock adaptor" and the important notes for dock operation.

