

## Software/driver information

Firmware version: V090312a for AJL303/12

## Benefits of the Upgrade

1. Adjust the alarm sound volume when FM radio is selected as the alarm source.
2. Solve the problem of the left and right buttons not selecting pictures playback.

## How can I Review the firmware version in my device?

1. Switch on the device.
2. Press the **Menu** button on the device.
3. Select **Setting**→**Version**.

## How can I upgrade the firmware in my player?

**Important: Make sure the serial number of your device is in the scope of GS1A084200005 ~ GS1A090314244 before the update starts. The serial number can be found from the label attached on the bottom of your device.**

1. Download the firmware to your PC.
2. Unzip the downloaded file; you will get a file named philips.bin. Attention: Do not rename the file to avoid firmware upgrade failure.
3. Copy the file into a SD card. Make sure the SD card is compatible with the device.
4. Switch on the device and then insert the SD card, the firmware upgrade will auto start.
5. Once the firmware update is completed, the device will auto restart and the **Philips** logo will appear on the display.  
We suggest the firmware should be removed from your SD card to avoid a duplicated update when it is inserted into the device next time.

## Upgrade History

**Version: 081226a** Solve the problem of clock time disappearing when customers attempt to set it.