



PHILIPS

AQ 6443 Stereo Cassette Player



Inventor of CD and DCC
DIGITAL
dcc
COMPACT CASSETTE
a product from Philips
COMPACT
disc
DIGITAL AUDIO



Guarantee and Service valid for Australia

The benefits given to the purchaser by this warranty are in addition to all other rights and remedies, which, under the Trade Practices Act or other Commonwealth or State law, the purchaser or owner has in respect of the product.

The Philips product carries the following warranties:

- C-series Hi-Fi systems 12 months
- Compact Disc Players 12 months
- Home Audio Systems 6 months
- Clock radios, portable radios, cassette recorders, cassette players and radio recorders 90 days

Any defect in materials or workmanship occurring within the specified period from the date of delivery, will be rectified free of charge by the retailer from whom this product was purchased.

Note: Please retain your purchase docket to assist prompt service.

Conditions of this warranty

- 1 All claims for warranty service must be made to the retailer from whom this product was purchased. All transport charges incurred in connection with warranty service or replacement will be paid by the purchaser.
- 2 These warranties do not cover batteries and extend only to defects in materials or workmanship occurring under normal use of the product where operated in accordance with our instructions.

**Philips Consumer Products Division,
Technology Park, Figtree Drive,
Australia Centre,
Homebush 2140,
New South Wales.**

Guarantee and Service for New Zealand

Thank-you for purchasing this quality Philips product. Philips New Zealand Ltd guarantees this product against defective components and faulty workmanship for a period of 12 months. Any defect in materials or workmanship occurring within 12 months from the date of purchase subject to the following conditions will be rectified free of charge by the retailer from whom this product was purchased.

Conditions

1. The product must have been purchased in New Zealand. As proof of purchase, retain the original sales docket indicating the date of purchase.
2. The guarantee applies only to faults caused by defective components, or faulty workmanship on the part of the manufacturer.
3. The guarantee does not cover failures caused by misuse, neglect, normal wear and tear, accidental breakage, use on the incorrect voltage, use contrary to operating instructions, or unauthorised modification to the product or repair by an unauthorised technician.
4. Reasonable evidence (in the form of a sales docket) must be supplied to indicate that the product was purchased no more than 12 months prior to the date of your claim.
5. In the event of a failure, Philips shall be under no liability for any injury, or any loss or damage caused to property or products other than the product under guarantee.

This guarantee does not prejudice your rights under common law and statute, and is in addition to the normal responsibilities of the retailer and Philips.

How to claim

Should your Philips product fail within the guarantee period, please return it to the retailer from whom it was purchased. In most cases the retailer will be able to satisfactorily repair or replace the product. However, should the retailer not be able to conclude the matter satisfactorily, or if you have other difficulties claiming under this guarantee, please contact

**The Guarantee Controller
Philips New Zealand Ltd.**

☐ P.O. Box 41,021, Auckland.

☎ (09) 84 94 160 fax ☎ (09) 84 97 858

Allmänt

TILLBEHÖR (MEDFÖLJER)

- Stereohörlur
- Baltesklämma

ANVÄND HUVUDET NÄR DU ANVÄNDER HÖRLURAR

Tänk på din hörsel: Spela inte med för hög volym. Öronläkare råder oss att inte kontinuerligt lyssna med hög volym genom hörlurar. Om det börjar susa i oronen, avbryt lyssnandet eller minska ljudstyrkan.

Tänk på trafiksäkerheten: Använd inte hörlur när du framför ett fordon. Det kan förorsaka en trafikolycka och är dessutom olagligt i flera länder. Även om hörluren är av så kallad öppen typ, som gör det möjligt för dig att höra omgivande ljud, skall du inte använda så hög volym att du inte kan höra andra trafikanter.

UNDERHÅLL

- Rengör tonhuvudet efter ca 50 timmars användning ved hjälp av en rengöringskassett.
- Skydda apparat och kassetter mot regn, fukt, sand samt mot hög värme, t. ex i en bil parkerad i solen

MILJÖANVISNINGAR

1. Allt onödigt förpackningsmaterial har tagits bort. Vi har också gjort så att materialet skall vara lätt att dela upp i tre materialgrupper för återvinning:
 - kartongpapper (låda)
 - expanderad polystyren (stötupptagare)
 - polyeten (plastpåsar, skyddsfolie)Tag reda på vilka bestämmelser som gäller lokalt för hantering av förpackningsmaterialet.
2. Apparaten består delvis av material som kan återanvändas, om den plockas isär och tas om hand av en specialfirma.
Tag reda på vilka lokala bestämmelser som gäller för hantering av din gamla anläggning
3. Släng inte batterierna bland hushållssoporna. Följ de lokala bestämmelser som gäller för återlämning av batterier.

Dette produkt overholder kravene til radio-interferens af Europæisk Fællesmarked.

Typnumret återfinns på apparatens undersida och serienumret i batterifacket.

Dansk

Typeskiltet findes på undersiden af apparaten og serienumret i batterirummet.