


# PHILIPS




RC 6513

- Ⓞ Stereo radio cassette player ▶
- ⓕ Radio-lecteur de cassette ▶
- Ⓧ Stereo Radio-Cassettenspieler ▶
- Ⓝ Stereo radio-cassettespeler ▶
- ⓔ Radio-tocassetes estéreo ▶
- Ⓡ Radio-lettore cassette stereo ▶
- Ⓢ Stereo Radio-kassettspelare ▶
- Ⓛ Stereo radiokassettsöitin ▶



**PHILIPS**



## **GUARANTEE AND SERVICE FOR UNITED KINGDOM**

Philips sell this product subject to the understanding that if any defect in manufacture or material shall appear in it within 12 months from the date of consumer sale, the dealer from whom the product was purchased will arrange for such defect to be rectified without charge, provided

1. Reasonable evidence is supplied that the product was purchased within 12 months prior to the date of claim.
2. The defect is not due to use of the product for other than domestic purposes, or on an incorrect voltage, or contrary to the Company's operating instructions, or to accidental damage (whether in transit or otherwise), misuse, neglect or inexpert repair

Products sent for service should be adequately packed as no liability can be accepted for damage or loss in transit, and name and address must be enclosed

### **Facts about free service**

When service is required, apply to the dealer from whom the product was purchased. Should any difficulty be experienced in obtaining Service, e.g. in the event of the dealer having ceased to trade, you are advised to contact Philips Service

*These statements do not affect the statutory rights of a consumer*

If you have any questions which your dealer cannot answer, please write to **Philips Consumer Relations,**

☐ **P.O. Box 298, 420 London Road, CROYDON CR9 3QR,** or ☎ **(01) 689-2166 Consumer Advice.**

Please retain this card. Produce if service is required

---

## **GUARANTEE AND SERVICE VALID FOR IRELAND**

This apparatus is made of high quality material and great care has been taken in its manufacture. Philips, therefore, give you a guarantee on parts against failures arising from faulty workmanship or material for 12 months after date of purchase. This guarantee is valid on the condition that this certificate is completed and signed immediately on delivery of the apparatus. In case of failure ask your dealer for further information. If you have any questions which your dealer cannot answer, you may apply to

**Philips Electrical (Ireland) Ltd., Service Department, Newstead, Clonskeagh, DUBLIN 14, ☎ 69 33 55.**

---

## **GUARANTEE AND SERVICE VALID FOR AUSTRALIA**

The benefits given to the purchaser by this warranty are in addition to all other rights and remedies, which, under the Trade Practices Act or other Commonwealth or State law, the purchaser or owner has in respect of the product. The Philips product carries the following warranties: C-series HiFi-systems 12 months. Compact Disc Players 12 months. Home Audio Systems 6 months. Clock radios, portable radios, cassette recorders, cassette players and radio recorders 90 days.

Any defect in materials or workmanship occurring within the specified period from the date of delivery, will be rectified free of charge by the retailer from whom this product was purchased

**Note:** Please retain your purchase docket to assist prompt service

### **Conditions of this warranty**

1. All claims for warranty service must be made to the retailer from whom this product was purchased. All transport charges incurred in connection with warranty service or replacement will be paid by the purchaser
2. These warranties do not cover batteries and extend only to defects in materials or workmanship occurring under normal use of the product where operated in accordance with our instructions

**Philips Consumer Products Division, Technology Park, Figtree Drive, Australia Centre, HOMEBUSH 2140, New South Wales**

---

## **GUARANTEE AND SERVICE FOR NEW ZEALAND**

Thank you for purchasing this quality Philips product. The document you are now reading is your guarantee card **Guarantee.**

Philips New Zealand Ltd guarantees this product against defective components and faulty workmanship for a period of 12 months. Any defect in materials or workmanship occurring within 12 months from the date of purchase subject to the following conditions will be rectified free of charge by the retailer from whom this product was purchased

### **Conditions.**

1. The product must have been purchased in New Zealand, and this guarantee card completed at time of purchase (this is your proof of date of purchase)
2. The guarantee applies only to faults caused by defective components, or faulty workmanship on the part of the manufacturer

# English

## SUPPLY

Batteries: Insert as indicated two alkaline batteries, type R6, UM3 or AA. Remove the batteries if exhausted or if they are not to be used for a long time.

Mains adaptor: Connect a mains adaptor to the 3V DC socket. The adaptor must supply 3V DC  $\oplus$ - $\ominus$ , minuspole  $\ominus$  to the 1.3 mm centre pin of the 3.4 mm socket.

## RADIO RECEPTION

- Set **TAPE/RADIO** to **RADIO**.
- Connect headphones to  $\Omega$  **PHONES**. The headphone lead will function as FM-aerial.
- Set **BAND** to **FM** or to **AM (=MW)**.
- Tune to the desired radio station using **TUNING**. When the **FM STEREO**  $\ast$  indicator lights up, you are receiving a FM-stereo transmitter.
- Adjust the sound with **VOLUME** and **DBB** (bass).
- The set is switched off when **TAPE/RADIO** is in position **TAPE** and no cassette player button is pressed.

## PLAYING BACK CASSETTES

- Set **TAPE/RADIO** to **TAPE**.
- Connect headphones to  $\Omega$  **PHONES**.
- Open the cassette holder and insert the cassette in it with the open part facing the buttons.
- To start playback, press **PLAY**  $\blacktriangleleft$ .
- Adjust the sound with **VOLUME** and **DBB** (bass).
- To stop, press **STOP**  $\blacksquare$  and the set is switched off.
- At the end of the tape the  $\blacktriangleleft$  **PLAY** button is automatically released and the set is switched off.

Fast Winding: Press **F.FWD**  $\blacktriangleleft\blacktriangleleft$  or **REW**  $\blacktriangleright\blacktriangleright$ . To stop, press **STOP**  $\blacksquare$ .

## MAINTENANCE

- Clean the magnetic head after every 50 hours of operation or, on average, once a month by playing through the cleaning cassette SBC 114.
- Do not expose the set and cassettes to rain, moisture, sand, or to excessive heat from e.g. heating equipment or in motor cars parked in the sun.

This set complies with the radio interference requirements of the European Community. The type number will be found at the back of the set and the serial number in the battery compartment.

3. The guarantee does not cover failures caused by misuse, neglect, normal wear and tear, accidental breakage, use on the incorrect voltage, use contrary to operating instructions, or unauthorised modification to the product or repair by an unauthorised technician.
4. Reasonable evidence (in the form of a sales docket or completed guarantee card) must be supplied to indicate that the product was purchased no more than 12 months prior to the date of your claim
5. In the event of a failure, Philips shall be under no liability for any injury, or any loss or damage caused to property or products other than the product under guarantee

*This guarantee does not prejudice your rights under common law and statute, and is in addition to the normal responsibilities of the retailer and Philips.*

#### **How to claim.**

Should your Philips product fail within the guarantee period, please return it to the retailer from whom it was purchased. In most cases the retailer will be able to satisfactorily repair or replace the product.

However, should the retailer not be able to conclude the matter satisfactorily, or if you have other difficulties claiming under this guarantee, please contact

**The Guarantee Controller, Philips New Zealand Ltd, P.O. Box 1041, AUCKLAND - ☎ (09) 605-914**

---

### **GARANTIE EN SERVICE IN NEDERLAND**

#### **• Wat wordt gegarandeerd?**

Philips Nederland B.V. garandeert dat dit apparaat kosteloos wordt hersteld indien (bij normaal particulier gebruik volgens de gebruiksaanwijzing) binnen 12 maanden na aankoopdatum fabricage- en/of materiaalfouten optreden

#### **• Wie voert de garantie uit?**

De zorg voor de uitvoering van de garantie berust bij de handelaar die u het apparaat verkocht heeft. De handelaar kan daarbij eventueel een beroep doen op een der Philips Service vestigingen

#### **• Uw aankoopbon + de identificatiekaart**

De identificatiekaart is uw garantiebewijs. U kunt alleen een beroep doen op de bovenschreven garantie tegen overlegging van de aankoopbon (factuur, kassabon of kwitantie), in combinatie met de identificatiekaart, waarop typenummer en serienummer zijn vermeld. Uit de aankoopbon dienen duidelijk de aankoopdatum en de naam van de handelaar te blijken. Mocht het noodzakelijk zijn deze documenten aan uw handelaar af te geven, dan kunt u hem daarvoor een ontvangstbewijs vragen.

De garantie vervalt indien op de genoemde documenten iets is veranderd, doorgehaald, verwijderd of onleesbaar gemaakt. De garantie vervalt eveneens indien het typenummer en/of serienummer op het apparaat is veranderd, doorgehaald, verwijderd of onleesbaar gemaakt.

#### **• Hoe te handelen bij een storing?**

Om onnodige kosten te voorkomen, raden wij u aan bij storingen eerst nauwkeurig de gebruiksaanwijzing te lezen. Indien de gebruiksaanwijzing daarin geen uitkomst biedt, kunt u uw handelaar raadplegen en/of hem het apparaat ter reparatie aanbieden.

#### **• ...en bij problemen?**

Bij problemen omtrent de garantie-uitvoering kunt u zich in verbinding stellen met **Philips Nederland B.V., Afdeling Consumentenbelangen, Antwoordnummer 500, 5600 VB EINDHOVEN** (postzegel niet nodig), of ☎ 040-78 11 78.

---

### **GARANTIE EN SERVICE IN BELGIË EN LUXEMBURG**

In België en Luxemburg gelden uitsluitend de garantiebepalingen zoals die in het via uw handelaar apart verstrekte garantiebewijs staan aangegeven.

#### **• Voor België**

Indien u na de aankoop van een of ander Philips apparaat problemen heeft met bijv. de waarborg, de werking, of het gebruik ervan, en indien de verdeler die u deze apparaten verkocht heeft moeilijkheden ondervindt om deze problemen op te lossen, stelt u zich dan telefonisch of schriftelijk in verbinding met onze dienst **'Klanten Kontakt', de Brouckèreplein 2, 1000 - BRUSSEL - ☎ 02/211 91 11**

---

### **GARANTIE EN BELGIQUE ET LUXEMBOURG**

Pour les conditions de garantie en Belgique et Luxembourg veuillez vous référer à la carte de garantie que le revendeur doit vous remettre au moment de l'achat.

#### **• Pour la Belgique**

Si après l'achat de l'un ou l'autre appareil Philips vous avez des problèmes concernant par exemple la garantie, le

#### ΠΑΡΟΦΟΡΙΕΣ ΓΙΑ SERVICE ΚΑΙ ΕΓΓΥΗΣΗ ΣΤΗΝ ΕΛΛΑΔΑ

Η συσκευή έχει ελεγχθεί σχολαστικά, η λειτουργία της είναι αριστη και λογος αντικαταστασεως της δεν προκειται σε καμια περιπτωση να προκυχει. Αν ομως, παρ' ολα αυτα, καποιο εξαρτημα δεν λειτουργησει, το εξαρτημα αυτο και η εργασία επισκευης παρεχονται απο την εταιρια δωρεαν. Η προσκομιζομενη για επισκευη συσκευη πρεπει να συνοδευεται απαραιτητα απο το ΔΕΛΤΙΟ ΔΙΑΝΙΚΗΣ ΠΩΛΗΣΕΩΣ, η φωτοτυπια του, και το παρον εντυπο συμπληρωμενο και σφραγισμενο απο το καταστημα αγορας του.

Η εγγυηση ισχυει για ΕΝΑ ετος, απο την ημερομηνια αγορας. Η εγγυηση δεν ισχυει στις παρακατω περιπτωσεις:

α. Για ανωμαλια οχι απο βλαβη της συσκευης, αλλα απο φθορα η βλαβη, που προκληθηκε απο τριτους η απο μεταβολη της τασεως του ηλεκτρικου ρευματος.

β. Για ανωμαλια λογω ελαττωματικης εγκαταστασεως της συσκευης.

γ. Όταν ο αριθμος κατασκευτης της συσκευης εχει αλλοιωθει.

δ. Για κεφαλες πικ-απ και μικροφωνα.

Η εργασία επισκευης γινεται στα Εργαστηρια της Εταιριας, οπου ο πελατης πρεπει να μεταφερει τη συσκευη με δικη του δαπανη.

Κανενας αντιπροσωπος δεν εχει το δικαωμα αλλαγης των ορων εγγυσεως. Μετα τη ληξη του χρονου εγγυσεως, για καθε προβλημα συντηρησεως, επισκευης η συμβουλης, σας συνιστομε να αποτεινεσθε στα κατα τοπους Service της Εταιριας.

Διευθυνση Κεντρικων **SERVICE PHILIPS:**

25ης Μαρτιου 15, 177 78 Ταυρος - ☎ 4894.911

Τσιμισκη 62, 546 93 Θεσσαλονικη - ☎ 260.621

---



Guarantee certificate  
Identificatiekaart  
Certificado de garantía  
Εγγύηση

Garantieschein  
Garantibeviset

Certificat de garantie  
Certificato di garanzia  
Takuutodistus


Type no. of product:  
Tipo no. del producto:



Date of purchase – Date d'achat – Kaufdatum – Koopdatum - Fecha de compra  
Data da compra – Data di acquisto Købsdato - Kjøpedato – Inköpsdato – Ostopäivä  
Ημερομηνία αγοράς

19

Dealer's name, address and signature  
Nom, adresse et signature du revendeur  
Name, Anschrift und Unterschrift des Händlers  
Naam, adres en handtekening van de handelaar  
Nombre, dirección y firma del distribuidor  
Nome, indirizzo e firma del fornitore  
Nome, morada e assinatura do vendedor  
Forhandlerens navn, adresse og underskrift  
Återförsäljarens namn, adress och namnteckning  
Myyjän nimi, osoite ja allekirjoitus  
Όνομα/Επωνυμιο Αντιπροσωπου



09/89

2301-920-0-01