



Philips
Portable CD Player

AX2411

Jogproof

Irresistibly classic, the vibrant AX2411 CD players truly let you savor smooth, skip-free music. It flaunts an appealing round form and comes with a large display for convenient track viewing. It's designed to liven up your music on the go.

Jogproof

- 45-second ESP™

Enhanced bass performance

- Dynamic Bass Boost for deep and dramatic sound

Enjoy all kinds of discs

- Plays CD, CD-R and CD-RW discs

PHILIPS
sense and simplicity

Specifications

Sound

- D/A converter: 1-bit
- Frequency response: 20 - 20 000 Hz
- Signal to noise ratio: > 85dB
- Sound Enhancement: Dynamic Bass Boost
- Output Power: 2 x 5mW RMS
- Volume Control: digital
- Acoustic Feedback

Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: 30-Track Programmable, Fast Forward/Backward, Hold, Repeat Play, Resume Playback from stop, Shuffle Play, Scan
- Electronic Skip Protection(CD): 45

Connectivity

- DC in: 4.0 mm, 4.5V, centre +
- Headphone: 3.5 mm
- Line-out: 3,5 mm

Convenience

- Display Type: LCD
- Indications: battery status, Cd functions, DBB, ESP,



time, track

Accessories

- Headphones: AY3805 headphones
- Included Accessories: User Manual

Dimensions

- Housing: Heat Resistant Body, Lenticular Sheet
- Master carton dimensions: 215 x 345 x 235 mm
- Master carton weight: 1.8 kg
- Master carton quantity: 3
- Packaging dimensions (W x H x D): 208 x 309 x 65 mm
- Packaging type: Clamshell
- Product dimensions (WxDxH): 140x140x27.5mm
- Product weight: 0.2 kg
- Product weight (lb): 0.5

Power

- Battery Playing Time CD: 20
- Battery type: AA, LR6, UM3

Highlights

45-second ESP™

Electronic Skip Protection is a convenient feature that ensures skip-free music even when your CD player is subjected to knocks and jolts while you're jogging or on the move. Devices with Electronic Skip Protection have an intelligent electronic buffer that adjusts both its contents and laser spin speeds automatically to guarantee uninterrupted music listening.

Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Plays CDs, CD-R and CD-RW

Plays CD, CD-R and CD-RW discs



Issue date 2009-04-12

Version: 4.0.6

12 NC: 9073 101 01751

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com