

CD Sound Machine

AZ1110

## CD Sound Machine

- **Dynamic Bass Boost**

*Enhances bass tone frequencies to give deep, rich sounds.*

- **CD Synchro Start Recording**

*Synchronises the start of a recording on audio cassette with the start of a CD at the touch of a button.*

- **CD Player**

- **Analogue Tuner**

- **Single Cassette Deck**



*Let's make things better.*



**PHILIPS**

CD Sound Machine

AZ1110

## Standard product information

### Amplifier

- Output power : 2 x 1.6 W RMS
- Dynamic Bass Boost
- Rotary volume control

### Sound System

- 2 x 4" full range speakers
- Metal speaker grilles

### CD Player

- Top loader
- 20 track programme, repeat, shuffle
- Cue/review
- CD synchro start recording

### Cassette Deck

- Single stereo cassette deck
- Normal tape type
- Automatic recording level control
- Full automatic stop

### Tuner

- Analogue tuning
- Wavebands
  - /00, /05 : FM stereo/MW
  - /01, /11, /13 : FM stereo/MW
  - /14 : FM 1 /2, MW
- Frequency ranges : FM 87.5 - 108 MHz
- FM 65.8 - 74/87.5 - 108 MHz (/14)
- MW 525 - 1607 kHz
- LW 148.5 - 284 kHz
- Telescopic antenna for FM reception
- Ferroreceptor for AM reception

### Display

- 2-digit LCD display

### Connections

- Headphone socket : 3.5 mm

### Power Supply

- AC/DC operation
- AC voltage /01, /11 : 120/230 V, 50 Hz
- /00, /05, /13, /14 : 230 V, 50 Hz
- Batteries : DC 6 x 1.5V, R20 cells

### General

- Material : HIPS
- Weight of product : 3.4 Kg
- Dimensions : 300 mm W x 159 mm H x 270 mm D
- Packaging dimensions : 370 mm W x 322 mm H x 210 mm D
- Quantity /mastercarton : 1

## Product Highlights

### • Compact Disc Digital Audio Player

Compact Disc technology that combines superb digital sound quality with the convenience of random track access and CD functions like CD programme, Shuffle Play and Repeat.

### • 20-Track Programmable

Stores up to 20 of your favourite CD tracks for playing back in your order of preference.

### • Shuffle Play

Plays disc selection randomly, giving you a new sequence of tracks each time.

### • Repeat One/All

Repeats the current track, the total CD, or your pre-selected programme.

### • CD Next/Previous Track Search

Plays the next or previous track at the touch of a button.

### • CD Music Search

Searches the CD at high speed while still producing low-volume sound so you know exactly when to stop.

### • Analogue Tuner

High-quality tuner with sensitive operation for maximum tuning control.

### • Stereo Cassette Deck

Play back recorded tapes on this full-functional stereo cassette deck, and record from the built-in CD player or tuner.

### • Full Auto Stop

Automatically shuts off the cassette deck at the end of playback to avoid overstretching the tape.

### • Automatic Recording Level Control

Electronic circuit that constantly monitors the input signal to ensure accurate, distortion-free recording.

### • CD Synchro Start Recording

Synchronises the start of a recording on audio cassette with the start of a CD at the touch of a button.

### • 4" Full-Range Speakers

For excellent sound performance across the entire audio frequency spectrum.

### • Dynamic Bass Boost

Enhances bass tone frequencies to give deep, rich sounds.

### • Two-Digit LCD Display

Displays CD track numbers and play modes like Shuffle, Repeat, and CD programme.

### • Stereo Headphone Socket

Enables stereo headphones to be used for private listening pleasure. Automatically switches off speakers when used.

### • AC/DC Operation

Operates either on batteries or mains supply, using the detachable AC power cord.

98-04-03

Subject to modification without notice  
© 1998 Philips Electronics N.V.  
All Rights Reserved

<http://www.philips.com>

Let's make things better.



PHILIPS