

CD Soundmachine

***Direct track
and station selection***

- Easy access keyboard
- Digital tuner with 40 station presets
- Autostore programming
- Dynamic bass boost
- Bass reflex speaker system
- CD-Rewritable compatible
- 20-track CD programmable
- Shuffle play



Let's make things better.



PHILIPS

CD Soundmachine



Standard product information

CD player

- Toploader with manual door
- 20-track CD programmable
- Shuffle play
- CD synchro-start recording
- CD-Rewritable compatible
- Repeat one/ all/ program
- CD next/ previous track search

Tuner

- Digital tuning system
- 40 station presets
- Autostore presets for quick programming
- Direct preset input via Easy access keyboard
- Telescopic antenna for FM reception
- Internal antenna for AM reception
- Wavebands
FM stereo
AM/ MW
LW (only for Europe)

Tapedeck

- Automatic recording level
- Full auto-stop

Sound system

- Output power 2 x 1 W RMS
- Dynamic bass boost
- 2 x 4" speakers
- Metal speaker grilles
- Digital up/ down volume control

Display

- 4-digit multi-functional LCD

Connections

- Headphone/ line out Stereo, 3.5 mm

Power supply

- AC/ DC operation
- Batteries 6 x 1.5V, R14

General

- Product dimensions 405 W x 162 H x
(mm) 232 D
- Product weight (kg) 3.1
- Package dimension 475 W x 211 H x
(mm) 260 D
- Weight incl packing 3.8
(kg)

Easy access keyboard

Well-known 10 button interface for easiest possible tuner preset and CD track access.

Digital tuner with 40 station presets

Provides fast, accurate tuning to your favourite stations. You can store up to 40 FM and MW stations in memory for fast, easy access.

Autostore programming

Automatic programming of strongest available radio stations.

Dynamic bass boost

An electronic circuit that enhances bass frequencies up to 3 times to compensate for the insensitivity of the human ear for bass frequencies at lower volume levels.

Bass reflex speaker system

Acoustic system that enhances the upper bass tones to provide a warmer, punchier bass sound.

CD-Rewritable compatible

CD player capable of playing all music CDs, including CD-Recordable and CD-Rewritable discs.

20-track CD programmable

Stores up to 20 of your favourite CD tracks for playing back in your order of preference.

Shuffle play

Plays all selections on a disc in random order, giving you a new sequence of tracks every time.

Digital up/ down volume control

Accurate electronic volume control with level indication.

CD Synchro-start recording

One button touch will synchronize the start of a recording on audio cassette and the start of a CD or CD program.

4" Full-range speakers

For excellent sound reproduction across the entire audio spectrum.

Full auto-stop tapedeck

Automatically shuts off the cassette deck at the end of playback to avoid stretching the tape.

Repeat one/ all/ program

Repeats the current track, the total CD, or your pre-selected program.

Stereo headphone socket

Supports stereo headphones for private listening pleasure. Automatically switches off speakers when used.

4-digit Multi-functional LCD display

Displays CD player information (track, time, play mode), tuner information (preset station, frequency) and DBB on/off.

Printed in Hong Kong 2001-11-12

Specifications subject to modification without notice

© 2001 Koninklijke Philips Electronics N.V.

All rights reserved

www.philips.com

www.audio.philips.com

Let's make things better.



PHILIPS