

Philips  
CD Soundmachine

Lifestyle design  
USB

AZ1837



## Enjoy your music wherever you go

Handy lifestyle design, enjoy music from different sources like USB Direct, MP3-CD, radio.

### Enjoy your music from different sources

- Play MP3/WMA-CD, CD and CD-RW
- Enjoy MP3/WMA music directly from your portable USB drives
- FM/MW tuner for radio enjoyment
- MP3 Link for portable music playback

### Easy to use

- CD Shuffle/Repeat for personalized music enjoyment
- 20-track CD programmable

# PHILIPS


# Highlights

## USB Direct for MP3/WMA music



Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

## CD Shuffle/Repeat



The "Shuffle/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favorite songs to the player, all you have to do is to select one of the modes - "Shuffle" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

## MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

## Play MP3/WMA-CD, CD and CD-RW



Audio compression technology allows large digital music files to be reduced up to 10 times in size without radically degrading their audio quality. MP3 or WMA are two of the compression formats that let you enjoy a world of digital music on your Philips player. Download MP3 or WMA songs from authorized music sites on the Internet or create your own MP3 or WMA music files by ripping your audio CDs and transferring them onto your player.

# Specifications

## Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: fast forward/backward, next/previous track search, repeat/shuffle/program
- USB Direct playback modes: fast backward/fast forward, previous/next, program play, shuffle

## Tuner/Reception/Transmission

- Tuner bands: FM, MW
- Antenna: FM antenna

## Connectivity

- USB: USB host
- MP3 Link: 3.5mm stereo line in

## Sound

- Sound system: stereo
- Volume control: rotary (analogue)
- Output power: 2 x 1 W RMS

## Loudspeakers

- No. of built-in speakers: 2
- Speaker grille finishing: metal

## Convenience

- Loader type: top
- Display type: LCD display

## Accessories

- Cables/Connection: 3.5 mm stereo line in cable, power cord
- Remote control
- Others: User Manual
- Warranty: Warranty Certificate

## Power

- Battery type: C size (LR14)
- Battery voltage: 1.5 V
- Power supply: 220 - 240 V
- Number of batteries: 6

## Dimensions

- Gross weight: 2.4 kg
- Packaging depth: 139 mm
- Packaging height: 262 mm
- Packaging width: 371 mm
- Weight: 1.8 kg
- Main unit depth: 236 mm
- Main unit height: 122 mm
- Main unit width: 341 mm



Issue date 2014-02-12

Version: 1.0.3

12 NC: 8670 000 60439  
EAN: 87 12581 52758 7

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)