

Philips
CD Soundmachine

Multisource ripping

USB
Tape

AZ1852



Great portable sound

Continuous music pleasure is in your hands with the Philips CD Soundmachine AZ1852. Rip CDs and convert your favorite radio programs and tapes to MP3 format without the need of a computer. Features USB Direct for added portable music fun

Continuous enjoyment of your favorite music

- Enjoy MP3/WMA music directly from your portable USB drives
- Plays MP3/WM-CD, CD, CD-R & CD-RW
- Autostop cassette deck
- FM tuner for radio enjoyment

Easy to use

- MP3 Link for portable music playback
- Handy remote control
- Rip-plus for one-touch MP3 recording from multiple sources

Rich and clear sound

- Dynamic Bass Boost for deep and dramatic sound

PHILIPS

Specifications

Audio Playback

- Loader Type: Top
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Programmable Tracks: 20
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Cassette Deck Technology: Mechanical
- Number of decks: 1
- USB Direct Modes: Delete, Fast Backward/Fast Forward, Play/Pause, Previous/Next, Repeat, Shuffle, Stop

Audio Recording

- Recording Media: Tape, USB device
- Tape Recording Enhancement: CD Synchro Start Recording
- USB recording sources: CD, Tape, Tuner

Tuner/Reception/Transmission

- Tuner Bands: FM
- Antenna: FM Antenna

Connectivity

- USB: USB host
- Headphone: 3.5 mm
- 3.5mm stereo line in: (MP3 Link)

Sound

- Output power (RMS): 2 x 1W
- Sound System: Stereo
- Speaker diameter: 3"
- Volume Control: rotary

Loudspeakers

- Built-in speakers: 2

Convenience

- Display Type: LCD

Accessories

- Included accessories: AC Power Cord, User Manual, Warranty certificate
- Remote control

Power

- Battery type: LR14
- Battery voltage: 1.5 V
- Mains power: 230 V - 240 V
- Number of batteries: 6

Dimensions

- Packaging dimensions (W x H x D): 404 x 204 x 304 mm
- Product dimensions (W x H x D): 360 x 161 x 256 mm
- Weight: 2.8 kg
- Weight incl. Packaging: 3.5 kg

Highlights

USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

Rip-plus

With this smart feature, you can rip your desired music content from CDs, cassette tapes (if applicable), radio programs or any device with a line-in connection via the hi-fi system directly to your USB device and SD card (if applicable) into MP3 format- without using a PC.



Issue date 2014-02-13

Version: 3.0.3

12 NC: 8670 000 66828
EAN: 87 12581 55945 8

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com