

Philips
CD Soundmachine

Multisource ripping

USB Tape

AZ1856



Great portable sound

With the advanced Philips CD soundmachine, you can now convert your favorite CDs, radio program, tape music to MP3 music with the single touch of a button, no computer is required.

Continuous enjoyment of your favorite music

- Plays MP3/WM-CD, CD, CD-R & CD-RW
- Enjoy MP3/WMA music directly from your portable USB drives
- Rip music from CDs, radio and cassette onto a USB device

Powerful sound you can hear and feel

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Dynamic Bass Boost for deep and dramatic sound

Easy to use

- One-touch buttons for easy recording
- Handy remote control

PHILIPS
sense and simplicity

Specifications

Connectivity

- USB: USB host
- Audio/Video output: Headphone (3.5mm)

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: fast forward/backward, next/previous track search, repeat/shuffle/program
- Cassette deck technology: mechanical
- Number of decks: 1
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, repeat, shuffle, stop

Tuner/Reception/Transmission

- Tuner bands: FM
- Antenna: FM antenna

Sound

- Sound system: stereo
- Volume control: rotary (analogue)
- Output power: 2 x 1 W / 60 W PMPO

Loudspeakers

- No. of built-in speakers: 2
- Speaker grille finishing: metal

Convenience

- Loader type: top
- Display type: LCD display

Accessories

- Cables/Connection: power cord
- Remote control
- Others: User Manual
- Warranty: Warranty Certificate

Power

- Battery type: C size (LR14)
- Battery voltage: 1.5 V
- Number of batteries: 6
- Power type: AC Input

Dimensions

- Gross weight: 4.15 kg
- Packaging depth: 298 mm
- Packaging height: 210 mm
- Packaging width: 452 mm
- Weight: 3.14 kg
- Main unit depth: 238 mm
- Main unit height: 162 mm
- Main unit width: 400 mm

Audio recording

- Recording media: tape, USB device
- Tape recording enhancement: CD synchro start recording
- USB recording modes: instant record, programmed tracks, single disc, single track
- USB recording sources: CD, tape, tuner

Highlights

USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

USB Rip All

With this smart feature, you can easily listen to all your music content on your Hi-Fi system directly from your portable MP3 player. Simply rip your desired music content from CDs, cassette tapes, radio programs or line-in music from your system directly to your USB device. Store your favorite cassette tapes and convert its content into MP3 format - without using a PC. You can also preset timer recording of your favorite radio show on your system and it will automatically record the show onto your USB device.



Issue date 2012-10-14

Version: 1.0.8

12 NC: 8670 000 33209
EAN: 87 12581 35836 5

© 2012 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com