

Philips
CD Soundmachine

Black/white

AZ202



Enjoy your music wherever you go

Enjoy music on the go. Stylish, portable and designed for ease of use, this Philips CD soundmachine's cool simplicity lets you enjoy your music wherever you are. Let great style and great sound bring the groove to your every move

Enjoy your music from different sources

- Play CD, CD-R and CD-RW
- FM/MW tuner for radio enjoyment
- MP3 Link for portable music playback

Easy to use

- CD Shuffle/Repeat for personalized music enjoyment
- 20-track CD programmable

Rich and clear sound

- Dynamic Bass Boost for deep and dramatic sound

PHILIPS

Specifications

Audio Playback

- Loader Type: Top
- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Programmable Tracks: 20

Tuner/Reception/Transmission

- Tuner Bands: FM, MW
- Antenna: FM Antenna

Sound

- Output power (RMS): 2 x 1W
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- Speaker diameter: 2.5"
- Volume Control: rotary

Connectivity

- 3.5mm stereo line in: (MP3 Link)

Power

- Mains power: 220V - 240V
- Battery type: LR14
- Battery voltage: 1.5 V
- Number of batteries: 6

Accessories

- Included accessories: AC Power Cord, User Manual, Warranty certificate

Dimensions

- Packaging dimensions (W x H x D): 324 x 284 x 139 mm
- Product dimensions (W x H x D): 297 x 112 x 264 mm
- Weight: 1.7 kg
- Weight incl. Packaging: 2.1 kg



Highlights

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

CD Shuffle/Repeat

The "Shuffle/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favorite songs to the player, all you have to do is to select one of the modes - "Shuffle" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

