



Philips  
CD Soundmachine

CD, MP3-CD, USB, FM

Tape  
SD  
2W



AZ329

## Enjoy music wherever you go

You take pleasure in the simple things in life and delight in convenience. The compact and portable Philips CD soundmachine lets you indulge in the pleasures of enjoying your favorite music with the help of easy-to-use functions.

### The ultimate listening experience

- USB Direct and SD card slots for MP3/WMA playback
- Play MP3-CD, CD and CD-R/RW
- FM tuner for radio enjoyment
- Autostop cassette deck

### Easy to use

- Audio-in for easy portable music playback
- CD Shuffle/Repeat for personalized music enjoyment
- 20-track CD programmable

# PHILIPS


# Highlights

## Play MP3-CD, CD and CD-R/RW




MP3 stands for "MPEG 1 Audio layer-7.6 cm (3")". MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

## Autostop cassette deck



Autostop cassette deck

## CD Shuffle/Repeat



The "Shuffle/Repeat" function helps you to get rid of the boredom of hearing your music played in the

same order all the time. After loading your favorite songs to the player, all you have to do is to select one of the modes - "Shuffle" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

## AUDIO-IN (3.5mm)



Make one easy connection and enjoy all your music from portable devices and computers. Simply plug your device to the AUDIO-IN (3.5 mm) port on your Philips set. With computers, the connection is typically made from the headset output. Once linked, you can enjoy your entire music collection directly, on a set of superior speakers. Philips simply delivers better sound.

## USB Direct and SD card slots



Thanks to the complete file transferability, you can easily enjoy the convenience and fun of accessing more digital music via the built-in USB Direct and SD card slots.

# Specifications

## Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, SD card, USB flash drive
- Disc playback modes: fast forward/backward, next/previous track search, repeat/shuffle/program
- Number of decks: 1
- Cassette deck technology: mechanical
- USB Direct playback modes: fast backward/fast forward, previous/next, program play, shuffle, play/pause, repeat, stop

## Tuner/Reception/Transmission

- Tuner bands: FM
- Antenna: FM antenna

## Sound

- Sound system: stereo
- Volume control: rotary (analogue)
- Output power: 2 x 1 W RMS

## Loudspeakers

- No. of built-in speakers: 2

## Convenience

- Display type: LCD display
- Loader type: top

## Connectivity

- Audio in (3.5mm)

## Power

- Power supply: 100 - 240V AC, 50/60Hz
- Battery type: C size (LR14)
- Number of batteries: 6
- Battery voltage: 1.5 V

## Accessories

- Cables/Connection: power cord
- Others: Quick start guide
- Warranty: Warranty leaflet

## Dimensions

- Packaging depth: 158 mm
- Packaging height: 275 mm
- Packaging width: 326 mm
- Gross weight: 2.4 kg
- Main unit depth: 240 mm
- Main unit height: 132 mm
- Main unit width: 299 mm
- Weight: 2 kg



Issue date 2014-06-12

Version: 2.0.3

12 NC: 8670 001 01009  
EAN: 87 12581 68059 6

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)