



Philips
CD Soundmachine

CD, MP3-CD, USB
FM/AM
2W

AZ380

Enjoy your music wherever you go

with USB direct

Want to enjoy the music collections stored at portable music player without using headphone? Plug the USB Direct socket to the Philips CD soundmachine and enjoy your favorite digital music through the powerful speakers - anytime, anywhere.

Enjoy your music from different sources

- USB Direct for MP3/WMA music playback
- Play MP3/WMA-CD, CD and CD-RW
- FM/MW tuner for radio enjoyment
- MP3 Link for portable music playback

Easy to use

- CD Shuffle/Repeat for personalized music enjoyment
- 20-track CD programmable

PHILIPS

Specifications

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: fast forward/backward, next/previous album search, next/previous track search, repeat/shuffle/program

Tuner/Reception/Transmission

- Tuner bands: FM, MW (AM)
- Antenna: FM antenna

Sound

- Sound system: stereo
- Volume control: rotary (analogue)
- Output power: 2 x 1 W RMS

Loudspeakers

- No. of built-in speakers: 2
- Speaker grille finishing: metal

Connectivity

- MP3 Link: 3.5mm stereo line in
- USB: USB host

Power

- Battery type: C size (LR14)
- Battery voltage: 1.5 V
- Number of batteries: 6
- Power type: AC Input - 110V

Convenience

- Display Digits: 3
- Display type: LCD display
- Loader type: top

Accessories

- Cables/Connection: power cord
- Warranty: Warranty leaflet
- Others: User Manual

Dimensions

- Product dimensions (WxDxH): 212 x 245 x 130 mm
- Packaging dimensions (WxDxH): 280 x 156 x 246 mm
- Product weight: 1.1 kg
- Weight incl. Packaging: 1.7 kg

Highlights

Play MP3/WMA-CD, CD and CD-RW



Audio compression technology allows large digital music files to be reduced up to 10 times in size without radically degrading their audio quality. MP3 or WMA are two of the compression formats that let you enjoy a world of digital music on your Philips player. Download MP3 or WMA songs from authorized music sites on the Internet or create your own MP3 or WMA music files by ripping your audio CDs and transferring them onto your player.

MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

USB Direct



With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.



Issue date 2014-06-12

Version: 1.0.2

12 NC: 8670 001 08437
UPC: 6 09585 23861 9

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com