





Connect wires 1

- 1 Check the car's wiring carefully, then connect them to the unit.


Mount in the dashboard 2

- 1 Remove the original in-car system and the controller panel of air conditioner from the dashboard.
- 2 Keep the controller panel of air conditioner and plastic buckles.
- 3 Fix the plastic buckles (removed from the original in-car system) to the unit. 
- 4 Attach the controller panel of the original air conditioner to the unit.
- 5 Fix the mounting brackets to the unit with screws (removed from the original in-car system). 
- 6 Slide the unit into the dashboard and fix it to the car with screws (removed from the original in-car system). 
- 7 Reconnect the negative terminal of the car battery.

Turn on

- 1 Press  to turn on the unit.
 - ↳ The available OSD (On-Screen Display) languages are displayed.



- 2 Tap a language with fingertip.
 - To turn off the unit, press and hold .

Set date and time

- 1 Tap  to display main menu.



- 2 Tap [Settings].
- 3 Tap [Time].



Set date


- 1 Tap [Date].
- 2 Tap on the displayed date information.



- 3 Tap  or  to set year, month and day.

Set clock mode

- 1 Tap [Clock mode].




- 2 Tap on [12Hr] or [24Hr] to select clock mode.

Set time

- 1 Tap [Time].
- 2 Tap on the displayed time.



- 3 Tap  or  to set hour and minute.


Use map

Note

- You may need to upgrade the map (sold separately) before using it (see "Upgrade the map" section).



- 1 Tap the upper left corner to display home menu.
- 2 Tap [Navigation].
 - ↳ The navigation menu is displayed in a few seconds.
- 3 Refer to the map manual to operate the navigation tool.

Listen to radio

- 1 Tap  to display home menu.
- 2 Tap [Radio].



- 3 Tap FM or AM to select band:
 - FM band options: FM1, FM2, FM3
 - AM band options: AM1, AM2

- 4 Briefly tap  or  to tune to a radio station by step.

Play disc 3

You can play video, audio or images stored on the following discs:

- DVD Video, DVD-R, DVD-RW
- VCD
- Audio CD, CD-R, CD-RW

- 1 Insert the disc into the disc slot with label side facing up.
 - ↳ Play starts automatically.

Connect USB device 4

- 1 Open the USB cover.
- 2 Insert your USB device to the USB socket.
 - ↳ Play starts automatically.




Insert SD/MMC card 5



- 1 Open the SD/MMC card cover.
- 2 Insert the SD/MMC card into the SD/MMC card slot.
 - ↳ Play starts automatically.



Make a call

To connect your Bluetooth device to the unit, you need to pair the device to the unit.

- 1 Turn on the Bluetooth function on the device.
- 2 Search for Bluetooth device with the device.
- 3 Select "CID3610" in the pairing list.
- 4 Enter default password "0000".
 - ↳ If pairing succeeds, phone call record is displayed.

- 5 Tap  or  to select the paired phone, then tap .

- 6 Tap  or  to search for phone number from the following list:
 - [Missed calls]
 - [Received calls]
 - [Dialed calls]
 - [Phone book]
 - [Sim phone book]
 - [Local phone book]




Or tap  to dial number directly, then tap  to dial.

简体中文

连接导线 1

- 1 仔细检查汽车的导线，然后将其连接至本装置。


在仪表盘中安装 2

- 1 从仪表板卸下原装车载系统和空调的控制器面板。
- 2 保留空调的控制器面板和塑料带扣。
- 3 将(从原装车载系统中卸下的)塑料带扣固定在装置上。 
- 4 将原空调的控制器面板安装到装置上。
- 5 用(从原装车载系统中卸下的)螺钉将安装托架固定在装置上。 
- 6 将装置滑入仪表板中，并用(从原装车载系统中卸下的)螺钉将其固定在汽车上。 
- 7 重新连接汽车电池的负极。

开机

- 1 按  启动本装置。
 - ↳ 屏幕上将显示可用的 OSD (屏幕显示) 语言。




- 2 用指尖轻击一种语言。
 - 要关闭装置，请按住 .

设置日期和时间

- 1 轻击  显示主菜单。



- 2 轻击 [设置]。
- 3 轻击 [时间]。



设置日期

- 1 轻击 [日期]。
- 2 轻击所显示的日期信息。



- 3 轻击  或 ，设置年、月、日。

设置时钟模式

- 1 轻击 [时钟模式]。



- 2 轻击 [12Hr] 或 [24Hr] 选择时钟模式。

设置时间

- 1 轻击 [时间]。
- 2 轻击所显示的时间。



- 3 轻击  或 ，设置小时、分钟。

使用地图

注

- 使用地图(另购)之前，可能需要先升级。


- 1 轻击屏幕左上角以显示主菜单。
- 2 轻击 [导航]。
 - ↳ 几秒钟后，将显示导航菜单。

- 3 要操控导航工具，请参阅地图手册。

收听广播

- 1 轻击  显示主菜单。
- 2 轻击 [收音机]。



- 3 轻击 FM 或 AM 以选择频段:
 - FM 频段选项: FM1, FM2, FM3
 - AM 频段选项: AM1, AM2
- 4 短暂地轻击  或  可逐步调谐至所需电台。

播放光盘 3

您可以播放存储在以下光盘上的视频、音频或图像:

- DVD Video, DVD-R, DVD-RW
- VCD
- Audio CD, CD-R, CD-RW

- 1 令标签面朝上，将光盘插入光盘插槽。
 - ↳ 播放将自动开始。

连接 USB 设备 4







- 1 打开 USB 盖。
- 2 将您的 USB 设备插入 USB 接口。
 - ↳ 播放将自动开始。



插入 SD/MMC 卡 5

- 1 打开 SD/MMC 卡保护盖。
- 2 将 SD/MMC 卡插入 SD/MMC 卡插槽。
 - ↳ 播放将自动开始。

打电话

要将蓝牙设备连接至本装置，您需要将该设备与本装置配对。

- 1 如有来电，屏幕上的 [来电...] 将闪烁。对着蓝牙耳机讲话。
 - 2 通话结束时，轻击  (红色) 可终止通话。
- 1 将电话与本装置配对。
 - 2 用本设备搜索蓝牙设备。
 - 3 选择配对列表中的 "CID3610"。
 - 4 输入默认密码 "0000"。
 - ↳ 如果配对成功，将显示通话记录。
 - 5 轻击  或  以选择配对的电话，然后轻击 。
 - 6 轻击  或  从下面的列表中搜索电话号码:
 - [未接来电]
 - [已接来电]
 - [已拨电话]
 - [手机电话]
 - [Sim电话]
 - [本地电话]

或轻击  直接拨打电话号码，然后轻击  拨号。

