

PHILIPS

Pusher

CP1326



to replace your current Pusher

you need the pusher to pull down all the ingredients

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

Specifications

Replaceable part

Fits product types:: HR1855/01, HR1855/03, HR1855/05, HR1855/30, HR1855/31, HR1855/40, HR1855/45

