


PHILIPS

Potato masher
paddle

CP1387



to replace your current Potato masher paddle

this is the replacement part for your Potato Masher Accessory

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

Specifications

Replaceable part

For kitchen appliance model:: HR253x, HR254x

