

PHILIPS

Pan for bread maker

CP9221



Pan for kneading dough and baking bread

Bread pan suitable for product week code \geq 1208

If the pan of your bread maker is worn or damaged, replace it with this original spare part from Philips and enjoy your freshly baked bread in the morning again.

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

Specifications

Replaceable part

Fits product type:: HD9020/40

