

Quick Start Guide






Step A *Connect*

Step B *Setup*





Step C *Enjoy*

What's in the Box?

You should find these items upon opening the box.



Remove the plastic protective sheet



Step A **Connect**

1 Connect the FM antenna.


2 Connect the power cord of the system.

Note:

- Position the FM antenna away from the speaker wires to avoid electrical interference.

Tip

See the User Manual for how to connect other equipment to this system.



Step B **Setup**

Setting the clock

Important!


- To set clock in the Eco Power mode, press and hold **POWER** on the set for 3 seconds or more to switch to normal standby mode first before proceeding with the procedures below.

1 In standby mode, press **PROG/SET TIME** for more than 3 seconds.
→ The clock digits flash.

2 Press **◀◀▶▶** to set the minutes.


3 Press **TUNING +/-** to set the hours.


4 Press **PROG/SET TIME** to confirm the time.



Playing a USB mass storage device

With the system, you can use USB flash memory (USB 2.0 or USB1.1), USB flash players (USB 2.0 or USB1.1).

- 1 Insert the USB device's USB plug into the socket  on the set.
- 2 Press **USB** to select **USB**.
- 3 Play the USB's audio files.




Before using the remote control

- 1 Pull out the plastic protective sheet.
- 2 Select the source you wish to control by pressing one of the source select keys on the remote control (for example **USB**, **TUNER**).
- 3 Then select the desired function (for example **▶ ||**, **◀◀◀**, **▶▶▶**)

Programming and tuning to radio stations

- 1 Press **TUNER** to select the tuner source.
- 2 Press **PROG/SET TIME** for more than 3 seconds to program all available stations.
- 3 Press **ALBUM/PRESET ▲ / ▼** until the desired preset station is displayed.



Playing Apple iPod using DC570

1

Select the correct dock adaptor, as indicated on each adaptor, then fit it in the dock.

2

Correctly place the compatible iPod player into the dock.

3

Press **iPod** to select the iPod source.

4

Power on your iPod player.

5

Select and play your favourite songs stored in the iPod player.

Tip

Detailed playback features and additional functions are described in the User Manual.

