

Quick Start Guide






Step A **Connect**

Step B **Setup**





Step C **Enjoy**

What's in the Box?

You should find these items upon opening the box.



Pull out the plastic protective sheet before use.



Step A **Connect**

1

Connect the FM antenna.

2


Connect the power cord of the system.

Note:

– Position the FM antenna away from the speaker wires to avoid electrical interference.

Tip

See the User Manual for how to connect other equipment to this system.



Step B **Setup**

Setting the clock

Important!

– To set clock in the Eco Power mode, press and hold **POWER** on the set for 3 seconds or more to switch to normal standby mode first before proceeding with the procedures below.

1

In standby mode, press **PROG/SET TIME** for more than 3 seconds.
→ The clock digits flash.

2


Press **◀◀/▶▶** to set the minutes.

3

Press **TUNING +/-** to set the hours.


4

Press **PROG/SET TIME** to confirm the time.




Playing a USB mass storage device

With the system, you can use USB flash memory (USB 2.0 or USB1.1), USB flash players (USB 2.0 or USB1.1).

1 Insert the USB device's USB plug into the socket  on the set.


2 Press **USB** to select **USB**.

3 Play the USB's audio files.



Before using the remote control

- 1 Pull out the plastic protective sheet.
- 2 Select the source you wish to control by pressing one of the source select keys on the remote control (for example **USB**, **TUNER**).
- 3 Then select the desired function (for example **▶ ||**, **◀◀**, **▶▶**)






Remove the plastic protective sheet

Programming and tuning to radio stations

1 Press **TUNER** to select the tuner source.

2 Press **PROG/SET TIME** for more than 3 seconds to program all available stations.

3 Press **ALBUM/PRESET**  /  until the desired preset station is displayed.



Playing Apple iPod using DC570

1

Select the correct dock adaptor, as indicated on each adaptor, then fit it in the dock.

2

Correctly place the compatible iPod player into the dock.

3

Press **iPod** to select the iPod source.

4

Power on your iPod player.

5

Select and play your favourite songs stored in the iPod player.

Tip

Detailed playback features and additional functions are described in the User Manual.



© Royal Philips Electronics N.V. 2007
All rights reserved.

