

















PHILIPS

FC9931, FC9929,
FC9928, FC9924,
FC9922, FC9921












FC9928
FC9924
FC9921






FC9931



FC9931



FC9922



FC9931
FC9929
FC9928



ATTENTION: Only suitable for soft floors (carpets)!
ACHTUNG: Nur für weiche Böden (Teppichböden) geeignet!
ATTENTION: Convient seulement à des sols mous (tapis)!
LET OP: Alleen geschikt voor zachte vloeren (tapijt)!
DIKKAT: Yalnızca yumuşak zeminler (halılar) için uygundur!

