






# Quick Start Card

HF3471



- Clock time / Hora del reloj / Heure (horloge)
- Alarm time / Hora de la alarma / Heure (alarme)
- Alarm sounds / Sonidos de la alarma / Sons d'alarme
- Dusk simulation / Simulación del anochecer / Simulation de crépuscule
- Display brightness / Brillo de la pantalla / Luminosité de l'affichage



**4**

