

shave & care
HP 6337/6336



rechargeable cordless
wet/dry razors

instructions for use

If you need help, answers or service,
please call us at 1-800-243-7884.



PHILIPS

IMPORTANT SAFETY INSTRUCTIONS

When using an electric appliance, basic precautions should always be followed, including the following:

Read All Instructions Before Using This Appliance.

DANGER

To reduce the risk of electric shock:

1. Do not use an extension cord with this appliance. Plug charging base directly into electrical outlet.
2. Do not use charging base while bathing or in a shower.
3. Do not place or store charging base where it can fall or be pulled into a tub or sink. Do not place charging base in or drop into water or other liquid.
4. Except when charging, always unplug charging base from electrical outlet immediately after using.
5. Unplug razor from charging base before cleaning.
6. When discarding razor, remove razor from charging base and be certain razor is in OFF position. To remove rechargeable battery from razor, see enclosed sheet for instructions.

WARNING

To reduce the risk of burns, fire, electric shock, or injury to persons:

1. Close supervision is necessary when this razor is used by, on, or near children or the disabled.
2. Use this razor for its intended household use as described in this manual. Do not use attachments not recommended by Philips Electronics North America Corporation.

3. Never operate this razor/charging base if it has a damaged plug, if it is not working properly, if it has been dropped or damaged, or charging base has been dropped into water. Return the razor to an Authorized Norelco Service Location for examination and repair.
4. Never drop or insert any object into any opening.
5. Do not charge razor or plug in charging base outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
6. **Always check foil before use. Do not use this razor with a damaged or broken foil or trimmer, as injury may occur.**
7. Never store razor in direct sunlight or store in cassette at a temperature above 140°F.
8. Razor is water-safe and can be used in the bath or shower. Do not submerge in water for extended period of time.

SAVE THESE INSTRUCTIONS

IMPORTANT: YOUR RAZOR CONTAINS A RECHARGEABLE NICKEL-CADMIUM BATTERY. See enclosed sheet for instruction.

PRODUCT ASSISTANCE

For Assistance or the Authorized Norelco Service Location nearest you, call toll free:

1-800-243-7884

Authorized Service Location information is available 24 hours a day, 7 days a week.



HP 6020



HP 6100



HP 6101

CONGRATULATIONS

The Philips Shave & Care System combines a newly designed razor with a specially developed Caring Shaving Balm to provide an exceptionally smooth shave. The Caring Shaving Balm conditions and prepares the skin for a very close and comfortable shave. It improves gliding for a smoother, more effective shaving experience leaving your skin moisturized and silky smooth. The Opti-Shave System features 2 completely different types of shaving foils ... one for shaving legs close and smooth, the other for gently shaving underarms and sensitive areas (for model HP6337 only). And since the Razor (not charging base) is fully submersible, you can simply rinse it clean after shaving dry or in the bath. Enjoy the close, smooth results when you shave with your Shave & Care Razor ... only from Philips.

FEATURES (see chart inside cover)

- A. Leg Foil (model HP6337 only)
- B. Underarm & Sensitive Area Foil (model HP6337 only)
- C. Removable Shaving Head
- D. ON/OFF Switch
- E. Charging Base with Recharge Indicator Light
- F. Caring Shaving Balm
- G. Pop-Up Trimmer
- H. Total Body Dual-Function Foil
- I. Cleaning Brush
 - Fully Submersible
 - Rechargeable for cordless shaving
 - Protective Cap for shaving head
 - Travel/Storage Cassette

IMPORTANT


Give your new Razor a chance!

Like many new products, your Philips Shave & Care Razor may take a little getting used to. If you are using a rechargeable razor for the first time, or if you've been using a different brand, your skin may need time to adapt to the Opti-Shave or Total Body Shaving System. Give yourself a little time to practice and determine the best stroking motions and Caring Shaving Balm application for the best shave.

Use it exclusively for 3 to 4 weeks. If you alternate shaving or other hair removal methods during this adjustment period, it may make it more difficult to adapt to the Philips Shave & Care Shaving System.

Since your Shave & Care Razor features Caring Shaving Balm and either the Opti-Shave or Total Body Shaving System, you'll be able to customize hair removal for the area you are shaving. However, you may need to practice to get as close a shave as you expect. After this adjustment period, you'll find that you can remove hair without nicks or cuts for a close, smooth shave.


Philips Shave & Care Razor, with Caring Shaving Balm and the Opti-Shave or Total Body Shaving System ... the choice for close, smooth shaving results.



Total Body Dual-Function Foil



HP 6336




Leg Foil

Underarm and Sensitive Area Foil

Removable Shaving Head C

Pop-Up Trimmer G

ON/OFF Switch D



Cleaning Brush

Charging Base with Recharge Indicator Light

HP 6337

BEFORE USING YOUR RAZOR

- Before the razor is used for the first time, or when it has not been used for some period of time, it should be charged for a full 12 hours for 20 minutes of shaving time (Fig. 5). Razor models HP6337/6336 are designed for cordless shaving only.
- **Before each use, check foil for wear or damage. If foil shows signs of wear or damage, do not use razor as injury may occur. Do not use until foil has been replaced. If using HP6337, please make sure correct foil is on (i.e. arm or leg) for the area you are shaving.**
- Before shaving, apply a thin layer of Shaving Balm to the area you want to shave. You may also try rubbing the lotion in before starting to shave. You may need to try both methods to determine which gives you the best results. After shaving, any remaining Balm may be massaged into skin. The unique Caring Shaving Balm acts as both a lubricant and moisturizer.
- If you have longer hairs (last shave was 2 or more days ago) you should use the Pop-Up Trimmer simultaneously with the Shaving Foil.
- Or, you can use the Pop-Up Trimmer first, then immediately shave again using the Caring Shaving Balm and Shaving Foil.
- When shaving your legs, underarms or bikini line, it is not necessary to press hard to get a close shave. Pressing too hard may cause skin irritation, and razor will not function properly. In addition, do not use deodorant or alcohol based lotions immediately before or after shaving.
- Clean Razor regularly following MAINTENANCE instructions.
- Only Razor, **NOT** Charging Base, can be submerged in water, however do not submerge razor for extended periods of time.

SHAVING SYSTEM

OPTI-SHAVE SYSTEM

Your new HP6337 Shave & Care Razor features the Opti-Shave System. Each of the two shaving foils was specifically designed to meet your personal shaving needs, so you can choose the best foil for the area you are shaving. Use the blue-colored foil marked with the arm symbol for a comfortable shave without pinching or irritation of delicate underarm or sensitive bikini areas (Fig. 1). Or use the silver-colored foil marked with the leg symbol for a smooth comfortable shave on your legs (Fig. 2).

- You can easily interchange the different shaving heads and use the specific shaving head for the area you wish to shave (Fig. 3).

TOTAL BODY SYSTEM

Your new HP6336 Shave & Care Razor features the Total Body Shaving System with a dual-function foil specifically designed to shave sensitive areas and shave your legs close without nicks or cuts (Fig. 4).

IMPORTANT BATTERY DISPOSAL INFORMATION

WHEN DISCARDING YOUR RAZOR:

THIS PHILIPS RAZOR CONTAINS A NICKEL-CADMIUM RECHARGEABLE BATTERY WHICH MUST BE RECYCLED OR DISPOSED OF PROPERLY.

Refer to enclosed instruction sheet for directions on removing rechargeable battery.

CAUTION:

- Battery should be removed only when razor is to be discarded.
- Remove Razor from Charging Base and unplug Charging Base from outlet before dismantling.
- All servicing should be performed by an Authorized Norelco Service Location only.

PHILIPS

60 - DAY MONEY-BACK GUARANTEE

If you are not fully satisfied with your Philips Shave & Care Razor, Philips will refund you the full purchase price.

The Razor must be shipped prepaid by insured mail, insurance prepaid, and have the sales receipt, indicating purchase price and the date of purchase, enclosed. The Razor must be postmarked no later than 60 days after the date of purchase. Philips reserves the right to verify the purchase price of the Razor and limit refunds not to exceed suggested retail price.

Send dated sales receipt, your complete name and address as indicated below, and the Razor, prepaid to:

**Norelco Consumer Products Company
A Division of
Philips Electronics North America Corporation
P.O. Box 1116
Skokie, IL 60076**

Please allow 4-6 weeks for delivery of check. (Please Print)

Name _____

Address _____

City _____

State _____ Zip _____

Telephone No. (_____) _____
AREA CODE

REASON FOR RETURNING _____

MAINTENANCE INSTRUCTIONS (cont.)

4. Be sure all parts are dry before reassembling. Do not use a cloth or towel to dry Shaving Foil, allow to air dry.
5. Replace Shaving Head by gently pressing back into position on Razor body. Hold Shaving Head by plastic housing only.

REPLACEMENT ACCESSORIES

REPLACEMENT FOILS

To maintain the best shaving results, it is recommended that you replace the Shaving Foil every 5-6 months if you use your Razor once a week or more. If the foil becomes worn or damaged, replace it immediately. When the Shaving Foil does need replacing, specify only Philips Shave & Care Total Body Replacement Foil, model HP6100, for use with Shave & Care Razor models HP6336/6330 or Philips Shave & Care Opti-Shave Replacement Foils, model HP6101, for use with Shave & Care Razor models HP6337/6331.

CARING SHAVING BALM

The Caring Shaving Balm may also be purchased separately, model HP6020.

Philips Replacement Accessories may be purchased at a store near you, an Authorized Norelco Service Location, or by using the handy order form enclosed. For assistance, please call 1-800-243-7884.

TO CHARGE/RECHARGE RAZOR

- Charge Razor only in Charging Base provided.
 - Be certain hand and Razor are dry before charging.
 - Recharge at temperatures between 40°F and 95°F. Charging at lower or higher temperatures adversely affects lifetime of battery.
1. Be certain Razor is OFF by pressing ON/OFF Button in center of Razor.
 2. Plug Charging Base directly into 120V AC electrical outlet.
 3. Place Razor in Charging Base.
 4. Recharge Indicator Light on base will light to indicate Razor is (re)charging (Fig. 5).
 5. Razor may be continuously charged in its base (with base connected to electrical outlet) for a maximum of 4 weeks. At the end of 4 weeks, you must allow the battery to totally deplete charge before recharging.
 - To deplete charge, shave in usual manner; however, do not recharge Razor in-between shaves. Continue to use Razor until battery is totally depleted.
 6. You may then keep Razor continuously charging for another 4 week period before you must once again allow Razor to totally deplete charge.

IMPORTANT: Before placing Razor in base, be certain Razor is OFF. With Razor in the base, the recharge light will light whether the Razor is OFF or ON, **however, your Razor will only recharge if Razor is in the OFF position.**

CARING SHAVING BALM

The Caring Shaving Balm was specially developed to be used together with your Shave & Care Razor to obtain perfectly smooth shaving results outside the bath or shower. The Balm prepares and conditions your skin for a close shave, leaving your skin soft and moisturized. It also ensures that the razor glides smoothly over your skin to make your shaving experience pleasant and comfortable. The Caring Shaving Balm has optimized shaving outside the shower.


HOW TO USE

1. Before shaving, apply a thin layer of Shaving Balm to the area you want to shave. You may also try rubbing the lotion in before starting to shave. You may need to try both methods to determine which gives you the best results.
 - Push up white lock on bottle (Fig. 6).
 - Gently squeeze bottle and apply Balm, against the direction of hair growth, to area to be shaved (Fig. 7).
2. You may apply additional Shaving Balm as needed while shaving.
3. Any Shaving Balm left on skin after shaving can be massaged into your skin as a moisturizer.


FOR WET USE

1. Your Shave & Care Razor and the Balm can also be used in the shower or bath.

SHAVING LEGS

- If you have longer hairs (last shave was 2 or more days ago), you should use the Pop-Up Trimmer simultaneously with the Shaving Foil.
 - Or, you can use the Pop-Up Trimmer first, then immediately shave again using the Caring Shaving Balm and Shaving Foil.
1. Prepare legs by applying a thin layer of Caring Shaving Balm onto the skin. You may also try rubbing the lotion in before starting to shave. You may need to try both methods to determine which gives you the best results.
 2. For Opti-Shave Razor, model HP6337, apply the leg foil  to Razor.
 3. Press the ON/OFF Button in center of Razor to turn Razor ON.
 4. Hold Razor so that Shaving Head is in full contact with your skin. Shave with smooth, steady strokes, against the direction of hair growth (Fig. 8). Apply additional Shaving Balm as necessary.
 - Pressing too hard may cause skin irritation.
 - Practice is best for optimal results.
 5. To turn Razor OFF, depress ON/OFF Button in center of Razor.
 6. Massage any remaining Shaving Balm into skin as a moisturizer.

SHAVING UNDERARMS

1. Prepare underarms and other sensitive areas for wet or dry shaving by applying a thin layer of Caring Shaving Balm onto the skin. You may also try rubbing the lotion in before starting to shave. You may need to try both methods to determine which gives you the best results.
- Do not use deodorant or alcohol based lotions immediately before or after shaving. For sensitive skin, you may wish to apply talcum powder after shaving.
2. For Opti-Shave Razor, model HP6337, apply the underarm foil  to Razor.
- Never clean, remove, or replace Shaving Foil while Razor is ON.
3. Turn Razor ON by pressing the ON/OFF Button in center of Razor.
4. Lift your arm until skin under arm stretches slightly. For other sensitive areas, stretch skin taut with your fingers.
5. Hold Razor so Shaving Head is in full contact with the skin. Shave with gentle strokes, using light pressure. Pressing too hard may cause skin irritation, and Razor will not function properly.
6. Turn Razor OFF by pressing the ON/OFF Button in center of Razor.

POP-UP TRIMMER

- If you have longer hairs (last shave was 2 or more days ago), you should use the Pop-Up Trimmer simultaneously with the Shaving Foil.
 - Or, you can use the Pop-Up Trimmer first, then immediately shave again using the Caring Shaving Balm and Shaving Foil.
1. Push up Trimmer (Fig. 9).
 2. Turn Razor ON by pressing the ON/OFF Button in center of Razor.
 3. Hold Razor so Trimmer edge is in contact with skin. Shave with gentle strokes, using light pressure, against the direction of hair growth (Fig. 10).
 4. Press Trimmer back down when finished. Turn Razor OFF by pressing ON/OFF Button in center of Razor.

MAINTENANCE INSTRUCTIONS

IMPORTANT

- It is recommended that you replace shaving foil every 5-6 months if you use your Razor once a week or more (see REPLACEMENT section).
 - Turn Razor OFF and remove Charging Base from electrical outlet before cleaning.
 - Never clean, remove, or replace Shaving Foil while Razor is ON.
 - Do not apply pressure or touch Shaving Foil with hard objects as this may dent or damage the foil. If damage occurs, replace foil.
 - Check foil regularly.
 - **Never use a razor with a damaged or broken foil or without the foil.**
 - For best shaving performance, twice a year lightly oil Shaving Head by spreading a drop of mineral oil over the foil and trimmer (Fig. 11). If this does not improve the performance of your Razor, it may be time to change the foil.
 - Never immerse Charging Base in water or other liquid. You may clean by wiping with a damp cloth.
1. After using your Shave & Care Razor with the Shaving Balm, clean the Razor by rinsing under lukewarm water (Fig. 12).
 2. Remove the shaving head to clean the cutter with water using the brush (Fig. 13). **DO NOT** apply pressure to Shaving Foil. Hold Shaving Head by plastic housing only.
- NOTE:** Avoid using brush on Shaving Foil as this may cause damage.
3. **DO NOT** submerge Razor in water for a long period of time.

FULL TWO YEAR WARRANTY

Philips Electronics North America Corporation warrants each new Philips Product, Model HP6337 or HP6336 (except foil(s) and trimmer), against defects in materials or workmanship for a period of two years from the date of purchase, and agrees to repair or replace any defective product without charge.

IMPORTANT: This warranty does not cover damage resulting from accident, misuse or abuse, lack of reasonable care, the affixing of any attachment not provided with the product or loss of parts or subjecting the product to any but the specified voltage.* Use of unauthorized replacement parts will void this warranty.

PHILIPS ELECTRONICS NORTH AMERICA CORPORATION WILL NOT PAY FOR WARRANTY SERVICE PERFORMED BY A NON-AUTHORIZED REPAIR SERVICE AND WILL NOT REIMBURSE THE CONSUMER FOR DAMAGE RESULTING FROM WARRANTY SERVICE PERFORMED BY A NON-AUTHORIZED REPAIR SERVICE.

NO RESPONSIBILITY IS ASSUMED FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES.

In order to obtain warranty service, simply take or ship the product postage prepaid to the nearest Authorized Norelco Service Location. It is suggested that for your protection you return shipments of product by insured mail, insurance prepaid. Damage occurring during shipment is not covered by this warranty.

NOTE: No other warranty, written or oral, is authorized by Philips Electronics North America Corporation. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion and limitations may not apply to you.

* Read enclosed instructions carefully.

Manufactured for:
Norelco Consumer Products Company
A Division of Philips Electronics North America Corporation
1010 Washington Blvd.
Stamford, CT 06912-0015

**RAZOR MADE IN AUSTRIA.
CHARGING BASE MADE IN CHINA.**



This symbol on the product's nameplate means it is listed by Underwriter's Laboratories, Inc.

PHILIPS and Philips Shield are Registered Trademarks of Philips Electronics N.V.

Shave & Care and Design and Caring Shaving are Trademarks of Philips Electronics N.V.

Opti-Shave and Total Body are Trademarks of Philips Electronics North America Corporation.

© 1998 Philips Electronics North America Corporation. All Rights Reserved.