




## Action Clean Razor Head Cleaner

HQ100

### Instructions for use



If you need help, answers or  
service, please call us at  
1-800-243-3050



**PHILIPS**

# IMPORTANT SAFEGUARDS

When using your Action Clean Razor Head Cleaner, basic safety precautions should always be followed, including the following:

### READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE.

1. Close supervision is necessary for any appliance being used by or near children or the disabled.
2. Use this Razor Head Cleaner for its intended household use as described in this manual. Do not use attachments or other cleaning solutions not recommended by Philips Electronics North America Corporation.
3. Never place this appliance on a soft surface, such as a bed or a sofa, where solution may spill. Do not tilt the unit.
4. Do not overfill chamber with liquid.
5. Do not rinse with water.
6. Never operate this unit if it is not working properly or if it has been dropped or damaged. Return Razor Head Cleaner to an Authorized Norelco Service Location for examination and repair.

## SAVE THESE INSTRUCTIONS

### Features

#### • Three Head Holder




#### • Two Head Holder



#### • Top

#### • Action Cleaning Chamber

#### • Base



### For Assistance

- For assistance or the Authorized Norelco Service Location nearest you, call toll free:  
1-800-243-3050




Authorized Service Location information is available 24 hours a day, 7 days a week.

### Important




Before using your new Action Clean Razor Head Cleaner, it is important to follow the instructions below:

- You do not need to remove cutters and combs from Razor Head Assembly to clean them in the Action Clean Razor Head Cleaner. The whole assembly piece can be cleaned as a complete unit. If you do remove cutters and combs be careful not to interchange them as they are matched sets. **If you do interchange cutters and combs, the shaving performance may be adversely affected for the next few shaves until the blades reseal themselves.**





## How to use your Action Clean Razor Head Cleaner



1. Turn the top of the Action Clean unit counter-clockwise and pull top from Cleaning Chamber. (Fig. 1)
2. Remove the filter unit from the Cleaning Chamber. (Fig. 2)
3. Depending on your razor model, select either the two or three head holder. Place it on top of filter unit, ensuring that the three notches of the holder fit in the slots of the filter unit. Replace the filter unit into the Action Cleaning Chamber, making sure that the filter unit clicks down into place. (Fig. 3)



4. Empty the contents of the Action Cleaning Solution into the Cleaning Chamber. (Fig. 4)
5. Place Razor Head Assembly from razor (with heads in place) onto Head Holder. (Fig.5)
6. Replace top on Cleaning Chamber, making sure that it locks into place by turning clockwise until it "clicks" into place. (Fig. 6)
7. Clean heads by pumping the top on the Action Cleaning Chamber for about 30 seconds. (Fig.7)



8. When finished, remove top from Action Cleaning Chamber and remove Razor Head Assembly. (Fig. 8) Place Razor Head Assembly on a paper towel to air dry. Make sure Razor Head Assembly is completely dry before placing it back on your razor.
9. **DO NOT RINSE WITH WATER.**
10. After each cleaning, spread one drop of lubricating oil from the tube included, Norelco Razor Lubricant Model AL80, or one drop of mineral oil over each razor head using your finger.
11. For consistently close and comfortable shaves, you should clean your razor heads every 4 - 6 weeks or when the display on your razor tells you to do so. If your shave is still not close enough, you may need new replacement heads.
12. Change the filter and Action Clean Cleaning Solution at least once a year. (Fig. 9,10,11)
13. Use only Norelco Action Clean Cleaning Solution with filter, model HQ101, with this unit.

## Replacement Accessories

Replacement Accessories may be purchased at an Authorized Norelco Service Location or by using the handy order form enclosed.

### Razor Head Cleaning Solution and Razor Lubricant:

Norelco Action Clean Cleaning Solution, Model HQ101, for use with Action Clean Razor Head Cleaner, model HQ100, only. Not for use with Norelco RAZORMATE Electrosonic Razor Head Cleaner, model ERC100. It is recommended that you change the filter and Action Clean Cleaning Solution at least once a year.

Norelco Razor Lubricant, Model AL80.

### Replacement Heads:

The self-sharpening rotary blades in your Norelco Razor are precision-made to give closer shaves. When they finally do need replacing, specify only Norelco brand replacement cutters and combs. It is recommended that you replace your razor heads once a year.

**DO NOT USE** shaver sharpeners as this will damage your blades and lifters and will adversely affect the shaving performance.

### FULL ONE YEAR WARRANTY

Philips Electronics North America Corporation warrants each new Norelco Product, Model HQ100, against defects in materials or workmanship for a period of one year from the date of purchase, and agrees to repair or replace any defective product without charge.

**IMPORTANT:** This warranty does not cover damage resulting from accident, misuse or abuse, lack of reasonable care, the affixing of any attachment not provided with the product or loss of parts or subjecting the product to any but the specified accessories.\* Use of unauthorized replacement parts will void this warranty.

**PHILIPS ELECTRONICS NORTH AMERICA CORPORATION WILL NOT PAY FOR WARRANTY SERVICE PERFORMED BY A NON-AUTHORIZED REPAIR SERVICE AND WILL NOT REIMBURSE THE CONSUMER FOR DAMAGE RESULTING FROM WARRANTY SERVICE PERFORMED BY A NON-AUTHORIZED REPAIR SERVICE. NO RESPONSIBILITY IS ASSUMED FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES.**

In order to obtain warranty service, simply take or ship the product postage prepaid to the nearest Authorized Norelco Service Location. It is suggested that for your protection you return shipments of product by insured mail, insurance prepaid. Damage occurring during shipment is not covered by this warranty.

**NOTE:** No other warranty, written or oral, is authorized by Philips Electronics North America Corporation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion and limitations may not apply to you.

\* Read enclosed instructions carefully.

Manufactured for:

Norelco Consumer Products Company  
A Division of Philips Electronics North America Corporation  
1010 Washington Blvd.  
Stamford, CT 06912-0015

**MADE IN HOLLAND.**

Norelco is a Registered Trademark of  
Philips Electronics North America Corporation.

Action Clean is a Trademark of Philips Electronics N.V.

PHILIPS and Philips Shield are Registered Trademarks of  
Philips Electronics N.V.

© 1997 Philips Electronics North America Corporation,  
All Rights Reserved.

