

PHILIPS

citrus juicer

instant flow system



quiet & smooth operation

HR2752



PHILIPS

PHILIPS

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

Read all instructions before using.

1. To protect against electrical shock, do not immerse cord, plug, or citrus juicer in water or other liquid.
2. Close supervision is necessary when any appliance is used by or near children.
3. Unplug from outlet when not in use, before putting on or taking off parts and before cleaning. Remove plug by gripping plug body and pull from outlet. Never yank or twist cord to unplug.
4. Avoid contacting moving parts.
5. Do not operate this appliance with a damaged cord or plug, or after the appliance malfunctions, or has been damaged in any manner; return the citrus juicer to the retail location where it was purchased for examination, repair, or adjustment.
6. Use this appliance only for its intended use as described in this manual. Do not use accessory attachments not recommended by Philips Electronics North America Corporation as they may cause fire, electric shock or injury.
7. Do not use outdoors or operate where oxygen is being administered or in the presence of explosive and/or flammable fumes.
8. Do not let cord hang over edge of table or counter, or touch hot surfaces.

9. This appliance is intended for household use **ONLY**; it is not for commercial or industrial use.
10. Any service of the citrus juicer should be performed by the retail location where it was purchased.
11. To disconnect citrus juicer, wait until motor stops, then remove plug from electrical outlet.
12. Do not operate unattended. Make sure the motor stops completely before disassembling. Unplug after each use.

SAVE THESE INSTRUCTIONS

SPECIAL POLARIZED PLUG INSTRUCTIONS

This Philips Citrus Juicer has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock:


- Plug will fit into polarized outlet only one way.
- If plug does not properly fit outlet at first, reverse it.
- If plug still does not fit, contact a qualified electrician.

DO NOT ATTEMPT TO DEFEAT THIS SAFETY FEATURE

Table of Contents


Features	2
Preparing the Citrus Juicer for Use	3
How to Use the Citrus Juicer	3-4
Cleaning	4
For Assistance	4
Warranty	Back Cover

Features




- Protective Dust Cover
- Ultra Low Noise Level

Preparing the Citrus Juicer for Use




- 1 Plug cord into any 120V AC electrical outlet.




- 2 If necessary, wind excess cord around cord wrap under Citrus Juicer base and exit cord through the opening at the back of the appliance.
- 3 Place the appliance on a firm, level surface outside the reach of children.


How to Use the Citrus Juicer




- 1 Remove the protective cover.



- 2 Put a glass under spout.
- 3 Flip the spout down towards the glass to open spout. The instant flow system guides juice directly into glass or container.




- 4 Switch the appliance on by pressing the halved fruit firmly onto the cone. The juice will be extracted quietly and quickly.




- 5** After you have finished, flip the spout up to prevent dripping and spilling of juice.

Always clean the appliance immediately after use (see 'Cleaning').


Cleaning



- 1** Unplug cord from electrical outlet.
- 2** Remove the cone, sieve and sieve holder from the appliance.



- 3** Flip the spout down fully in order to clean it properly. The spout cannot be detached from the appliance.



- 4** Clean the cone, sieve and sieve holder using warm soapy water. Dry all parts.

Do not clean these parts in a dishwasher.

- 5** Clean the motor unit using a moist cloth. Never immerse the motor unit in water or rinse it under the tap.

For assistance

For assistance call toll free:

1-800-243-7884
or visit our website: www.philipsonline.com.

FULL ONE YEAR WARRANTY

Philips Electronics North America Corporation warrants each new Philips product, model HR2752 (except cord), against defects in materials or workmanship for a period of one year from the date of purchase.

IMPORTANT: This warranty does not cover damage resulting from accident, misuse or abuse, lack of reasonable care, the affixing of any attachment not provided with the product or loss of parts or subjecting the product to any but the specified voltage.*

**PHILIPS ELECTRONICS NORTH AMERICA CORPORATION
WILL NOT PAY FOR UNAUTHORIZED SERVICE OF ANY
TYPE.**

**NO RESPONSIBILITY IS ASSUMED FOR ANY SPECIAL,
INCIDENTAL OR CONSEQUENTIAL DAMAGES.**

In order to address warranty issues, simply take or ship the product back to the retail location where it was purchased.

* Read enclosed instructions carefully.

Manufactured for:
Norelco Consumer Products Company
A Division of Philips Electronics North America Corporation
1010 Washington Blvd., Stamford, CT 06912-0015

For Assistance call 1-800-243-7884

MADE IN SLOVENIA.



This symbol on the product's nameplate means
it is listed by Underwriters' Laboratories, Inc.

PHILIPS and Philips Shield are Registered Trademarks of Koninklijke
Philips Electronics N.V.

© 2000 Philips Electronics North America Corporation.
All Rights Reserved.

HR2752