

PHILIPS

Food processor
bowl

3.4 l

white handle

HR3921



Indispensable part of your food processor

Find matching products on the specifications tab

This bowl, part of your Philips food processor, allows you to make extra large amounts of, for example, soup or dough in one go. An additional one might be handy: when one's in the dishwasher you can use the other!

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

Specifications

Replaceable part

Fits product types: HR7774/30

