

Philips Software Upgrade for Blu-Ray players and Home Theaters

Introduction

Philips offers software upgrade capability for your Blu-Ray. After you have completed the software upgrade, your Blu-Ray will typically perform better. What improvements are made depends on the software you are using as well as the software your Blu-Ray contained before the upgrade. You can execute the software upgrade procedure yourself. Be aware that the content of this document is addressing technical and software skilled users.

For the procedure you will require:

- > A personal computer with web browsing capability
- > An archive utility that supports the ZIP-format (e.g. WinZip for windows or Stuffit for Mac OS).
- > A CD burner on your computer.

Check the current version of software:

1. In the "Software Update" menu, use the cursor up/down keys on your remote to select "Current Version", then press OK.
2. Press OK or Return to exit.

If the version of software on the website is greater than the version on your player, proceed with the update. If the version is the same, do not update.

Update procedure:

1. Extract the .bin file from the zip file downloaded from this site.
2. Burn the *.bin file to the root directory of a blank CD. Make sure the CD burner is set to finalize the CD.
3. In the "Software Update" menu, use the cursor up/down keys on the remote to select "Disc Update", then OK.
4. Use the cursor up/down button to select "Yes", then press OK.
5. Insert the Disc.
6. After the disc has loaded, a confirmation message will appear. Select "Yes" and press OK to start uploading.
7. After the disc update is finished, the unit will restart and eject the disc.

Software History

SW Version

Problem resolved

1.006

- Bedtime Stories reboot issue
- Get and set menu language features