






1



2



VOICE TRACER

LFH0615

LFH0625

LFH0635

LFH0645

LFH0648

LFH0655



Quick start guide


Register your product and get support at www.philips.com/welcome

© 2011 Royal Philips Electronics. All rights reserved.

Specifications are subject to change without notice.

Trademarks are the property of Royal Philips Electronics or their respective owners.

Document version 2.0, 2011/01/11



LFH0615

LFH0625

LFH0635

LFH0645


LFH0648

LFH0655


LFH0635

LFH0645

LFH0648




LFH0655




PHILIPS




1




2



3



4



1s OFF >> ON

1s ON >> OFF

.mp3 → **A** **B** **C** **D**



1s OFF >> ON

.mp3 → **A** **B** **C** **D**



MENU

MODE SLP LP SP HQ SHQ PCM

	MI C	VA	CL40 ICE	bEEP	AutoOFF	FORMAT	INFO	L 16Hz	SPLI t	d IN IDE	CHARGE	EQUALI
HI	LO	ON	OFF	ON	OFF	NO	YES	100	20 10	09/25	ON	OFF
LFH0615	LFH0625	LFH0635	LFH0645	LFH0648	LFH0655	NO	YES	ON	OFF	30	60	OFF

SLP LP SP HQ SHQ PCM

MI C VA CL40 ICE bEEP AutoOFF FORMAT INFO L 16Hz SPLI t d IN IDE CHARGE EQUALI

HI LO ON OFF ON OFF NO YES 100 20 10 09/25 ON OFF 30 60 ON OFF

OFF P OP JA 22 CL 15