

Software/driver information

Firmware version: **V1.4 2010.01.07**

Benefits of the Upgrade

Solved the Station shifted problem.

How can I review the firmware version in my device?

1. Press the DISC key on the remote control to select the disc source.
2. Press the **SYSTEM MENU** key on the remote control and then go to the **Preference** page to select **Version info**. The current firmware version will appear.

How can I upgrade the firmware in my device?

Important: DO NOT turn off the device during the firmware upgrade.

1. Click the **Download** button to download the firmware package on your computer.
2. Unzip the firmware package, you will get 2 files.
3. Burn the both files on an optical disc. **Note: DO NOT rename either of the 2 files to avoid upgrade failure.**
4. Place the burned disc on the disc tray and then close the tray.
5. Press the **DISC** key on the remote control to select the disc source, the device will recognize the disc and ask you to start the firmware upgrade.
6. Use the **left / right** keys on the remote control to select **OK**. The firmware upgrade will start.
7. The disc tray will open when the upgrade is completed. **Wait until the tray AUTO closes** and the device will auto restart.

Enjoy your device now!

Upgrade History

Version: N/A.