

## Software/driver information

Firmware version: **Ver1.3SND**

### Benefits of the Upgrade

- Improve the product performance.

### How can I review the firmware version on my device?

1. Press the **SYSTEM** button on the remote control.
2. Select **Preference Setup -> Version Info**. You will find the firmware version number here.

### How can I upgrade the firmware in my player?

**Important: DO NOT turn off the device or disconnect the USB device from the device during the firmware upgrade.**

1. Click the Download button to download the firmware on your computer. You will get a Zip archive.
2. Unzip your downloaded Zip archive to get the firmware file. **Attention: Do not rename the file to avoid firmware upgrade failure.**
3. Copy the file into a USB device. Make sure the USB device can be recognized by the device.
4. Switch on the device to select the **USB** source.
5. Connect the USB device with the firmware to the device until you see a message **NO DEVICE** on the display of the device. The firmware upgrade will auto start.
6. It will take about 2 minutes to complete the firmware upgrade. The TV will be black screen, and then **PHILIPS** will appear, which means the firmware upgrade is completed.
7. Press the **SYSTEM** button on the remote control.
8. Select **Preference Setup -> Default -> Reset**. You will find the upgraded firmware version number here.

**Enjoy the new function on your system now!**

### Upgrade History

Version: N/A.