

Quick Start Guide








Step A Setup

Step B Enjoy

What's in the Box?

You should find these items upon opening the box.



PHILIPS


Step A Setup

Connection

- 1 For radio reception, connect the supplied AM antenna to the **AM aerial** terminal.
- 2 Connect the speaker wires to the **SPEAKERS** terminals.
- 3 Connect the power cord of the system to the AC power outlet.


Tip

It is unnecessary to connect the FM pigtail antenna since it is fixed to the main unit.



Setting the clock


- 1 In standby mode, press and hold **DISPLAY/CLOCK** (**CLOCK/MENU** on the remote control) for 2 seconds. The clock digits for the hours flash.
- 2 Press **TUNING** **◀◀ / ▶▶** to set the hours.
- 3 Press **DISPLAY/CLOCK** again. The clock digits for the minutes flash.
- 4 Press **TUNING** **◀◀ / ▶▶** to set the minutes.
- 5 Press **DISPLAY/CLOCK** to confirm the time.



Step B *Enjoy*

Playing a disc

- 1 Select **CD** source.
- 2 Press **OPEN•CLOSE** on the top of the system to open the CD door.
- 3 Insert a disc with the printed side facing up and press down on **OPEN•CLOSE** to close the CD door.
- 4 Press **▶ ||** to start playback.
- 5 Press **■** to stop playback.



Programming and Listening to radio stations

- 1 Select **TUNER** source.
- 2 Press **PROGRAM** on the set for more than 2 seconds to program all available stations in order of waveband.
- 3 Press **ALBUM/PRESET ▼ ▲** until the desired preset station is displayed.

Tip

Detailed playback features and additional functions are described in the accompanied owner's manual.


Notes for the remote control:

- First, select the source you wish to control by pressing one of the source select keys on the remote control (CD or TUNER, for example).
- Then select the desired function (▶||, ◀, ▶ for example).

Step B *Enjoy*

Playing iPod using the dock

- 1 Select the correct dock adaptor supplied, then snap the adaptor into the correct dock connector (iPod) to provide a snug fit for the player.
 - The indication on the adaptor's back fits specific iPod player.
- 2 Correctly place your player in the correct dock connector:
- 3 Connect the cables of the dock to **DOCKING IN** jacks on the main set correspondingly.
- 4 Press **SOURCE** repeatedly or **iPod** to select iPod source.
 - The connected player will play automatically.
 - The iPod battery will be charged in either normal standby mode or power-on mode. The charging will not be available in the Eco power standby mode.



Tip

Refer to the user manual supplied for detailed descriptions of "Compatible portable player", "Selecting the correct dock adaptor", "Installing the dock adaptor", and the important notes for dock operation.



© Royal Philips Electronics N.V. 2007
All rights reserved.

<http://www.philips.com>

PDCC-JH-0720 **GB**

