

Software/driver information

Firmware version: **M302 V12 JUL 01 09**

Benefits of the Upgrade

To solve the problem that RDS does not work properly.

How can I Review the firmware version in my device?

1. Simultaneously press the PLAY and STOP buttons on the device and then connect the device to the AC power. You will find the firmware information on the display of the device.

How do I upgrade the firmware in my device?

1. Click the **Download** button to download the firmware file on your PC.
2. Extract the firmware file from the downloaded file to your USB stick.

Note: 1. The extracted files should not be placed in a folder on the disc but just in the top level directory (root).

2. DO NOT rename the extracted firmware file.

3. Turn on the device and then select USB source.
4. Connect the USB stick with the firmware to the device. The firmware upgrade will auto start.

Remark: when upgrading, at the first you can hear "Di Di" sound five times from speaker, it means the firmware begins to upgrade, after about 30 seconds, you can hear consecutive "Di Di" sound, it means firmware upgrade is completed. Now we can unplug USB and power cord.

5. **Unplug power cord** and plug it again to turn on the device.

Upgrade History

Version: update CD software to Version 11 to solve the wrong display when pressing **DSC** or **LOUD** button on RC.