Quick Start Guide







PHILIPS

What's in the Box?

You should find these items upon opening the box.









Set clock

- In the standby mode, press and hold CLOCK to activate the clock setting mode.
- → The hour digits are displayed and begin to blink.
- → If the hour digits are not displayed, press and hold \oplus for more than 2 seconds to switch to standby mode, then repeat step 1.


2

- Press + VOL to set the hour.
- The minute digits are displayed and begin to blink.



4

Press + VOL - to set the minute.







Play from disc

Press CD to select the CD source.
Press OPEN/CLOSE.
The disc tray opens.
Place a disc onto the tray and press OPEN/CLOSE.
Ensure that the label is facing upwards.

4

Playback will start automatically.

If play does not start, press I</>


 If play does not start, press I
 II.

Play from USB





Program and tune to radio stations



Тір

Detailed playback features and additional functions are described in the accompany owner's manual.



© Royal Philips Electronics N.V. 2009 All rights reserved.

http://www.philips.com

