



## English

# 1 Important

## Safety and Warranty

Before using your set:  
Check out details inside this booklet

# PHILIPS



### Safety

Only use attachments/accessories specified by the manufacturer. The product shall not be exposed to dripping or splashing. Do not place any sources of danger on the product (e.g. liquid filled objects, lighted candles). Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like. Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type. Where the plug of the Direct Plug-in Adapter is used as the disconnect device, the disconnect device shall remain readily operable.

#### Warning

- Never remove the casing of this apparatus.
- Never lubricate any part of this apparatus.
- Never place this apparatus on other electrical equipment.
- Keep this apparatus away from direct sunlight, naked flames or heat.
- Ensure that you always have easy access to the power cord, plug or adaptor to disconnect the apparatus from the power.

### Compliance

#### Note

- The type plate is located on the bottom of the product.

### Care of the environment

#### Environmental information

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet.)

Your system consists of materials which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, and old equipment.

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

Please inform yourself about the local separate collection system for electrical and electronic products.



Specifications are subject to change without notice  
© 2013 Koninklijke Philips Electronics N.V.  
All rights reserved.

P8\_P9\_98\_JA\_SafetySheet\_V1.0  
wk1250.4

Please act according to your local rules and do not dispose of your old products with your normal household waste. Correct disposal of your old product helps to prevent potential negative consequences for the environment and human health. Please inform yourself about the local rules on separate collection of batteries because correct disposal helps to prevent negative consequences for the environmental and human health.

Always bring your product to a professional to remove the built-in battery.

## Notice

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Philips is under license.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V or their respective owners. Philips reserves the right to change products at any time without being obliged to adjust earlier supplies accordingly.

## 日本語

### 1 重要

#### 安全上の注意

製造元によって指定されている付属品/アクセサリー以外は使用しないでください。

製品に水滴がかかったり水跳ねしたりしないようにしてください。

危険性のある物体を製品の上に置かないでください(液体の入った物、火が点いたキャンドルなど)。

電池(バッテリーパック、または装着されている電池)を、日光や炎など過度の熱にさらさないでください。

間違った方法でバッテリーを装着すると、破裂の危険があります。バッテリーを入れ換える場合は、同じ型のバッテリー、または同等のバッテリーのみを使用してください。

ダイレクトプラグインアダプタのプラグを断路装置として使用している場合、断路装置はすぐに動作可能な状態にしておいてください。

#### 警告

- 機器のケーシングは絶対に取り外さないでください。
- 機器のどの部分にも絶対に潤滑剤を塗らないでください。
- 機器は他の電子機器の上に絶対に置かないでください。
- 機器は直射日光、裸火、熱から離して置いてください。
- 機器を電源から切断するために、電源コード、プラグ、アダプターに手が届きやすいようにしておいてください。

#### 適合性

#### 注

- タイププレートは製品の底面にあります。

## 環境への配慮

#### 環境に関する情報

本製品の梱包には不必要な梱包材を使用していません。当社では、梱包材をダンボール(箱)、発泡スチロール(緩衝材)、ポリエチレン(袋、保護発泡シート)の3種類の素材ごとに簡単に分類できるように、努力を払っています。

システムは、リサイクル可能な素材で製造されているため、専門業者による分解の後に再利用できるようになっています。梱包材や古くなった機器の廃棄方法については、お住まいの地域の廃棄手順に従ってください。

ご使用の機器(プレイヤー)は、純度の高い素材と材質を使用してデザインおよび製造されたもので、リサイクルと再利用が可能です。

お住まいの地域の電気電子製品分別回収システムについて情報を入手してください。

製品を廃棄する際は地域の規則に従ってください。一般の家庭ごみと一緒に捨てないでください。適切な分別回収は、環境や人体に及ぼす影響の低減につながります。お住まいの地域での電池の分別収集ルールを確認してください。適切な分別回収は、環境や人体に及ぼす影響の低減につながります。

内蔵バッテリーを取り外す場合は、必ず専門業者に製品を持ち込んで依頼してください。



#### 通知

Bluetooth® ワードマークおよびロゴは、Bluetooth SIG, Inc. の所有物であり、Philips はライセンスに基づきこのマークを使用しています。

仕様は予告なく変更されることがあります。商標は、Koninklijke Philips Electronics N.V または各所有者の所有物です。Philips はいつでも予告なく製品に変更を加える権利を有します。その際、既に提供済みの物をその変更に従って調整する義務は負いません。