

# PHILIPS

## Normal Skin Cleansing Brush

Replace every 3 months

For daily use

For normal to oily skin

Easy to replace



SC5990/00



## Replacement Brush Head for Normal Skin

For clean and soft skin

Replacement Brush Head for Normal Skin care. For use only with Philips VisaPure Essential facial cleansing brush.

### **Developed for normal to oily skin types**

- 17000 soft bristles for deep skin cleansing
- Perfectly designed for optimal hygiene

### **Easy to maneuver to focus on hard-to-reach areas**

- Perfect size and shape to easily reach all face areas

### **Easy to replace**

- Click-on brush head; easy to put on and take off
- For optimal results, replace the brush every three months



[asimpleswitch.com](http://asimpleswitch.com)

# Highlights

## Size and shape

Perfect size and shape to easily reach all face areas

## Brush Bristles

17000 soft filaments gently massage and deeply cleanse the skin like 17000 fingers.

## Click-on brush head

Simply click on or click off the brush head. Easy to fit, our brush heads are compatible across all Visapure models.

## Long operating time

For optimal results, replace the brush every three months

## Designed for optimal hygiene

The silky soft bristle material of all our VisaPure brush heads is a specially chosen, delicate nylon. This helps to ensure the brush heads are super easy to clean and keep fresh.

# Specifications

## Benefits

**Type of skin:** For all skin types

## Ease of use

**Compatible with:** Philips VisaPure Essential

**Replacement:** Easy snap-on brush head

**Recommended replacement:** Every 3 months



[asimpleswitch.com](http://asimpleswitch.com)

## Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.