

PHILIPS

Sensitive Skin Cleansing Brush

Replace every 3 months

For daily use

Normal to sensitive skin

Easy to replace



SC5991/00



Replacement Brush Head for Sensitive Skin

For clean and soft skin

Replacement Brush Head specifically designed for Sensitive Skin care. For use only with Philips VisaPure Essential facial cleansing brush.

Easy to maneuver to focus on hard-to-reach areas

- Perfect size and shape to easily reach all face areas

Easy to replace

- For optimal results, replace the brush every three months
- Click-on brush head; easy to put on and take off

Developed for sensitive skin types

- Ultra soft bristles for a more effective, gentle cleaning
- Perfectly designed for optimal hygiene



asimpleswitch.com

Highlights

Size and shape

Perfect size and shape to easily reach all face areas

Click-on brush head

Simply click on or click off the brush head. Easy to fit, our brush heads are compatible across all Visapure models.

Long operating time

For optimal results, replace the brush every three months

Brush Bristles

The specially designed filaments are even thinner and softer than those of the normal brush head to deliver an even softer and delicate cleansing experience specific for sensitive skin.

Designed for optimal hygiene

The silky soft bristle material of all our VisaPure brush heads is a specially chosen, delicate nylon. This helps to ensure the brush heads are super easy to clean and keep fresh.

Specifications

Benefits

Type of skin: For sensitive skin

Ease of use

Compatible with: Philips VisaPure Essential
Replacement: Easy snap-on brush head
Recommended replacement: Every 3 months

Service

Warranty: 2-year limited warranty



asimpleswitch.com

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.