


注册您的产品并在以下网站链接中了解详情
www.philips.com/AVENT

SCF722



AVENT
PHILIPS



EN Important safety instructions

For the safety and health of your child, adult supervision is required when your child uses the spoon.

- Before the first use and after each use, clean and sterilize the spoon.
- Before each use, check the spoon. If any damage or crack is detected, stop using the spoon immediately.

⚠ Warning:

- Prevent your child from running or walking while feeding.

! Caution:

- The spoon is intended for feeding. Do not use it to prepare food.
- There is stainless steel within the product. Therefore, it is unsuitable for microwave use.
- Check the food temperature before feeding.
- Do not over bend the spoon.

Cleaning and sterilization

! Caution:

- Never use abrasive, anti-bacterial cleaning agents, or chemical solvents.
- Do not place the spoon directly on surfaces that are cleaned with anti-bacterial cleaners.
- Food coloring can discolor the spoon.
- Use cleaning agents of appropriate concentration. Cleaning agents of excessive concentration may eventually cause the spoon to crack.
- Use a soft dishcloth to clean the spoon thoroughly in warm and soapy water, and then rinse them in clean water. Or, clean it on the top rack of dishwasher.
- Do not sterilize or store the spoon in drying or sterilizing cabinets with heating elements.




飞利浦新安怡
飞利浦电子(英国)有限公司
地址: 飞利浦中心, 吉尔福德商业区, 吉尔福德, 萨里
邮编: GU2 8XH

商标由飞利浦集团所有
©荷兰皇家飞利浦电子有限公司, 版权所有

3140 035 26471

SCF722_China_V1.1





Storage

! Caution:

- Never place the spoon near flames or other heat sources. Keep it from direct sunlight.
- For hygiene maintenance, store the spoon in a dry and covered container.

* Tip:

- This learning spoon is intended for babies under 12 months. For children of 12 months and above, Philips AVENT offers Toddler forks and spoons, like SCF712. For more product information, visit www.philips.com/AVENT.

ZHS 重要安全说明

为了宝宝的安全和健康，宝宝必须在成人的陪同下使用汤匙。

- 首次使用前及每次使用后，对汤匙进行清洁并消毒。
- 每次使用之前，先检查一下汤匙。如果发现损坏或破裂，请立即停止使用汤匙。

! 警告:

- 在喂食的过程中使宝宝不要跑动或走动。

! 注意:

- 汤匙适于喂食。请勿用其准备食物。
- 产品中含有不锈钢成分。因此，其不适合在微波炉中使用。
- 喂食前，必须检查食物温度。
- 不要过度弯折汤匙。

清洁和消毒

! 注意:

- 请勿使用腐蚀性抑菌清洁剂或化学溶液。
- 请勿将汤匙直接置于使用抗菌清洁剂清洁过的物体表面。

- 食物的色素可能使汤匙变色。
- 使用适当浓度的清洁剂。清洁剂浓度过高可能最终会造成汤匙破裂。
- 在温和的肥皂水中使用柔软的抹布彻底清洁汤匙，然后用清水冲洗干净。或者，在洗碗机的上搁架上进行清洁。
- 不要将汤匙放在带有加热元件的烘干或消毒柜中进行消毒或存放。

存储

! 注意:

- 切勿将汤匙置于靠近明火或其它热源的地方。不要将其置于阳光直射处。
- 为保持卫生，请将汤匙存放在干燥的带盖容器中。

* 提示:

- 此学习汤匙适用于 12 个月以下的婴儿。对于 12 个月或以上的婴儿，飞利浦新安怡可提供幼儿餐叉和汤匙，如 SCF712。有关产品的详细信息，请访问 www.philips.com/AVENT。

ZHT 重要安全指示

為了兒童的安全及健康，兒童使用湯匙時需有成人監督。

- 首次使用前及每次使用後，清潔並消毒湯匙。
- 每次使用前，檢查湯匙。如果發現任何損壞或裂痕，請立即停用湯匙。

! 警告:

- 餵食期間，避免兒童奔跑或行走。

! 注意:

- 湯匙用作餵食。請勿用作準備食物。
- 產品含有不銹鋼。因此，不適合微波使用。
- 餵食前，檢查食物溫度。
- 請勿弄彎湯匙。

清潔與消毒

! 注意:

- 請勿使用磨蝕性、抗菌清潔劑或化學溶劑。
- 請勿將湯匙直接放在使用抗菌清潔劑清潔的表面上。
- 食物顏色可導致湯匙退色。
- 使用適當濃度的清潔劑。濃度過高的清潔劑最終可能導致湯匙裂開。
- 在溫暖的肥皂水裡使用柔軟的抹布徹底清潔湯匙，然後在清水裡清洗。或者，放在洗碗機中清洗。
- 請勿在備有發熱元件的抽濕或消毒櫃消毒或存放湯匙。

存放

! 注意:

- 請勿將湯匙放在靠近火焰或其他熱源的位置。保存在遠離陽光直射的地方。
- 為了保持衛生，將湯匙存放在乾爽密封的容器內。

* 貼士:

- 此款學習湯匙為 12 個月以下的嬰兒而設。至於 12 個月及以上的嬰兒，Philips AVENT 提供幼兒餐叉及湯匙，如 SCF712。有關產品的更多資訊，請瀏覽 www.philips.com/AVENT。

PHILIPS
AVENT

产品	: 飞利浦新安怡学习汤匙
型号	: SCF722
主要材料	: 不锈钢、硅胶
使用温度	: 100 °C
检验	: 合格
产地	: 中国

珠海经济特区飞利浦家庭电器有限公司
中国珠海市三灶镇琴石工业区
邮政编码: 519040
全国顾客服务热线: 4008 800 008