

PHILIPS

Tongs for teat

SCF941



For handling teats hygienically

Find matching products on the specifications tab

Teats may be hot when removed from the steriliser. These Philips Avent teat tongs fit on the finger and thumb of one hand and allow you to grip the teat without touching it. A handy tool to keep teats sterile!

Ease of using Philips spare parts

- Easy renew your product with original Philips parts

Highlights

Easy renew of product parts

From time to time your product needs a facelift but it was never so easy like with Philips consumer replacement parts to renew your product. This all with guaranteed Philips quality.

Specifications

Replaceable part

Fits product type:: SCF666, SCF663, SCF660, SCF686, SCF683, SCF680, SCF276, SCF274, SCF271

Fits product types: SCF271/01, SCF271/02, SCF271/06, SCF271/07, SCF271/20, SCF271/42, SCF271/51, SCF274/01, SCF274/02, SCF274/13, SCF274/14, SCF274/15, SCF274/16, SCF274/23, SCF274/24, SCF274/26, SCF274/27, SCF274/29, SCF274/30, SCF274/31, SCF274/34, SCF274/35, SCF274/37, SCF274/38, SCF274/39, SCF274/51, SCF276/01, SCF276/02, SCF276/13, SCF276/14, SCF276/16, SCF276/23, SCF276/24, SCF276/26, SCF276/27, SCF276/29, SCF276/32, SCF276/33, SCF276/37, SCF276/38, SCF276/39, SCF276/40, SCF276/41, SCF276/42, SCF276/43, SCF276/44, SCF625/01, SCF680/00, SCF680/04, SCF680/17, SCF680/18, SCF680/19, SCF680/27, SCF680/28, SCF680/37, SCF680/47, SCF680/49, SCF680/57, SCF680/61, SCF680/62, SCF680/63, SCF680/64, SCF680/67, SCF683/00, SCF683/07, SCF683/08, SCF683/17, SCF683/18, SCF683/19, SCF683/27, SCF683/28, SCF683/37, SCF683/38, SCF683/47, SCF683/57, SCF683/61, SCF683/62, SCF683/63, SCF683/66, SCF683/67, SCF686/00, SCF686/17, SCF686/18, SCF686/19, SCF686/27, SCF686/37, SCF686/47, SCF686/61, SCF660/04, SCF660/07, SCF660/10, SCF660/17, SCF660/18, SCF660/20, SCF660/27, SCF660/28, SCF660/99, SCF663/00, SCF663/04, SCF663/07, SCF663/10, SCF663/17, SCF663/18, SCF663/20, SCF663/27, SCF663/28, SCF663/37, SCF663/47, SCF666/10, SCF666/17, SCF666/18, SCF666/27

