

## Assured feeding Soft ribbed teat for easy feeding

### Instructions for use

#### For your child's safety and health **WARNING!**

- For the health and safety of the child always use this product with adult supervision.
- Do not use the teat as a soother.
- Clean and sterilise the feeding teat before and after each use.
- Place in boiling water for five minutes or sterilise using a Philips AVENT electric or microwave steam steriliser. Consult the steriliser user manual for details. If sterilising solution is used do not immerse the teat for longer than the recommended time.
- Do not use corrosive or anti-bacterial cleaners, chemical solutions, or concentrated cleaners.
- Do not place components directly on surfaces that have been cleaned with anti-bacterial cleaners.
- Always assemble teats and screw ring when wet.
- During inspection of the teat, pull the teat in all directions. Throw away at the first signs of damage or weakness.
- Ensure the anti-colic valve (the valve on the side of the teat) is open. If the anti-colic valve is closed, pull the teat to the side to open it.
- To avoid damage to the teat, do not allow babies that are teething to feed for extended periods.
- Extended feeding of liquids may lead to tooth decay.
- Keep out of reach of children.
- Keep bottles and components away from heat sources and direct sunlight.
- Do not place feeding bottles in a heated drier or sterilising cabinet.
- For hygiene reasons, remove all components and store in a dry container with a lid.
- Wash both hands thoroughly before touching sterilised components.
- Ensure that the teat with the correct flow is used during feeding.
- Always check food temperature before feeding.
- For hygiene reasons, after 3 months we recommend replacing teats.
- Only use Philips AVENT Standard teats with Philips AVENT Standard feeding bottles.

